

SERVICE MANUAL

**T9.435 / T9.480 / T9.530 / T9.565
T9.600 / T9.645 / T9.700**

Tractor

PIN ZFF403001 and above

Part number 47924553

1st edition English

October 2015





SERVICE MANUAL

T9.435 Heavy duty wheeled model [ZFF403001 -] , T9.480 Heavy duty wheeled model [ZFF403001 -] , T9.530 Heavy duty wheeled model [ZFF403001 -] , T9.530 Wheeled scraper model [ZFF403001 -] , T9.565 Heavy duty wheeled model [ZFF403001 -] , T9.600 Heavy duty wheeled model [ZFF403001 -] , T9.600 Wheeled scraper model [ZFF403001 -] , T9.645 Heavy duty wheeled [ZFF403001 -] , T9.645 Standard wheeled model [ZFF403001 -] , T9.645 Wheeled scraper model [ZFF403001 -] , T9.700 Heavy duty wheeled model [ZFF403001 -]

Link Product / Engine

Product	Market Product	Engine
T9.435 Heavy duty wheeled model [ZFF403001 -]	Europe	F2CFE614A*B
T9.480 Heavy duty wheeled model [ZFF403001 -]	Europe	F3HFE613G*B001
T9.530 Heavy duty wheeled model [ZFF403001 -]	Europe	F3HFE613B*B001
T9.530 Wheeled scraper model [ZFF403001 -]	Europe	F3HFE613B*B001
T9.565 Heavy duty wheeled model [ZFF403001 -]	Europe	F3HFE613B*B001
T9.600 Heavy duty wheeled model [ZFF403001 -]	Europe	F3DFE613J*B001
T9.600 Wheeled scraper model [ZFF403001 -]	Europe	F3DFE613J*B001
T9.645 Standard wheeled model [ZFF403001 -]	Europe	F3DFE613G*B001
T9.645 Heavy duty wheeled [ZFF403001 -]	Europe	F3DFE613G*B001
T9.645 Wheeled scraper model [ZFF403001 -]	Europe	F3DFE613G*B001
T9.700 Heavy duty wheeled model [ZFF403001 -]	Europe	F3DFE613F*B001

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.202] Air cleaners and lines	10.3
[10.310] Aftercooler.....	10.4
[10.400] Engine cooling system	10.5
[10.414] Fan and drive	10.6
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.7
Power coupling.....	19
[19.110] Flywheel damper	19.1
Transmission.....	21
[21.113] Powershift transmission	21.1
[21.135] Powershift transmission external controls.....	21.2
[21.155] Powershift transmission internal components.....	21.3
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.310] Final drives	25.3
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
[27.120] Planetary and final drives	27.3
Power Take-Off (PTO)	31
[31.104] Rear electro-hydraulic control.....	31.1
[31.110] One-speed rear Power Take-Off (PTO)	31.2

[31.220] Gearbox	31.3
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.105] Charge pump.....	35.3
[35.106] Variable displacement pump	35.4
[35.204] Remote control valves	35.5
[35.220] Auxiliary hydraulic pump and lines	35.6
[35.300] Reservoir, cooler, and filters.....	35.7
[35.304] Combination pump units	35.8
[35.600] High flow hydraulics	35.9
Hitches, drawbars, and implement couplings.....	37
[37.100] Drawbars and towing hitches	37.1
Frames and ballasting	39
[39.100] Frame	39.1
[39.110] Drawbar and hitch assembly	39.2
Steering.....	41
[41.101] Steering control	41.1
[41.200] Hydraulic control components.....	41.2
[41.206] Pump	41.3
Cab climate control	50
[50.104] Ventilation	50.1
[50.200] Air conditioning	50.2
[50.300] Cab pressurizing system	50.3

Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.301] Alternator.....	55.3
[55.302] Battery.....	55.4
[55.010] Fuel injection system.....	55.5
[55.014] Engine intake and exhaust system.....	55.6
[55.024] Transmission control system.....	55.7
[55.045] Front axle control system	55.8
[55.046] Rear axle control system.....	55.9
[55.048] Rear Power Take-Off (PTO) control system	55.10
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.11
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls.....	55.12
[55.404] External lighting	55.13
[55.522] Cab Power Take-Off (PTO) controls	55.14
[55.640] Electronic modules	55.15
[55.035] Remote control valve electric control	55.16
[55.130] Rear three-point hitch electronic control system	55.17
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.18
[55.DTC] FAULT CODES.....	55.19
Platform, cab, bodywork, and decals	90
[90.100] Engine hood and panels	90.1
[90.102] Engine shields, hood latches, and trims	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.150] Cab.....	90.4
[90.151] Cab interior.....	90.5

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com