

SERVICE MANUAL

TC5.80 / TC5.90 / TC5.90 Hillside Combine

Part number 48001074

English
April 2016





SERVICE MANUAL

**TC5.80 FPT NEF TIER 4B
TC5.90 FPT NEF TIER 4B
TC5.90 Hillside FPT NEF TIER 4B**

Link Product / Engine

Product	Market Product	Engine
TC5.80 FPT NEF TIER 4B	Europe	F4HFE6137*B003
TC5.90 FPT NEF TIER 4B	Europe	F4HFE613D*B006
TC5.90 Hillside FPT NEF TIER 4B	Europe	F4HFE613D*B006

Contents

INTRODUCTION

Engine.....	10
[10.450] Engine air compressor	10.1
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.2
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.145] Gearbox internal components.....	21.3
[21.182] Differential.....	21.4
Front axle system	25
[25.310] Final drives	25.1
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.550] Non-powered rear axle.....	27.2
Hydrostatic drive.....	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.204] Reservoir, cooler, and lines	29.2
[29.218] Pump and motor components.....	29.3
[29.202] Hydrostatic transmission	29.4
[29.300] Rear hydrostatic transmission.....	29.5
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2

[35.106] Variable displacement pump	35.3
[35.359] Main control valve	35.4
[35.204] Remote control valves	35.5
[35.610] Machine leveling control system	35.6
[35.630] Machine lateral leveling system	35.7
[35.640] Machine longitudinal leveling system	35.8
[35.602] Header or attachment leveling system	35.9
[35.518] Reel control system	35.10
Steering.....	41
[41.200] Hydraulic control components.....	41.1
[41.101] Steering control	41.2
[41.206] Pump	41.3
[41.216] Cylinders	41.4
Cab climate control	50
[50.200] Air conditioning	50.1
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.3
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls.....	55.4
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.5
[55.834] Sieve electric control	55.6
[55.426] Harvest material flow control system.....	55.7
[55.618] Reverser electric control	55.8
[55.DTC] FAULT CODES.....	55.9
Attachments/Headers	58
[58.101] Attachment/Header reel.....	58.1
[58.900] Belt feeding	58.2

Product feeding	60
[60.101] Feed roll	60.1
[60.110] Feeder housing	60.2
[60.105] Floating roll, feed chain, and drive	60.3
[60.150] Feeder drive system	60.4
[60.122] Length-of-cut gearbox	60.5
[60.165] Feeder reverse system	60.6
Threshing	66
[66.000] Threshing	66.1
[66.330] Drum	66.2
[66.321] Drum/Rotor variator with electrical control	66.3
[66.105] Concave	66.4
[66.260] Threshing mechanism drive system	66.5
Separation	72
[72.350] Beater	72.1
[72.101] Straw walkers and shafts	72.2
Residue handling	73
[73.210] Straw chopper drive system	73.1
[73.215] Straw chopper electro-magnetic clutch support	73.2
Cleaning	74
[74.000] Cleaning	74.1
[74.101] Cleaning drive systems	74.2
[74.110] Grain pan	74.3
[74.114] Upper shaker shoe	74.4
[74.118] Lower shaker shoe	74.5
[74.130] Fan housing	74.6
[74.136] Fan drive system	74.7

[74.140] Tailings return system	74.8
Crop storage / Unloading	80
[80.180] Grain tank unload	80.1
[80.101] Clean grain elevator.....	80.2
Platform, cab, bodywork, and decals	90
[90.105] Machine shields and guards	90.1
[90.150] Cab.....	90.2
[90.156] Cab glazing	90.3

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com