


SERVICE MANUAL



**TC5040 [9622 -] , TC5050 [9622 -] , TC5060 [9622 -] , TC5070 [9622 -] ,
TC5070 , TC5080 Hillside , TC5080 [9622 -] , TC5080**

Contents

INTRODUCTION

| | |
|---|--------|
| Engine..... | 10 |
| Engine air compressor | 10.450 |
| Clutch | 18 |
| Clutch hydraulic release control | 18.104 |
| Clutch and components | 18.110 |
| Transmission..... | 21 |
| Mechanical transmission | 21.114 |
| Mechanical transmission external controls | 21.130 |
| Gearbox | 21.120 |
| Gearbox internal components | 21.145 |
| Differential | 21.182 |
| Front axle system | 25 |
| Final drives | 25.310 |
| Rear axle system..... | 27 |
| Planetary and final drives..... | 27.120 |
| Hydrostatic drive..... | 29 |
| Transmission and steering hydrostatic control | 29.100 |
| Reservoir, cooler, and lines..... | 29.204 |
| Pump and motor components | 29.218 |
| Hydrostatic transmission | 29.202 |
| Rear hydrostatic transmission | 29.300 |
| Brakes and controls | 33 |
| Hydraulic service brakes | 33.202 |
| Parking brake..... | 33.110 |
| Hydraulic systems..... | 35 |

| | |
|---|-----------|
| Hydraulic systems | 35.000 |
| Reservoir, cooler, and filters | 35.300 |
| Variable displacement pump | 35.106 |
| Main control valve | 35.359 |
| Remote control valves | 35.204 |
| Machine leveling control system | 35.610 |
| Machine lateral leveling system | 35.630 |
| Machine longitudinal leveling system..... | 35.640 |
| Header/Attachment leveling system..... | 35.602 |
| Reel control system | 35.518 |
| Steering..... | 41 |
| Hydraulic control components | 41.200 |
| Pump | 41.206 |
| Cylinders | 41.216 |
| Cab climate control | 50 |
| Air conditioning | 50.200 |
| Electrical systems | 55 |
| Electrical system | 55.000 |
| Harnesses and connectors | 55.100 |
| Selective Catalytic Reduction (SCR) electrical system..... | 55.988 |
| Electronic modules | 55.640 |
| Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls..... | 55.051 |
| Heating, Ventilation, and Air-Conditioning (HVAC) control system..... | 55.050 |
| Sieve electric control | 55.834 |
| Precision farming system..... | 55.785 |
| FAULT CODES | 55.DTC |
| Attachments/Headers..... | 58 |
| Attachment/Header reel | 58.101 |
| Belt feeding..... | 58.900 |

| | |
|---|-----------|
| Product feeding | 60 |
| Feed roll | 60.101 |
| Floating roll, feed chain, and drive | 60.105 |
| Feeder drive system..... | 60.150 |
| Length-of-cut gearbox | 60.122 |
| Threshing | 66 |
| Threshing..... | 66.000 |
| Drum..... | 66.330 |
| Drum/Rotor variator with electrical control | 66.321 |
| Concave | 66.105 |
| Separation | 72 |
| Beater | 72.350 |
| Straw walkers and shafts | 72.101 |
| Residue handling | 73 |
| Straw chopper drive system..... | 73.210 |
| Straw chopper electromagnetic clutch support..... | 73.215 |
| Cleaning | 74 |
| Cleaning | 74.000 |
| Cleaning drive systems..... | 74.101 |
| Grain pan | 74.110 |
| Upper shaker shoe | 74.114 |
| Lower shaker shoe | 74.118 |
| Fan housing | 74.130 |
| Fan drive system | 74.136 |
| Tailings return system | 74.140 |
| Crop storage / Unloading | 80 |
| Clean grain elevator | 80.101 |
| Platform, cab, bodywork, and decals | 90 |

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com