

850, 900HC, 950 and 1050 Tractors



JOHN DEERE

TECHNICAL MANUAL

850, 900HC, 950 and 1050
Tractors

TM1192 (01AUG86) English

John Deere
Lawn & Grounds Care Division
TM1192 (01AUG86)

LITHO IN U.S.A.
ENGLISH



850, 900HC, 950 AND 1050 TRACTORS

Technical Manual

TM-1192 (Aug-86)

SECTION AND GROUP CONTENTS

SECTION 10 - GENERAL

- Group 00 - Specifications and Special Tools
- Group 05 - Predelivery, Delivery, and After-Sale Services—850 and 950 Tractors
- Group 06 - Predelivery, Delivery, and After-Sale Services—1050 Tractor
- Group 10 - Tune-Up
- Group 15 - Lubrication
- Group 20 - Separation

SECTION 20 - ENGINE REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Cylinder Head, Valves, and Camshaft—850 and 950 Tractors
- Group 06 - Cylinder Head, Valves, and Camshaft—1050 Tractor
- Group 10 - Cylinder Block, Liners, Pistons and Rods
- Group 15 - Crankshaft, Main Bearings, and Flywheel
- Group 20 - Lubrication System
- Group 25 - Cooling System—850 and 950 Tractors*
- Group 26 - Cooling System—850, 950, and 1050 Tractors**

SECTION 30 - FUEL AND AIR REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - 850 and 950 Air Intake System
- Group 06 - 1050 Air Intake System
- Group 10 - Diesel Fuel System
- Group 15 - 850 and 950 Control Linkage*
- Group 16 - 850, 950, and 1050 Control Linkage**

SECTION 40 - ELECTRICAL REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - General Information
- Group 10 - Charging System
- Group 15 - Starting Circuit
- Group 20 - Lighting and Accessory Circuits

SECTION 50 - POWER TRAIN REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Engine and Clutch Linkage—850 (-16000) and 950 (-20000) Tractors

*850 (-009000), 950 (-012000)

**850 (009001-), 950 (012001-)

SECTION 50—POWER TRAIN REPAIR—Continued

- Group 06 - Engine and Clutch Linkage 850 (16001-), 950 (20001-) and 1050 Tractor
- Group 10 - Sliding Gear Transmission 850 (-16000) and 950 (-20000) Tractors
- Group 11 - Sliding Gear Transmission 850 (16001-), 950 (20001-) and 1050 Tractor
- Group 15 - PTO 850 (-16000) and 950 (-20000) Tractors
- Group 16 - PTO 850 (16001), 950 (20001-) and 1050 Tractor
- Group 20 - Differential 850 (-16000) and 950 (-20000) Tractors
- Group 21 - Differential 850 (16001-), 950 (20001-) and 1050 Tractor
- Group 25 - Final Drive—850-950 Tractors
- Group 26 - Final Drive—1050 Tractor
- Group 27 - Drop Housings and Final Drives—900HC Tractor
- Group 30 - Mechanical Front-Wheel Drive

SECTION 60 - STEERING/BRAKES REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Steering
- Group 10 - Power Steering
- Group 15 - Brakes

SECTION 70 - HYDRAULIC REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Hydraulic Pump and Oil Filters
- Group 10 - 850/950 Rockshaft and Implement Hitches
- Group 15 - 1050 Rockshaft and Implement Hitches
- Group 20 - Selective Control Valve

SECTION 80 - MISCELLANEOUS REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Front Axle Assembly
- Group 10 - Wheels

COPYRIGHT© 1986 DEERE & COMPANY

Moline, Illinois
All rights reserved
Previous Edition
Copyright © 1984
Copyright © 1980
Copyright © 1979
Copyright © 1978
Copyright © 1977
DEERE & COMPANY

SECTION AND GROUP CONTENTS—Continued

- SECTION 90 - OPERATOR STATION REPAIR
 Group 00 - Specifications and Special Tools
 Group 05 - ROLL-GARD®
 Group 10 - Canopy
- SECTION 220 - ENGINE OPERATION AND TESTS
 Group 00 - Specifications and Special Tools
 Group 05 - System Operation
 Group 10 - System Tests and Diagnosis
- SECTION 230 - FUEL/AIR OPERATION AND TESTS
 Group 00 - Specifications and Special Tools
 Group 05 - 850 and 950 Air Intake System
 Group 06 - 1050 Air Intake System
 Group 10 - Diesel Fuel System
 Group 15 - Speed Control Linkage—850 and 950 Tractors*
 Group 16 - Speed Control Linkage—850, 950, and 1050 Tractors**
- SECTION 240 - ELECTRICAL OPERATION AND TESTS
 Group 00 - Specifications and Special Tools
 Group 05 - General Information and Diagrams
 Group 10 - Charging System Diagnosis
 Group 15 - Starting Circuit Diagnosis
 Group 20 - Lighting and Accessory Circuits
- SECTION 250 - POWER TRAIN OPERATION AND TESTS
 Group 00 - Specifications and Special Tools
 Group 05 - Clutch and Transmission Operation—850 (-16000) and 950 (-20000) Tractors
 Group 06 - Clutch and Transmission Operation—850 (16001-), 950 (20001-) and 1050 Tractor
 Group 10 - Trouble Shooting the Clutch, Transmission and PTO—850 (-16000) and 950 (-20000) Tractors
 Group 11 - Trouble Shooting the Clutch, Transmission and PTO—850 (16001-), 950 (20001-) and 1050 Tractor
 Group 15 - Differential and Final Drive—850 (-16000) and 950 (-20000) Tractors
 Group 16 - Differential and Final Drive—850 (16001-), 950 (20001-) and 1050 Tractor
 Group 20 - Mechanical Front-Wheel Drive

SECTION 260 - STEERING/BRAKES OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
 Group 05 - Steering
 Group 10 - Power Steering
 Group 15 - Brakes

SECTION 270 - HYDRAULIC OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
 Group 05 - Hydraulic System Operation
 Group 10 - Hydraulic System Tests and Diagnosis
 Group 15 - Hydraulic Pump
 Group 20 - 850/950 Rockshaft and Implement Hitches
 Group 25 - 1050 Rockshaft and Implement Hitches
 Group 30 - Selective Control Valve



This tractor is of metric design. All hardware is therefore metric. Make sure you use the specified metric hardware when replacement becomes necessary. For your convenience most specifications are given in customary U.S. measurement with metric measurement following. Some specifications cannot be converted. Those appear in metric only.

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

*850 (-009000), 950 (-012000)

**850 (009001-), 950 (012001-)

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com