

COMPUTER TRAK™ 100, 200, and 300™ Planter Monitors



JOHN DEERE

OPERATORS MANUAL COMPUTER TRAK™ 100, 200, and 300™ Planter Monitors

OMA49879 Issue H5 English

John Deere Plow & Planter Works
OMA49879 Issue H5

LITHO IN U.S.A.
ENGLISH



OWNER REGISTER

Name _____
Post Office _____
County _____
City _____ State _____
Model _____
Monitor Serial No. _____
Power Module Serial No. _____
Radar Serial No. _____
Date Sold _____

DELIVERY CHECK LIST

The following check list is a reminder of very important information which should be conveyed directly to the customer at the time the monitor is delivered. Check off each item as it is fully explained to the customer.

- Give the operator's manual to the customer and explain all operating adjustments.
- To the best of my knowledge this monitor has been delivered ready for field use and customer has been fully informed as to proper care and operation.

(Date Delivered)

(Signature of Delivery Person)



Contents

Page	
2	Safety
3	Attaching and Detaching
4-33	Operating the Monitor
34-35	Trouble Shooting
36-37	Service
38-64	Assembly
65-66	Specifications
67	Index



Safety

Electrical Connections

Keep all sparks and flames away from battery, as gas given off by electrolyte is explosive. To avoid sparks, connect ground cable last and disconnect it first.

Do Not Modify the Monitor or Radar Sensor

Unauthorized modifications to the monitor or radar sensor may impair the function and void the warranty on the monitor or radar sensor.

Read Safety Signs Carefully

Carefully read and follow all CAUTION and WARNING safety signs.

Keep safety signs in good condition. Replace missing or damaged safety signs.



A29117

A29117

Radar Sensor

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com