


omar178070 - 8120, 8220, 8320, 8420, and 8520 Tractors (North American Edition)

Using Auxiliary Power Strip- *If Equipped*

Using Auxiliary Power Strip- *If Equipped*



RW26240-UN: Auxiliary Power Strip

LEGEND:

A - Auxiliary Power Strip

IMPORTANT:

Power strip is not a surge suppressor. Electrical equipment with program memory requires protection from damage of electrical surges and spikes.

The power strip (A) provides six outlets, of 12-volt power with grounds. This power is 30 amp switched and 30 amp unswitched. The connectors can be used when connecting auxiliary equipment.

Adapters plug directly into power strip as unswitched power. To change to switched power on cigarette lighter adapter or standard adapter (with three wires), remove small tab at end of slot on plug and rotate plug 180°.


NOTE:

*The small white dot on adapter plug face next to the cap hinge indicates circuit is **unswitched** . If dot is opposite cap hinge, circuit is **switched** .*

Adapters are available from your John Deere Dealer for the following: cigarette lighter adapters, three-way convenience adapters, and standard adapters.

omar178070 - 8120, 8220, 8320, 8420, and 8520 Tractors (North American Edition)
Identifying GREENSTAR™ System Connections- *If Equipped*

Identifying GREENSTAR™ System Connections- *If Equipped*



RXA0071146-UN: GreenStar Connections



RXA0071147-UN: GPS Receiver Connector


LEGEND:

- A - Display Monitor Connector
- B - Mobile Processor Connector
- C - Corner Post Display Connector
- D - GPS Receiver Connector


Connectors (A-C) are behind the corner post cover.

Connector (D) is by the front wiper motor.

Nine-Pin connector (A) located at rear of tractor.



RXA0071148-UN: Early Version Implement Connector



RXA0071145-UN: Late Version Implement Connector

LEGEND:

- A - Implement Connector
- B - Release
- C - Handle


For later version tractors, push release (B) and pull handle (C) to open implement connector.

omar178070 - 8120, 8220, 8320, 8420, and 8520 Tractors (North American Edition) Using Monitor Mounts


Using Monitor Mounts



RXA0057158-UN: Corner Post



RW26659-UN: Rear Cab Post



RW26695-UN: Side Console

Monitor mounting points are used to connect implement monitors to the cab.

-: Monitor Mounting Points

Mounting Locations


A-Corner Post Display

B-Rear Cab Post

C-Side Console

omar178070 - 8120, 8220, 8320, 8420, and 8520 Tractors (North American Edition)
Using Electric Rear View Mirror- *If Equipped*

Using Electric Rear View Mirror- *If Equipped*



RXA0053037-UN: Rear View Mirror Switch



RXA0053034-UN: Electrical Right Rear View Mirror

LEGEND:

- A - Switch
- B - Rear View Mirror
- C - Knob

Push switch (A) in the direction desired to adjust right rear view mirror (B).

Loosen knob (C) to adjust distance of the mirror from cab.


omar178070 - 8120, 8220, 8320, 8420, and 8520 Tractors (North American Edition)

Using Storage Compartment-If Equipped

Using Storage Compartment-If Equipped



RXA0056378-UN: Storage Compartment Cover



RXA0056379-UN: Storage Compartment

LEGEND:

- A - Retainer
- B - Storage Compartment

NOTE:


Early models had storage capability for tools in battery compartment. Current models have tool box on left side of tractor with no storage space in battery compartment.

Remove retainer (A) and cover to gain access to storage compartment (B).

omar178070 - 8120, 8220, 8320, 8420, and 8520 Tractors (North American Edition)

Positioning Steps and Handrails

Positioning Steps and Handrails



RXA0056383-UN: Position Steps and Handrails

LEGEND:

- A - Step Angle Bolts
- B - Handrail
- C - Step Positioning Bolts

Steps

Step assembly can be adjusted to accommodate various row spacings, crop height or attachments.

Change step assembly angle by removing bolts (A). Move step assembly and install bolts.

Handrail

Handrail (B) should be positioned in conjunction with the steps.

Change step position by removing bolts (C). Move step and install bolts.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com