

2020 Tractor (117,500-)



TECHNICAL MANUAL

2020 Tractor (117,500-)

TM1044 (01FEB71) English

John Deere Tractor Works TM1044 (01FEB71)

LITHO IN U.S.A. ENGLISH



2020 TRACTOR TECHNICAL MANUAL TM-1044 (Feb-71)

CONTENTS

SECTION 10 - GENERAL	SECTION 50 - POWER TRAIN
Group 5 - Specifications	Group 5 - Clutches
Group 10 - Predelivery, Delivery, and After-Sale	Group 10 - Hi-Lo Shift Unit
Services	Group 15 - Reverser
Group 15 - Tune-Up and Adjustment	Group 20 - Collar Shift Transmission
Group 20 - Lubrication	Group 25 - Differential
Group 25 - Separation	Group 30 - Final Drive
Group 25 - Coparation	Group 35 - Continuous and Transmission PTO
SECTION 20 - ENGINE	Group 40 - Independent PTO
Group 5 - General Information, Diagnosis, and	Group 45 - Belt Pulley
Tests	Group 45 - Bett runey
Group 10 - Cylinder Head, Valve Train, and Cam-	SECTION 60 - STEERING AND BRAKES
shaft	Group 5 - General Information
Group 15 - Cylinder Block, Liners, Pistons, and	Group 5 " General Information
Rods	SECTION 70 - HYDRAULIC SYSTEM
Group 20 - Crankshaft, Main Bearings, and Fly-	Group 5 - General Information, Diagnosis and
wheel	Tests
Group 25 - Timing Gear Train	Group 10 - Miscellaneous Hydraulic Components
Group 30 - Lubrication System	Group 15 - Hydraulic Pumps
Group 35 - Cooling System	Group 20 - Steering System
Group 40 - Governor and Speed Control Linkage	Group 25 - Hydraulic Brakes
Group 40 - Governor and opeed Control Emikage	Group 30 - Rockshaft System
SECTION 30 - FUEL SYSTEM	· · · · · · · · · · · · · · · · · · ·
Group 5 - Diagnosing Malfunctions	Group 35 - Selective Control Valve, Breakaway
· • •	Couplers, and Remote Cylinders
Group 10 - Fuel Injection System	OFOTION OF AMERICA
Group 15 - Gasoline Fuel System	SECTION 80 - MISCELLANEOUS
OFOTION 40 FLECTBLOAL SYSTEM	Group 5 - Front Axle
SECTION 40 - ELECTRICAL SYSTEM	
Group 5 - Information and Diagrams	
Group 10 - Charging Circit	

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Copyright 1971 DEERE & COMPANY Moline, Illinois All rights reserved

Group 15 - Starting Circuit Group 20 - Ignition Circuit

Group 25 - Lighting and Accessory Circuits

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com