

9935 Cotton Picker

For complete service information also see:

6068 Engine CTM104
Engine Fuel Injection CTM68
Starting Motors and Alternators CTM77

John Deere Des Moines Works
TM1613 (18SEP01)

LITHO IN U.S.A.
ENGLISH

Contents

SECTION 10—GENERAL

- Group 05 —Safety
- Group 09 —General Specifications
- Group 15 —Fuels and Lubricants
- Group 20 —Welding Repair

SECTION 20—ENGINE REPAIR

- Group 05 —Remove and Install Engine
- Group 10 —Cooling System Repair

SECTION 30—FUEL AND AIR REPAIR

- Group 05 —Diesel Fuel System
- Group 10 —Control Linkage

SECTION 40—ELECTRICAL REPAIR

- Group 05 —Charging Circuit
- Group 10 —Starting Circuit
- Group 15 —Monitor and Gauges
- Group 20 —Accessory Circuit
- Group 25 —Connector Repair

SECTION 50—POWER TRAIN REPAIR

- Group 05 —Hydrostatic Drive
 - Components—Remove and Install
- Group 06 —Hydrostatic Drive
 - Components—Repair
- Group 10 —Transmission
- Group 15 —Final Drive
- Group 20 —Control Linkage

SECTION 60—STEERING AND BRAKES REPAIR

- Group 05 —Remove and Install Steering
 - Components
- Group 06 —Steering Column Repair
- Group 07 —Steering Metering Pump Repair
- Group 08 —Steering Cylinder Repair
- Group 10 —Brake Repair

SECTION 70—HYDRAULIC SYSTEM REPAIR

- Group 05 —Hydraulic Pump
- Group 10 —Solenoid Control Valve Repair
- Group 15A —Basket Lift Cylinder Repair
- Group 15B —Picking Unit Lift Cylinder Repair

- Group 15C —Vane Dump Control Cylinder Repair
- Group 15D —Steering Cylinder
- Group 20 —Compactor Hydraulic Motor Repair
- Group 25 —Height Control Valve Repair

SECTION 80—GUIDE AXLE AND WHEEL HUB REPAIR

- Group 05 —Axle and Wheel Hub Repair

SECTION 90—OPERATOR'S STATION REPAIR

- Group 05 —Air Conditioning System Repair
- Group 10 —Heating System
- Group 15 —Seat Repair
- Group 20 —Cab Repair

SECTION 100—PICKING UNIT REPAIR—IN-LINE UNITS

- Group 05 —Remove and Install
- Group 10 —Grid Bar and Pressure Plate
- Group 15 —Spindle and Picker Bar
- Group 20 —Drums, Drive Shafts, and Gear
- Group 25 —Idler Gear
- Group 30 —Doffer Columns
- Group 35 —Moistener Column
- Group 40 —Gear Cases and Countershafts
- Group 45 —Cabinet and Cam Track Alignment

SECTION 105—Picking Unit Repair—PRO 12 Units

- Group 04 —Picking Unit—Remove and Install
- Group 10 —Grid Bar and Pressure Plate
- Group 15 —Spindle and Picker Bar
- Group 20 —Drums, Drive Shafts, and Gear
- Group 25 —Idler Gear
- Group 30 —Doffer Columns
- Group 35 —Moistener Column
- Group 40 —Gear Cases and Countershaft
- Group 45 —Cabinet and Cam Track Alignment

SECTION 110—LUBRICATION SYSTEM REPAIR

- Group 05 —Lubrication System Pump Repair
- Group 09 —Solenoid Control Valve Repair
- Group 15 —Transfer Pump Repair

Continued on next page

SECTION 120—SOLUTION SYSTEM REPAIR

Group 05 —Water System Components

SECTION 130—AIR SYSTEM REPAIR

Group 05 —Cotton Fan Repair

**SECTION 210—OPERATIONAL CHECKOUT
PROCEDURE**

Group 05 —Machine Operational Checkout
Group 09 —Diagnostic/Testing Procedures
Group 15 —Tune-Up and Adjustments

SECTION 220—ENGINE OPERATION AND TESTS

Group 05 —System Operational Checks
Group 10 —Diagnostic Information
Group 15 —Engine System Operation and Tests
Group 19 —Theory of Operation

**SECTION 230—FUEL/AIR OPERATION AND
TESTS**

Group 05 —System Operational Checks
Group 10 —Diagnostic Information
Group 15 —System Tests
Group 20 —System Adjustments
Group 25 —Theory of Operation

**SECTION 240—ELECTRICAL OPERATION AND
TESTS**

Group 05 —System Information
Group 10 —System Diagnosis
Group 15 —Sub-System Diagnostics
Group 15A —Power Circuit
Group 15B —Start Circuit
Group 15C —Charging Circuit
Group 15D —Lighting System Circuit
Group 15E —Horn Circuit
Group 15F —Monitor System Circuit
Group 15G —Gauges Circuit
Group 15H —Tachometer Circuit (P.I.N.
—2000)
Group 15I —Tachometer Circuit (P.I.N. 2001—)
Group 15J —Windshield Wiper Circuit
Group 15K —Dome and Console Light Circuit
Group 15L —Lighter Circuit
Group 15M —Radio Circuit (P.I.N. 2001—)
Group 15N —Cab Blower and Air Conditioning
Circuit
Group 15O —Auxiliary Plug Circuit
Group 15P —Basket Electro-Hydraulic Controls
Circuit

Group 15Q —Units Electro-Hydraulic Controls
Circuit

Group 15R —Fan Actuator Circuit

Group 15S —Destroke, Tether and Lube Circuit

**SECTION 250—POWER TRAIN OPERATION AND
TESTS**

Group 05 —System Operational Checks
Group 10 —System Diagnostic Checks
Group 15 —System Tests
Group 20 —System Adjustments
Group 25 —Theory of Operation

**SECTION 260—STEERING AND BRAKES
OPERATIONS AND TESTS**

Group 05 —System Operational Checks
Group 10 —System Diagnostics
Group 15 —System Tests
Group 20 —System Adjustments
Group 25 —Theory of Operation

**SECTION 270—HYDRAULIC SYSTEM
OPERATION AND TESTS**

Group 05 —Operational Checks
Group 10 —Hydraulic System Diagnosis
Group 10A —Hydraulic Pump Diagnostics
Group 10B —Solenoid Control Valve Diagnostics
Group 10C —Hydraulic Cylinder Diagnostics
Group 10D —Height Sensing System Diagnostics
Group 15 —Hydraulic System Tests
Group 20 —Hydraulic System Adjustments
Group 25A —Theory of Operation
Group 25B —Hydraulic Pump Operation
Group 25C —Solenoid Control Valve Operation
Group 25D —Hydraulic Cylinder Operation
Group 25E —Hydraulic Motor Operation
Group 25F —Height Control Operation

**SECTION 290—OPERATOR'S STATION
OPERATION AND TESTS**

Group 05 —Operator's Station Operational
Checks
Group 10 —Operator's Station Diagnostics
Group 15A —Air Conditioning System Tests
Group 20 —Operator's Station Tests
Group 25 —Operator's Station Theory of
Operation

**SECTION 300—IN-LINE PICKING UNIT
OPERATION AND TESTS**

Group 05 —Picking Unit Diagnostics
Group 10 —Picking Unit Adjustments
Group 15 —Picking Unit Theory of Operation

Continued on next page

**SECTION 305—PRO-12 PICKING UNITS
OPERATION AND TESTS**

- Group 04 —Diagnostics
- Group 10 —PRO-12 Picking Units Adjustments
- Group 15 —Picking Unit Theory of Operation

105

**SECTION 310—PICKING UNIT LUBRICATION
SYSTEM OPERATION AND
TESTS**

- Group 05 —Lubrication System Operational Checks
- Group 09 —Lubrication System Diagnostics
- Group 15 —Lubrication System Tests
- Group 25 —Lubrication System Theory of Operation

110

120

**SECTION 320—SOLUTION SYSTEM OPERATION
AND TEST**

- Group 05 —Solution System Operational Checks
- Group 10 —Solution System Diagnostics
- Group 15 —Solution System Adjustments
- Group 25 —Solution System Theory of Operation

130

**SECTION 330—AIR SYSTEM OPERATION AND
TEST**

- Group 05 —Air System Operational Checks
- Group 10 —Air System Diagnostics
- Group 15 —Air System Adjustments
- Group 20 —Air System Theory of Operation

210

**SECTION 399—DEALER FABRICATED SPECIAL
TOOLS**

- Group 05 —Fabricated Tools

220

Index

230

240

250

260

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com