Rowtrac™ 350 / 400 / 450 / 500
Steiger® 350 / 400 / 450 / 500 / 550 / 600
Quadtrac® 450 / 500 / 550 / 600
Tier 4
Tractor

SERVICE MANUAL

Part number 47488212
English
February 2013
Replaces part number 84354095

CASE IH AGRICULTURE

SERVICE MANUAL

Rowtrac 350 [ZDF100001 -] , Rowtrac 400 [ZDF100001 -] , Rowtrac 450 [ZDF100001 -] , Rowtrac 500 [ZDF100001 -] , Steiger 350 [ZBF100001 -] , Steiger 350 [ZCF100001 -] , Steiger 350 [ZDF100001 -] , Steiger 400 [ZBF100001 -] , Steiger 400 [ZCF100001 -] , Steiger 400 [ZDF100001 -] , Steiger 450 QT [ZBF100001 -] , Steiger 450 QT [ZCF100001 -] , Steiger 450 QT [ZDF100001 -] , Steiger 450 [ZBF100001 -] , Steiger 450 [ZCF100001 -] , Steiger 450 [ZDF100001 -] , Steiger 500 QT [ZBF100001 -] , Steiger 500 QT [ZCF100001 -] , Steiger 500 QT [ZDF100001 -] , Steiger 500 [ZBF100001 -] , Steiger 500 [ZCF100001 -] , Steiger 500 [ZDF100001 -] , Steiger 550 QT [ZBF100001 -] , Steiger 550 QT [ZCF100001 -] , Steiger 550 QT [ZDF100001 -] , Steiger 550 [ZBF100001 -] , Steiger 550 [ZCF100001 -] , Steiger 550 [ZDF100001 -] , Steiger 600 QT [ZBF100001 -] , Steiger 600 QT [ZCF100001 -] , Steiger 600 QT [ZDF100001 -] , Steiger 600 [ZBF100001 -] , Steiger 600 [ZCF100001 -] , Steiger 600 [ZDF100001 -]

47488212 04/10/2013

EN

Link Product / Engine

Product	Market Product	Engine
null [ZDF100001 -]	North America	F2CFE614A*A
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZBF100001 -]	North America	F2CFE614A*A
null [ZCF100001 -]	North America	F2CFE614A*A
null [ZDF100001 -]	North America	F2CFE614A*A
null [ZBF100001 -]	North America	F3BFE613A*A001
null [ZCF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZBF100001 -]	North America	F3BFE613A*A001
null [ZCF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZBF100001 -]	North America	F3BFE613A*A001
null [ZCF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZBF100001 -]	North America	F3BFE613A*A001
null [ZCF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZBF100001 -]	North America	F3BFE613A*A001
null [ZCF100001 -]	North America	F3BFE613A*A001
null [ZDF100001 -]	North America	F3BFE613A*A001
null [ZBF100001 -]	North America	F3DFE613A*A001
null [ZCF100001 -]	North America	F3DFE613A*A001
null [ZDF100001 -]	North America	F3DFE613A*A001
null [ZBF100001 -]	North America	F3DFE613A*A001
null [ZCF100001 -]	North America	F3DFE613A*A001
null [ZDF100001 -]	North America	F3DFE613A*A001
null [ZBF100001 -]	North America	F3DFE613A*A001
null [ZCF100001 -]	North America	F3DFE613A*A001
null [ZDF100001 -]	North America	F3DFE613A*A001
null [ZBF100001 -]	North America	F3DFE613A*A001
null [ZCF100001 -]	North America	F3DFE613A*A001
null [ZDF100001 -]	North America	F3DFE613A*A001

Contents

INTRODUCTION

Engine 10

[10.001] Engine and crankcase 10.1

[10.202] Air cleaners and lines 10.2

[10.400] Engine cooling system 10.3

[10.414] Fan and drive 10.4

[10.500] Selective Catalytic Reduction (SCR) exhaust treatment 10.5

Transmission 21

[21.113] Powershift transmission 21.1

[21.135] Powershift transmission external controls 21.2

[21.145] Gearbox internal components 21.3

[21.155] Powershift transmission internal components 21.4

Front axle system 25

[25.100] Powered front axle 25.1

[25.102] Front bevel gear set and differential 25.2

[25.310] Final drives 25.3

[25.500] Front axle track yoke assembly 25.4

Rear axle system 27

[27.100] Powered rear axle 27.1

[27.106] Rear bevel gear set and differential 27.2

[27.120] Planetary and final drives 27.3

[27.610] Rear axle track yoke assembly 27.4

Power Take-Off (PTO) 31

[31.104] Rear electro-hydraulic control 31.1

[31.110] One-speed rear Power Take-Off (PTO) 31.2

[31.220] Gearbox 31.3

Brakes and controls 33
[33.110] Parking brake or parking lock 33.1
[33.202] Hydraulic service brakes 33.2
Hydraulic systems 35
[35.000] Hydraulic systems 35.1
[35.102] Pump control valves 35.2
[35.105] Charge pump 35.3
[35.106] Variable displacement pump 35.4
[35.204] Remote control valves 35.5
[35.220] Auxiliary hydraulic pump and lines 35.6
[35.300] Reservoir, cooler, and filters 35.7
[35.304] Combination pump units 35.8
[35.600] High flow hydraulics 35.9
Hitches, drawbars, and implement couplings 37
[37.100] Drawbars and towing hitches 37.1
Frames and ballasting 39
[39.100] Frame 39.1
[39.110] Drawbar and hitch assembly 39.2
Steering 41
[41.101] Steering control 41.1
[41.200] Hydraulic control components 41.2
[41.206] Pump 41.3
Wheels 44
[44.511] Front wheels 44.1
[44.520] Rear wheels 44.2
Tracks and track suspension 48
[48.100] Tracks 48.1
[48.130] Track frame and driving wheels 48.2

[48.134] Track tension units 48.3
[48.138] Track rollers 48.4
Cab climate control 50
[50.104] Ventilation 50.1
[50.200] Air conditioning 50.2
[50.300] Cab pressurizing system 50.3
Electrical systems 55
[55.010] Fuel injection system 55.1
[55.014] Engine intake and exhaust system 55.2
[55.024] Transmission control system 55.3
[55.035] Remote control valve electric control 55.4
[55.045] Front axle control system 55.5
[55.046] Rear axle control system 55.6
[55.048] Rear Power Take-Off (PTO) control system 55.7
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system 55.8
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls 55.9
[55.100] Harnesses and connectors 55.10
[55.130] Rear three-point hitch electronic control system 55.11
[55.301] Alternator 55.12
[55.302] Battery 55.13
[55.404] External lighting 55.14
[55.522] Cab Power Take-Off (PTO) controls 55.15
[55.640] Electronic modules 55.16
[55.988] Selective Catalytic Reduction (SCR) electrical system 55.17
[55.DTC] FAULT CODES 55.18
Platform, cab, bodywork, and decals 90
[90.100] Engine hood and panels 90.1
[90.102] Engine shields, hood latches, and trims 90.2

[90.124] Pneumatically-adjusted operator seat. 90.3
[90.150] Cab 90.4
[90.151] Cab interior 90.5

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com