WX148
Wheeled Excavator

SERVICE MANUAL

CASE CONSTRUCTION

Part number 48005353
English
April 2016

Link Product / Engine

Product	Market Product	Engine
WX148 Wheeled excavator Mono Tier3 MY2013 - Nef 4 CYL Mech	Middle East Africa	F4GE9484
WX148 Wheeled excavator Mono Tier3 MY2013 - Nef 4 CYL Mech	Europe	F4GE9484
WX148 Wheeled excavator 2PB Tier3 MY2013 - Nef 4 CYL Mech	Europe	F4GE9484
WX148 Wheeled excavator 2PB Tier3 MY2013 - Nef 4 CYL Mech	Asia Pacific	F4GE9484
WX148 Wheeled excavator 2PB Tier3 MY2013 - Nef 4 CYL Mech	Middle East Africa	F4GE9484
WX148 Wheeled excavator Mono Tier3 MY2013 - Nef 4 CYL Mech	Asia Pacific	F4GE9484

Contents

INTRODUCTION

Engine 10

[10.202] Air cleaners and lines 10.1

[10.206] Fuel filters 10.2

[10.216] Fuel tanks 10.3

[10.218] Fuel injection system 10.4

[10.254] Intake and exhaust manifolds and muffler 10.5

[10.310] Aftercooler 10.6

[10.400] Engine cooling system 10.7

Transmission 21

[21.105] Powershift transmission lubrication system 21.1

[21.113] Powershift transmission 21.2

[21.135] Powershift transmission external controls 21.3

[21.155] Powershift transmission internal components 21.4

Four-Wheel Drive (4WD) system 23

[23.314] Drive shaft 23.1

Front axle system 25

[25.100] Powered front axle 25.1

[25.102] Front bevel gear set and differential 25.2

[25.108] Final drive hub, steering knuckles, and shafts 25.3

[25.122] Axle suspension control 25.4

Rear axle system 27

[27.100] Powered rear axle 27.1

[27.106] Rear bevel gear set and differential 27.2

[27.120] Planetary and final drives 27.3

Brakes and controls 33

[33.110] Parking brake or parking lock 33.1
[33.202] Hydraulic service brakes 33.2
Hydraulic systems 35
[35.000] Hydraulic systems 35.1
[35.106] Variable displacement pump 35.2
[35.300] Reservoir, cooler, and filters 35.3
[35.304] Combination pump units 35.4
[35.352] Hydraulic swing system 35.5
[35.353] Hydraulic travel system 35.6
[35.354] Hydraulic central joint 35.7
[35.357] Pilot system 35.8
[35.359] Main control valve 35.9
[35.360] Hammer and rotating bucket hydraulic system 35.10
[35.703] Stabilizer hydraulic system 35.11
[35.730] Positioning arm hydraulic system 35.12
[35.736] Boom hydraulic system 35.13
[35.737] Dipper hydraulic system 35.14
[35.738] Excavator and backhoe bucket hydraulic system 35.15
[35.741] Dozer blade cylinders 35.16
Frames and ballasting 39
[39.103] Swing ring assembly 39.1
[39.129] Stabilizers 39.2
[39.140] Ballasts and supports 39.3
Steering 41
[41.101] Steering control 41.1
[41.106] Tie rods 41.2
[41.200] Hydraulic control components 41.3
[41.216] Cylinders 41.4

Wheels 44
[44.511] Front wheels 44.1
[44.520] Rear wheels 44.2
Cab climate control 50
[50.200] Air conditioning 50.1
Electrical systems 55
[55.000] Electrical system 55.1
[55.010] Fuel injection system 55.2
[55.011] Fuel tank system 55.3
[55.012] Engine cooling system 55.4
[55.014] Engine intake and exhaust system 55.5
[55.015] Engine control system 55.6
[55.020] Transmission speed sensors 55.7
[55.036] Hydraulic system control 55.8
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system 55.9
[55.100] Harnesses and connectors 55.10
[55.110] Electrical rotary joint 55.11
[55.302] Battery 55.12
[55.404] External lighting 55.13
[55.416] Swing control system 55.14
[55.425] Boom, dipper, and bucket control system 55.15
[55.512] Cab controls 55.16
[55.514] Cab lighting 55.17
[55.525] Cab engine controls 55.18
[55.530] Camera 55.19
[55.640] Electronic modules 55.20
Booms, dippers, and buckets 84
[84.100] Bucket 84.1

[84.910] Boom 84.2

Dozer blade and arm 86

[86.110] Dozer blade 86.1

Platform, cab, bodywork, and decals 90

[90.118] Protections and footboards 90.1

[90.124] Pneumatically-adjusted operator seat 90.2

[90.150] Cab 90.3

[90.151] Cab interior 90.4

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com