

---

# SECTION 00 - GENERAL INFORMATION

BOOK 1 - 86705316

## CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
00 000	Precautionary Statements .....	3
	Safety Precautions .....	3
	General Considerations .....	5
	Tractor Identification .....	12
	Engine Identification .....	15
	Service Techniques .....	17
	Minimum Hardware Tightening Torques .....	18
	Standard Torque Data .....	20
	Recommended Lubricants and Coolants .....	22
	Recommended Sealants .....	24

---

# SECTION 10 - ENGINE

BOOK 1 - 86705316

## Chapter 1 - Engine Systems

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	<b>AIR INDUCTION SYSTEM</b>	
	Specifications .....	3
	Bolt Torque Specifications .....	4
	Special Tools .....	6
	Air Induction System - Description and Operation .....	6
	Introduction .....	6
	Component Operation .....	8
	Troubleshooting .....	10
	Turbocharger Boost Testing .....	11
	Air Induction System - Removal and Repair of Components .....	13
	Turbocharger Intake Tube .....	13
	Turbocharger Outlet Tube .....	14
	Air Filter Housing, Precleaner, and Air Induction Scoop .....	15
	Turbocharger .....	20
	Repair Time Schedule .....	25
	<b>EXHAUST SYSTEM</b>	
	Specifications .....	26
	Bolt Torque Specifications .....	27
	Exhaust System - Description of Operation .....	27
	Exhaust System Component Removal and Repair .....	28
	Exhaust Muffler and Stack .....	28
	Repair Time Schedule .....	32
	<b>ENGINE</b>	
	Engine Specifications .....	33
	Torque Values .....	40
	Special Tools .....	42
	Description and Operation .....	44
	Introduction .....	44
	Cylinder Head Assembly .....	44
	Camshaft Assembly .....	46
	Connecting Rods .....	47
	Pistons .....	48
	Manifolds .....	48
	Cylinder Block Assembly .....	48
	Timing Gears .....	49

---

## SECTION 10 - ENGINE (CONTINUED)

BOOK 1 - 86705316

### Chapter 1 - Engine Systems

Section	Description	Page
	Lubrication System .....	50
	Troubleshooting .....	51
	Dynamometer Engine Testing .....	55
	Dynamometer Engine Break In .....	59
	Compression Test .....	60
	Engine Overhaul .....	62
	Introduction .....	62
	Engine Removal .....	62
	Engine Disassembly .....	76
	Engine Component Disassembly, Inspection, and Assembly .....	88
	Front Timing Gears, Oil Pan, Camshaft, and Valve Tappets (Lifters) .....	97
	Pistons and Connecting Rods .....	99
	Crankshaft and Main Bearings .....	103
	Oil Pump and Sump Tube .....	109
	Oil Cooler/Filter Support Assembly .....	111
	Flywheel .....	112
	Engine Assembly .....	113
	Engine Installation .....	132
	Repair Time Schedule – Engine Overhaul .....	143
	<b>COOLING SYSTEM</b>	
	Bolt Torque Specifications .....	154
	Special Tools .....	150
	Cooling System Description and Operation .....	151
	Introduction .....	151
	Individual Component Operation .....	152
	Cooling System Troubleshooting .....	157
	Cooling System Testing .....	158
	Cooling System Tests .....	158
	Cooling System - Removal and Repair of Components .....	163
	Radiator .....	163
	Thermostat .....	168
	Cooling Fan (North American Models) .....	171
	Cooling Fan and Viscous Clutch (International Models) .....	172
	Fan Belt Tensioner .....	173
	Water Pump .....	175
	Repair Time Schedule - Cooling System .....	186

---

# SECTION 10 - ENGINE

BOOK 1 - 86705316

## Chapter 2 - Fuel System

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	FUEL SYSTEM	
	Specifications .....	2
	TV140 Fuel Injection Pump Test Plan .....	3
	Special Tools .....	4
	Fuel System – Description and Operation .....	5
	Introduction .....	5
	Fuel Injection Pump .....	12
	Engine Shutoff .....	18
	Troubleshooting .....	19
	Injector Nozzle Testing .....	20
	Fuel System Service .....	24
	Bleeding The Fuel Injection System .....	24
	Fuel Injectors .....	25
	Bosch VE Fuel Injection Pump .....	30
	Electric Lift Pump .....	39
	Fuel Sedimenter .....	40
	Fuel Filter .....	43
	Fuel Tanks .....	46
	Crossover Tube .....	53
	Cold Start System – North American Models .....	54
	Cold Start System – International Models .....	58
	Throttle Cable .....	59
	Repair Time Schedule - Fuel System .....	65

---

# SECTION 21 - TRANSMISSIONS

BOOK 2 - 86705317

## Chapter 1 - Splitter Box, Hydrostatic Drive, and Drivelines

### CONTENTS

Section	Description	Page
	Introduction .....	2
	Orientation .....	2
	Splitter Box .....	2
	Hydrostatic Drive Description .....	2
	Specifications .....	3
	Torque Specifications .....	5
	Special Tools .....	7
	Safety .....	10
	Power Flow .....	12
	Description of Operation .....	13
	Splitter Box Description .....	13
	Splitter Box Gear Sets .....	14
	Hydrostatic and Hydraulic System Components .....	16
	Hydrostatic Drive Description .....	18
	Moving a Disabled Tractor .....	31
	Troubleshooting and Testing .....	37
	Pressure Testing .....	44
	Range Select Control Switch and Valve .....	51
	Overhaul .....	62
	Removal and Installation .....	62
	Introduction .....	62
	Splitter Box .....	62
	Auxiliary Pump .....	62
	Disassembly, Inspection, and Repair .....	65
	Auxiliary Drive Housing .....	69
	Auxiliary 3/4" Couplers .....	79
	Articulation Joint Drive Shafts .....	86
	Upper Drive Shaft .....	86
	Engine Power Input Shaft .....	91
	Lower Drive Shaft .....	94
	Splitter Box Power Input (Top) Shaft .....	98
	Splitter Box Power Output (Bottom) Shaft .....	101
	Engine-end Axle Drive Shaft .....	103
	Splitter Box .....	107
	Tapered Bearing End Play Check and Adjustment .....	116
	Hydrostatic Motor .....	125
	Hydrostatic Pump .....	133
	FNR Lever Cables .....	139
	Repair Time Schedule .....	151

---

# SECTION 25 - ENGINE-END AXLE

BOOK 2 - 86705317

## Chapter 1 - Engine-End Axle

### CONTENTS

Section	Description	Page
	Specification .....	3
	Axle Shaft Preload .....	3
	Axle Shaft Spacer Selection Table .....	3
	Differential Bearing Preload .....	3
	Differential Bearing Shim Table .....	3
	Drive Pinion Preload .....	4
	Drive Pinion Spacer Table .....	4
	Tightening Torques .....	5
	Special Tools .....	6
	Introduction .....	7
	Drive Path .....	8
	Drive Pinion .....	9
	Differential .....	11
	Planetary Assembly .....	12
	Axle Shaft and Trumpet Housing .....	13
	Differential Lock .....	14
	Troubleshooting .....	22
	Disassembly and Repair .....	27
	Trumpet/Axle Disassembly .....	28
	Planetary Disassembly .....	31
	Planetary Inspection .....	32
	Planetary Reassembly .....	32
	Planetary Ring Gear Removal .....	33
	Planetary Ring Gear Installation .....	34
	Trumpet/Axle Inspection .....	34
	Trumpet/Axle Reassembly .....	36
	Pinion Gear Removal .....	42
	Pinion Gear Disassembly .....	44
	Pinion Gear Inspection .....	46
	Center Housing Inspection .....	46
	Pinion Gear Reassembly .....	47
	Pinion Bearing Preload .....	48
	Drive Pinion Spacer Table .....	49
	Pinion Gear Installation .....	50
	Differential Disassembly .....	51

---

## SECTION 25 - ENGINE-END AXLE (CONTINUED)

BOOK 2 - 86705317

### Chapter 1 - Engine-End Axle

Section	Description	Page
	Differential Inspection .....	54
	Differential Reassembly .....	55
	Differential Bearing Preload .....	59
	Differential Bearing Shim Table .....	60
	Differential Lock Internal Operating Components Overhaul .....	61
	Differential Lock Valve and Tube Removal .....	62
	Differential Lock Valve and Tube Inspection .....	62
	Differential Lock Valve and Tube Installation .....	63
	Oscillating Components .....	63
	Rear Trunnion Inspection .....	66
	Rear Trunnion Installation .....	67
	Front Trunnion Removal .....	69
	Front Trunnion Inspection .....	71
	Front Trunnion Installation .....	72
	Diff Lock Switch Removal .....	74
	Diff Lock Switch Inspection .....	75
	Diff Lock Switch Installation .....	76
	Apply Solenoid and Valve Removal .....	76
	Apply Solenoid and Valve Inspection .....	76
	Apply Solenoid and Valve Installation .....	76
	Breather Removal .....	77
	Breather Inspection .....	77
	Breather Installation .....	77
	Repair Time Schedule .....	78

---

## SECTION 27 - CAB-END AXLE

BOOK 2 - 86705317

### Chapter 1 - Cab-End Axle

#### CONTENTS

Section	Description	Page
27 000	Specifications .....	2
	Torque Specifications .....	2
	Special Tools .....	4
	Introduction .....	5
	Overview .....	5
	Description of Operation .....	6
	Troubleshooting .....	19
	Overhaul .....	24
	Repair Time Schedule .....	105

## SECTION 31 - POWER TAKE-OFF

BOOK 3 - 86705318

### Chapter 1 - Cab-End PTO

#### CONTENTS

Section	Description	Page
	Specifications .....	2
	Special Tools .....	3
	Description of Operation .....	4
	Cab-End PTO Clutch Control Valve Operation .....	5
	Cab-End Output Drive .....	8
	Electrical Operation .....	10
	Cab-End PTO Electrical Circuit .....	10
	Troubleshooting .....	14
	Disassembly and Repair .....	16
	Preliminary Procedures .....	16
	Cab-End PTO Clutch .....	17
	Cab-End PTO Shafts and Gears .....	35
	PTO Switch .....	51
	Repair Time Schedule .....	53



---

# SECTION 31 - POWER TAKE-OFF

BOOK 3 - 86705318

## Chapter 2 - Engine-End PTO

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Specifications .....	2
	Special Tools .....	2
	Description of Operation .....	3
	Electrical Operation .....	4
	Engine-End PTO Electrical Circuit .....	4
	Engine-End Output Drive .....	8
	Clutch and Brake Pressure Apply .....	10
	Lubrication Flow .....	13
	Breather Lines .....	15
	Troubleshooting .....	17
	Testing PTO Gearbox Drain Pump Flow .....	19
	Disassembly and Repair .....	22
	Preliminary Procedures .....	22
	Engine-End PTO Gearbox Overhaul .....	22
	PTO Transfer Shaft and Coupler .....	76
	Clutch Pressure Apply Hose .....	82
	Lube Motor .....	86
	Lube Circuit Hose .....	89
	Breather and Hose .....	99
	Apply Solenoid and Valve .....	107
	Brake .....	111
	PTO Switch .....	115
	Repair Time Schedule .....	117

---

# SECTION 33 - BRAKES

BOOK 3 - 86705318

## Chapter 1 - Brakes

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Specifications .....	2
	Special Tools .....	3
	Introduction .....	4
	Overview .....	4
	Description of Operation .....	5
	Troubleshooting and Testing .....	15
	Adjustments .....	19
	Removal and Installation of Components .....	25
	Brake Disc Components .....	25
	Foot Pedal Linkage .....	37
	Master Cylinder .....	42
	Reservoir .....	50
	Hose - Reservoir To Master Cylinder .....	52
	Tubes - Pressure Supply .....	54
	Park Brake Lever .....	56
	Park Brake Cables and Links .....	59
	Brake Pedal Switch .....	65
	Park Brake Switch .....	66
	Repair Time Schedule .....	68

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 86705319

## Chapter 1 - Hydraulics and Steering

### CONTENTS

Section	Description	Page
	Specifications .....	2
	Special Tools .....	8
	Description and Operation .....	10
	Auxiliary Hydraulics .....	10
	Component Identification .....	11
	Hydraulic Circuits .....	15
	Description of Operation .....	36
	Steering Control Valve .....	65
	Troubleshooting and Testing .....	83
	Disassembly and Repair .....	129
	Implement Pump .....	130
	Implement Valve .....	146
	Priority (Inlet) Valve Section .....	150
	Tan (Float) Valve Section .....	152
	Blue (Detent) Valve Section .....	162
	Green (Standard) Valve Section .....	172
	Implement Valve .....	177
	1/2" Couplers .....	180
	Implement Valve Control Linkage .....	185
	Control Lever Cable .....	186
	Control Pedal Assembly .....	195
	Control Pedal Cable .....	196
	Steering Control Valve .....	201
	In Cab Flow Control Cables .....	230
	Hydraulic System Hoses .....	233
	3/4" Couplers .....	299
	Hydraulic Oil Heater .....	306
	Engine End Remote Valves .....	309
	Hydraulic Oil Cooler .....	322
	Hydraulic Oil Cooler By-pass .....	327
	Repair Time Schedule .....	336

---

# SECTION 35- HYDRAULIC SYSTEMS

BOOK 5 - 86705320

## Chapter 2 - Cab-End Hitch

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Specifications .....	2
	Special Tools .....	3
	Description of Operation .....	4
	Three-Point Hitch Electrical Control Components .....	7
	Three-Point Hitch Electrical Control System .....	10
	Neutral – Manual Mode .....	14
	Raise – Manual Mode .....	17
	Lower – Manual Mode .....	20
	Raise – Manual Mode – Fender Switches .....	23
	Lower – Manual Mode – Fender Switches .....	26
	Neutral – Automatic Mode .....	29
	Raise – Automatic Mode .....	32
	Lower – Automatic Mode .....	35
	Raise – Automatic Mode – Fender Switches .....	38
	Lower – Automatic Mode – Fender Switches .....	39
	Float – Automatic Mode .....	40
	Float Position Control – Automatic Mode .....	43
	Hydraulic Lift Assembly Control Valve .....	46
	Troubleshooting .....	50
	Three-Point Hitch Controller Fault Codes .....	51
	Electrical .....	52
	Hydraulics .....	75
	Adjustments .....	79
	Calibration Mode .....	79
	Upper Limit Operating Set Point Adjustment .....	83
	Removal and Repair of Components .....	86
	Raise/Lower Switches .....	86
	Automatic/Manual Switch .....	88
	Status Light .....	90
	Depth Control Potentiometer .....	92
	Lowering Rate Potentiometer .....	94
	External Three-Point Hitch Controls .....	96
	Feedback Potentiometer .....	98
	Hydraulic Lift Cover .....	99
	Lift Cylinder .....	112
	Cross Shaft .....	118
	Control Valve .....	122
	Upper Lift Link .....	128
	Lower Lift Link Stabilizer Assembly .....	131
	Lower Lift Link .....	134
	Lift Assist Ram .....	137
	Flexible Link Ends .....	142
	Link Assembly .....	143
	Repair Time Schedule .....	148

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 5 - 86705320

## Chapter 3 - Engine-End Hitch

### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Three-Point Hitch Electrical Control Components .....	5
	Three-Point Hitch Electrical Control System .....	8
	Manual Mode .....	11
	Automatic Mode .....	20
	Hydraulic Lift Assembly Control Valve .....	35
	Special Tools .....	39
	Specifications .....	40
	Troubleshooting .....	41
	Electrical .....	43
	Hydraulics .....	66
	Adjustments .....	70
	Calibration Mode .....	70
	Upper Limit Operating Set Point Adjustment .....	74
	Removal and Repair of Components .....	77
	Status Light .....	81
	Depth Control Potentiometer .....	83
	Lowering Rate Potentiometer .....	85
	Feedback Potentiometer .....	87
	Cross Shaft .....	91
	Control Valve .....	99
	Center Lift Link .....	109
	Stabilizer Assembly .....	111
	Lower Lift Link .....	114
	Hydraulic Cylinders .....	115
	Flexible Link Ends .....	121
	Lift Link Assembly .....	122
	Repair Time Schedule .....	125

---

## SECTION 37 - WHEELS, TIRES, AND BALLASTING

BOOK 6 - 86705321

### Chapter 1 - Wheels and Tires

#### CONTENTS

Section	Description	Page
	Introduction .....	2
	Proper Jacking .....	3
	Tire Inflation .....	4
	Tire and Wheel Options .....	5

## SECTION 37 - WHEELS, TIRES, AND BALLASTING

BOOK 6 - 86705321

### Chapter 2 - Ballasting

#### CONTENTS

Section	Description	Page
	Ballasting and Tires .....	2
	Wheel Slippage .....	3
	Ballast Limitations .....	3
	Ballasting Recommendations .....	3
	Cast Iron Weights .....	4
	Liquid Ballast Calculations .....	5

---

# SECTION 39 - FRAMES

BOOK 6 - 86705321

## Chapter 1 - Frames

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Specifications .....	2
	Torques .....	3
	Special Tools .....	5
	Description of Operation .....	5
	Introduction .....	5
	Troubleshooting .....	6
	Overhaul .....	7
	Engine Hood .....	7
	Hood Support Assembly .....	10
	Side Panels, Right-hand and Left-hand .....	14
	Front Grille .....	16
	Cab-end Fenders .....	18
	Left-hand and Right-hand .....	18
	Engine-end Fenders .....	18
	Left-hand and Right-hand .....	18
	Heatshield .....	22
	Engine End Drawbar .....	28
	Cab End Drawbar .....	33
	Front Axle Support .....	34
	Frame Side Rails .....	38
	Steering Pins .....	42
	Pivot Pins .....	43
	Front Frame .....	51
	Rear Frame .....	60
	Repair Time Schedule .....	62

---

# SECTION 50 - CLIMATE CONTROL

BOOK 6 - 86705321

## Chapter 1 - Climate Control

### CONTENTS

Section	Description	Page
	Specifications .....	2
	Special Tools .....	2
	Description and Operation .....	3
	R134a Refrigerant Information .....	3
	The Basics of Refrigeration .....	6
	Individual Component Operation .....	9
	Compressor and Clutch .....	9
	Condenser .....	13
	Receiver-drier .....	15
	Thermal Expansion Valve .....	18
	Evaporator/Heater Assembly .....	22
	Blower Motor Assembly .....	23
	Thermostatic Switch .....	25
	High and Low Pressure Switches .....	28
	Heater Control Valve .....	29
	Switched Power: Fuses and HVAC Relay .....	31
	Air Filtration .....	32
	Troubleshooting and Testing .....	33
	General Safety and Service Precautions .....	33
	Recovering R134a Refrigerant With OEM1598 .....	36
	System Evacuation and Recharging With OEM1598 .....	40
	Oil Level Check Or Adjustment .....	45
	Leak Detection .....	49
	Performance Testing .....	58
	Pressure/Temperature Relationship Chart .....	58
	Conditions For Performance Testing .....	58
	Gauge Readings and Interpretations .....	59
	Performance Test and Diagnosis Summary .....	71
	General Troubleshooting Summary .....	74
	Heating System .....	74
	Air Conditioning System .....	74
	Air-conditioning Component Removal and Installation .....	83
	Thermal Expansion Valve .....	91
	Evaporator/Heater Assembly .....	93
	Condenser .....	97
	High and Low Pressure Switches .....	99
	Compressor .....	100
	Compressor Clutch .....	102
	Receiver-drier .....	109
	Air Conditioning Hoses .....	110
	Heater Control Valve .....	116
	Recirculation Door Control .....	120
	Blower Speed Control .....	123
	Heater Hoses .....	124
	Repair Time Schedule .....	128



---

# SECTION 55 - ELECTRICAL SYSTEM

BOOK 7 - 86705322

## Chapter 1 - Electrical System

### CONTENT

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Specifications .....	2
	Fuse and Relay Panel .....	6
	Torque Specifications .....	12
	Special Tools .....	12
	Introduction .....	13
	Electrical System .....	14
	Using Schematics .....	36
	Circuit Troubleshooting .....	40
	Temporary Wiring Harness Repair .....	43
	Description of Operation .....	46
	Batteries .....	46
	Starting and Charging Systems .....	47
	Starter .....	253
	Batteries Troubleshooting .....	254
	Starter Troubleshooting .....	279
	EICS Error Codes .....	286
	EICS Connector Chart .....	292
	Alarms .....	303
	Three-Point Hitch Controller .....	316

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)