

4386 and 4586 Tractors

Operators Manual

1084586R2

Reprinted

CASE III



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
2. MAKE SURE THE OPERATOR READS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS MACHINE.



IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.

BEFORE STARTING THE ENGINE, DO THE FOLLOWING:

1. READ THE OPERATOR'S MANUAL.
2. READ ALL SAFETY DECALS ON THE MACHINE.
3. CLEAR THE AREA OF OTHER PERSONS.

LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

To The Owner

Before you operate the tractor study this manual carefully. It has been prepared to help you operate and maintain your tractor with utmost efficiency.



This symbol is used to call your attention to instructions concerning your personal safety. Be sure to observe and follow these instructions.

Assembled in this manual are operation, lubrication, and maintenance instructions for the International 4386 and 4586 Articulated Tractors. This material has been prepared in detail in the hope that it will help you to better understand the correct care and efficient operation of your tractor.

For prompt, efficient service, always specify the tractor model and serial numbers, including prefix and suffix letters. Write these serial numbers in the spaces provided under "Serial Numbers".

The International 4386 and 4586 four-wheel drive tractors are designed to distribute the tractor weight on the four driving wheels during operation, and thus provide better floatation and less soil compaction. Also, the four driving wheels, with proper load distribution, will enable the tractor to achieve higher drawbar pull and drawbar power than a two-wheel drive tractor with equivalent power.

To achieve the most efficient operation of a four-wheel drive tractor, nearly equal weight and traction should be maintained between the front and rear wheels. Implement loads transfer weight from the front to the rear wheels. Excessive weight transfer, particularly with hitch mounted implements, can upset this equal weight distribution and nullify the four-wheel drive concept. Also, if weight transfer is excessive, the rear axle can transmit full engine power which would result in damage to the axle.

To avoid this possibility, gauge wheels should be used on heavy tillage equipment and the tractor should not be operated at gear settings below third gear for continuous operation. If continuous operation cannot be maintained in third gear or above, the implement load should be reduced by operating at a shallower depth or by reducing implement width. The three-point hitch control valve should be positioned in the "Float" settings whenever possible for heavy tillage.

Your local International Harvester dealer is interested in the performance you receive from these tractors. He has factory-trained servicemen, informed in the latest method of servicing tractors, modern tools, and original-equipment IH service parts which assure proper fit and good performance.

To obtain top performance and assure economical operation the tractor should be inspected, depending on its use, periodically, or at least once a year by your International Harvester Dealer.



Universal symbols are used to pictorially identify various tractor instruments and controls. Throughout this manual, an identifying symbol is placed by the instructions like this example for engine coolant temperature. The waves signify water or coolant and the thermometer indicates temperature. Regardless of the language used in a nation, and without translation, this symbol means water or coolant temperature.

Optional equipment and accessories are available. Disregard the instructions for equipment not on your tractor.

METRIC (SI) MEASUREMENTS

A standard of metric measurement known as International System of Units (SI) has been adopted for world-wide use. English Units followed by Metric Equivalents are used throughout this manual. (Metric Equivalents are given in parenthesis)


CONTENTS

TO THE OWNER	Inside	COOLING SYSTEM	24, 25, 26
	Front	Checking the Coolant Level	24
	Cover	Draining and Filling the	
		Cooling System	24
SERIAL NUMBERS	3, 4	Hoses and Clamps	25
		Cleaning the Cooling System	25
WORK SAFELY – FOLLOW		Thermostat	25
THESE RULES	6, 7	Cleaning the Radiator, Transmission	
Servicing and Before Starting	6	Oil Cooler and Condenser Core Fins	25
Starting	6	Cooling System Filter Conditioner	25
During Operation	6	Water Pump, Alternator-Generator,	
Transporting	7	and Fan Belt Tension	26
Tractors with Cabs	7		
Before Dismounting	7	AIR CLEANING SYSTEM	27, 28
After an Upset	7	Removing and Cleaning the	
		Primary Filter Element	27
INSTRUMENTS AND CONTROLS	8, 9	Inspection	28
Instrument Panel, Cab Interior		Secondary Filter Element	28
and Controls	8	Automatic Dust Unloader	28
Seat Controls	9		
Swivel Seat Controls	9	ELECTRICAL SYSTEM	29 to 32
		Charging System for	
BEFORE OPERATING YOUR TRACTOR	9	Alternator-Generator	29
		Cranking System	29
OPERATING THE TRACTOR	10 to 15	Lighting System	29
Neutral Starting Switch	10	Turn Signal Indicators	30
Starting the Engine	10	Combination Turn Signals and	
Stopping the Engine	11	Warning Lights	30
With the Engine Running	11	Headlight Switch	30
Steering the Tractor	13	Auxiliary Work Light Switch	30
Starting the Tractor	13	Tellites	31
Clutch	13	Fuses	31
Clutch Adjustment	14	Batteries	31
Stopping the Tractor	14		
Selecting Ground Speeds	14	HYDRAULIC CONTROLS	33
Park Brake	14		
Frame Lock Pin	15	THREE-POINT HITCH	34, 35, 36
Towing the Tractor	15	Lift Links and Leveling Screws	34
Tractor Break-In Procedure	15	Hitch Lower Links	34
		Hitch Upper Link	34
CAB INTERIOR AND CONTROLS	16, 17, 18	Lateral Limiter	34
Operating the Controls	16	Rigid Hitch Position	35
Control Settings	17	Free to Float Position	35
Radio Units	17	Coupling the Equipment	35
Seat	17	Uncoupling the Equipment	36
ENGINE AND FUEL SYSTEM	19 to 23	HITCHING TRAILING EQUIPMENT	
Warranty Notice	21	TO THE TRACTOR	36
Fuel System	21		
Fuel Injection Pump and Nozzles	22		
Priming the Turbocharger	22		
Changing the Ether Fluid Container	23		

CONTENTS


<p>AUXILIARY VALVES, REMOTE CYLINDERS, AND HYDRAULIC OUTLETS 37, 38, 39</p> <p style="padding-left: 20px;">Connecting Hoses to the Rear Hydraulic Outlets 37</p> <p style="padding-left: 20px;">Operating Double-Acting Cylinders 38</p> <p style="padding-left: 20px;">Operating Single-Acting Cylinders 38</p> <p style="padding-left: 20px;">Adding Fluid After Connecting Cylinders and Hoses 38</p> <p style="padding-left: 20px;">Freeing the System of Trapped Air 39</p> <p>WHEELS 40, 41, 42</p> <p style="padding-left: 20px;">Adjusting the Tread Widths 40</p> <p style="padding-left: 20px;">Tread Widths 40</p> <p style="padding-left: 20px;">Wedge Hubs 41</p> <p style="padding-left: 20px;">Dual Wheels 42</p> <p>TIRES 42, 43</p> <p style="padding-left: 20px;">Inflation 42</p> <p style="padding-left: 20px;">Load Capacity 43</p> <p>BALLASTING THE TRACTOR 44</p> <p>COLD WEATHER PRECAUTIONS 44</p> <p style="padding-left: 20px;">Fuel System 44</p> <p style="padding-left: 20px;">Electrical 44</p> <p style="padding-left: 20px;">Lubrication 44</p> <p style="padding-left: 20px;">Cooling System 44</p> <p>STORING THE TRACTOR 45</p> <p style="padding-left: 20px;">Storage 45</p> <p style="padding-left: 20px;">Removing from Storage 45</p> <p>LUBRICATION 46, 47</p> <p style="padding-left: 20px;">Engine Oil 46</p> <p style="padding-left: 20px;">Gear Lubricant 46</p> <p style="padding-left: 20px;">Lubrication Fitting Grease 46</p> <p style="padding-left: 20px;">Engine Oil Filter 47</p> <p style="padding-left: 20px;">Hydraulic Fluid Filter 47</p> <p>LUBRICATION TABLE 48</p> <p>LUBRICATION GUIDE 49 to 52</p> <p>PREVENTIVE MAINTENANCE GUIDE 53, 54, 55</p>	<p>CAB EQUIPMENT PREVENTIVE MAINTENANCE 56 to 59</p> <p style="padding-left: 20px;">Cab Air Filters 56</p> <p style="padding-left: 20px;">Air Conditioner Condenser 57</p> <p style="padding-left: 20px;">Refrigerant Sight Glass 57</p> <p style="padding-left: 20px;">Refrigeration System Pressures 57</p> <p style="padding-left: 20px;">Evaporator Drain Valves 57</p> <p style="padding-left: 20px;">Adjusting the Compressor Belt Tension 58</p> <p style="padding-left: 20px;">Compressor Pulley and Clutch 58</p> <p style="padding-left: 20px;">Compressor Oil Level 58</p> <p style="padding-left: 20px;">Compressor Shaft Seal 59</p> <p style="padding-left: 20px;">Heater Coolant Shut-Off 59</p> <p style="padding-left: 20px;">Electrical 59</p> <p style="padding-left: 20px;">Miscellaneous 59</p> <p>SPECIFICATIONS 60, 61, 62</p> <p>OPTIONAL EQUIPMENT 63</p> <p>METRIC (SI) MEASUREMENTS Inside Back Cover</p>
--	--

SERIAL NUMBERS



1 - Diesel engine serial number


DTI-466 _____




1 - Diesel engine serial number

V-800 _____


The engine serial number is stamped on pad located on crankcase "V" rear and also on the left side valve cover.



1 - 4386 Tractor transfer case serial number




1 - 4586 Tractor transfer case serial number




1 - Cab model and serial number

2 - Tractor serial number


SERIAL NUMBERS




1 - 4386 Tractor transmission serial number



1 - 4586 Tractor speed transmission serial number



1 - Front axle serial number




1 - Rear axle serial number



MA-11874

1-Front 2-Right 3-Rear 4-Left

Terms of location for 4386 tractor.



MA-11875

1-Front 2-Right 3-Rear 4-Left

Terms of location for 4586 tractor.

Buy Now



Our support email:

ebooklibonline@outlook.com