

1000 Powershift Series Bearcat & Cougar

Operators Manual

37-151

Reprinted

CASE



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
2. MAKE SURE THE OPERATOR READS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS MACHINE.



IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.

BEFORE STARTING THE ENGINE, DO THE FOLLOWING:

1. READ THE OPERATOR'S MANUAL.
2. READ ALL SAFETY DECALS ON THE MACHINE.
3. CLEAR THE AREA OF OTHER PERSONS.

LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

STEIGER TRACTOR, INC. BEARCAT AND COUGAR 1000 WARRANTY

Steiger Tractor, Inc (Steiger) warrants to an authorized Steiger dealer and the Steiger dealer, in turn, warrants to the original purchaser each new tractor covered by this manual to be free of defect in material or workmanship, subject to the following provisions.

WARRANTY PERIOD

Tractor Warranty	The base warranty period starts on the date the tractor is delivered to the original purchaser and extends for a period of twelve (12) months.
Extended Drivetrain Warranty	The extended drivetrain warranty starts at end of base warranty period and ends twenty four (24) months, or 2000 hours, whichever occurs first from the date of delivery to the original purchaser. Applies to transmission, transfer case, drivelines and axle assemblies (engine excluded).
Caterpillar Engine Warranty	Caterpillar engine warranty starts on the date the tractor is delivered to the original purchaser and extends for a period of twenty four (24) months (administered by Steiger in U.S. and Canada).
Steiger Service Parts Warranty	Steiger service parts and remanufactured parts purchased from an authorized Steiger dealer are warranted to be free of defect in material or workmanship for a period of 90 days, starting from the date of purchase or for the balance of the Steiger equipment's warranty period, whichever is greater.
Caterpillar Service Parts	Caterpillar service parts and remanufactured parts purchased from a Caterpillar dealer and used on Steiger equipment are warranted to be free of defect in material or workmanship for a period of 180 days, starting from the date of purchase or the balance of the Steiger equipment's warranty period, whichever is greater.

WARRANTY REGISTRATION

Warranty will become valid only when a warranty registration form for the tractor has been properly completed and received by Steiger.

SECURING WARRANTY REPAIR

Warranty repair can be performed by any Steiger dealer authorized to sell and/or service the tractor involved. When securing warranty repair, preference should be given to the dealer from which the tractor was purchased.

STEIGER RESPONSIBILITIES

If a defect is found in material or workmanship during the warranty period, Steiger will, through a Steiger dealer:

- Repair the defective parts or provide new or remanufactured parts.
- Pay reasonable labor cost when warranty is performed during normal working hours at dealer's place of business. (Labor expense is not paid under Steiger and Caterpillar service parts warranty).

PURCHASER RESPONSIBILITIES

- Transport tractor to dealer's place of business or pay the cost of dealer service calls and/or transportation charges associated with the warranty repair.
- Premium or overtime labor cost requested by purchaser.
- Cost of normal maintenance and normal replacement of service items such as oil, filters, belts etc.
- Give timely notice of a warrantable repair within the warranty period and promptly make the tractor available for repair.
- Cost of removal and replacement of modifications not authorized by Steiger.
- Provide evidence of date of delivery of tractor or purchase date of service parts, whichever is applicable when securing warranty service.

LIMITATIONS

Warranty Does Not Cover:

- Cummins engines, Caterpillar engines (other than in U.S. and Canada) or tires and tubes. These components are covered by the respective manufacturer's warranty, if any.
- Failures resulting from misadjustment, abuse, lack of lubrication, improper maintenance, normal wear, accident or improper use.
- Failures resulting from modifications of the tractor in ways not approved by Steiger.
- Attachments, accessory items and parts not sold by Steiger.
- Repairs required due to purchaser's unreasonable delay in making tractor available after notice for product improvements ordered by Steiger.
- Warrantable repair cost, when such repairs are performed by other than authorized Steiger dealer.

TO THE EXTENT ALLOWED BY LAW THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED AND THERE IS NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT WILL STEIGER, ITS EMPLOYEES, ITS DEALERS OR ANY COMPANY AFFILIATED WITH STEIGER BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OR INJURIES, INCLUDING, BUT NOT LIMITED TO: LOSS OF CROPS, LOSS OF PROFITS, RENTAL OF EQUIPMENT, LOSS OF USE OR OTHER ECONOMIC LOSSES.

STEIGER TRACTOR INC.
P.O. BOX 6006, FARGO, NORTH DAKOTA 58108

**Bearcat/Cougar 1000 Series
PREDELIVERY CHECK**

THIS FORM MUST BE FILLED OUT BY THE DEALER AND SIGNED BY THE CUSTOMER WHEN THE 200 HOUR CHECK IS PERFORMED IN ORDER FOR THE WARRANTY TO BE VALID.

OWNER NAME			DEALER NAME		
ADDRESS			ADDRESS		
CITY	COUNTY	STATE	CITY	COUNTY	STATE
TELEPHONE NO.		ZIP CODE	DEALER I.D.		ZIP CODE
MACHINE		MODEL NAME	HOURS		
MODEL NO.		TRACTOR S/N	DATE		
ENGINE MODEL		ENGINE S/N	NOTE: Record Serial Numbers Directly From Tractor		

Check and Adjust as Required.

INOPERATIVE SERVICE CHECKS

- Engine Oil Level.
- Engine coolant level.
- Check all fuel and hydraulic line routings and tightness.
- Brake master cylinder full.
- Hydraulic oil level full.
- Transmission oil sump full.
- Differential oil levels.
- Wheel hub oil levels.
- Grease all lube points as required.
- Air cleaner filters and hose connections (in position and tight).
- Engine air and exhaust stack.
- Tire pressures.
- Battery cables tight and clean.
- Cab air filter (in position).
- All belt tensions.
- Engine mount bolts.
- All driveshaft flange and U-joint bolts torqued.
- Wheel lug bolts torqued.
- Dual bolts torqued.
- Hinge pins tightened.
- Check all electrical cables and wire routings keeping away from sharp edges, moving parts and exhaust heat.
- Cab seat adjustments and operation.
- Cab interior upholstery, trim, mouldings and general appearance.
- Cab mount bolts torqued.
- Door latches and lock operation.
- Cab and door glass seals.

- Steering column adjusts.
- Radio working.
- All lights and switches working.
- Paint.
- All decals and shields on and correct.
- Hitch pin (supplied).
- Operator's manual in cab.
- Record all serial numbers on back cover of Operator's manual.

OPERATIONAL SERVICE CHECKS

All Operative Checks are to be performed with the tractor at normal operating temperatures.

- Engine oil pressure normal.
- Engine temperature normal.
- Engine low idle .(Record.)
- Engine high idle .(Record.)
- Throttle and linkage.
- All instruments and gauges operational.
- Starting and Starter Neutral Switch operation
- Steering functions smoothly.
- Air conditioner and heater operation.
- Hydraulic control valves working.
- Windshield wiper/washer operational.
- Fluid and oil leaks.

PERFORMANCE CHECK

- Transmission operation.
- Brake operation.
- Engine operation including throttle and governor operation.
- All optional equipment and accessories.
- Steering Operation.

OPTIONS

Check as required.

THREE-POINT

- Lubricate and adjust as required.
- Fluid leaks.

PTO SYSTEM

- Check master shield operation.
- PTO shaft guard on.
- PTO control and operation.
- Check for fluid leaks.

Technician's Signature: _____

Dealer Comments _____

Owner's Signature _____ Date _____

Dealer Copy

STEIGER TRACTOR INC.
P.O. BOX 6006, FARGO, NORTH DAKOTA 58108

**Bearcat/Cougar 1000 Series
PREDELIVERY CHECK**

THIS FORM MUST BE FILLED OUT BY THE DEALER AND SIGNED BY THE CUSTOMER WHEN THE PREDELIVERY CHECK IS PERFORMED IN ORDER FOR THE WARRANTY TO BE VALID.

OWNER NAME			DEALER NAME		
ADDRESS			ADDRESS		
CITY	COUNTY	STATE	CITY	COUNTY	STATE
TELEPHONE NO.		ZIP CODE	DEALER I.D.		ZIP CODE
MACHINE		MODEL NAME	HOURS		
MODEL NO.		TRACTOR S/N	DATE		
ENGINE MODEL		ENGINE S/N	NOTE: Record Serial Numbers Directly From Tractor		

**Check and Adjust as Required.
INOPERATIVE SERVICE CHECKS**

- Engine Oil Level.
- Engine coolant level.
- Check all fuel and hydraulic line routings and tightness.
- Brake master cylinder full.
- Hydraulic oil level full.
- Transmission oil sump full.
- Differential oil levels.
- Wheel hub oil levels.
- Grease all lube points as required.
- Air cleaner filters and hose connections (in position and tight).
- Engine air and exhaust stack.
- Tire pressures.
- Battery cables tight and clean.
- Cab air filter (in position).
- All belt tensions.
- Engine mount bolts.
- All driveshaft flange and U-joint bolts torqued.
- Wheel lug bolts torqued.
- Dual bolts torqued.
- Hinge pins tightened.
- Check all electrical cables and wire routings keeping away from sharp edges, moving parts and exhaust heat.
- Cab seat adjustments and operation.
- Cab interior upholstery, trim, mouldings and general appearance.
- Cab mount bolts torqued.
- Door latches and lock operation.
- Cab and door glass seals.

- Steering column adjusts.
- Radio working.
- All lights and switches working.
- Paint.
- All decals and shields on and correct.
- Hitch pin (supplied).
- Operator's manual in cab.
- Record all serial numbers on back cover of Operator's manual.

OPERATIONAL SERVICE CHECKS
All Operative Checks are to be performed with the tractor at normal operating temperatures.

- Engine oil pressure normal.
- Engine temperature normal.
- Engine low idle .(Record.)
- Engine high idle .(Record.)
- Throttle and linkage.
- All instruments and gauges operational.
- Starting and Starter Neutral Switch operation
- Steering functions smoothly.
- Air conditioner and heater operation.
- Hydraulic control valves working.
- Windshield wiper/washer operational.
- Fluid and oil leaks.

PERFORMANCE CHECK

- Transmission operation.
- Brake operation.
- Engine operation including throttle and governor operation.
- All optional equipment and accessories.
- Steering Operation.

OPTIONS

Check as required.

THREE-POINT

- Lubricate and adjust as required.
- Fluid leaks.

PTO SYSTEM

- Check master shield operation.
- PTO shaft guard on.
- PTO control and operation.
- Check for fluid leaks.

Technician's Signature: _____

Dealer Comments _____

Owner's Signature _____ **Date** _____

STEIGER TRACTOR INC.
P.O. BOX 6006, FARGO, NORTH DAKOTA 58108

Bearcat/Cougar 1000 Series
200 HOUR CHECK

THIS FORM MUST BE FILLED OUT BY THE DEALER AND SIGNED BY THE CUSTOMER WHEN THE 200 HOUR CHECK IS PERFORMED IN ORDER FOR THE WARRANTY TO BE VALID.

OWNER NAME			DEALER NAME		
ADDRESS			ADDRESS		
CITY	COUNTY	STATE	CITY	COUNTY	STATE
TELEPHONE NO.		ZIP CODE	DEALER I.D.		ZIP CODE
MACHINE		MODEL NAME	HOURS		
MODEL NO.		TRACTOR S/N	DATE		
ENGINE MODEL		ENGINE S/N	NOTE: Record Serial Numbers Directly From Tractor		

Check and Adjust as Required.
INOPERATIVE SERVICE CHECKS

- Engine Oil Level.
- Engine coolant level.
- Check all fuel and hydraulic line routings and tightness.
- Brake master cylinder full.
- Hydraulic oil level full.
- Transmission oil sump full.
- Differential oil levels.
- Wheel hub oil levels.
- Grease all lube points as required.
- Air cleaner filters and hose connections (in position and tight).
- Engine air and exhaust stack.
- Tire pressures.
- Battery cables tight and clean.
- Cab air filter (in position).
- All belt tensions.
- Engine mount bolts.
- All driveshaft flange and U-joint bolts torqued.
- Wheel lug bolts torqued.
- Dual bolts torqued.
- Hinge pins tightened.
- Check all electrical cables and wire routings keeping away from sharp edges, moving parts and exhaust heat.
- Cab seat adjustments and operation.
- Cab interior upholstery, trim, mouldings and general appearance.
- Cab mount bolts torqued.
- Door latches and lock operation.
- Cab and door glass seals.

- Steering column adjusts.
- Radio working.
- All lights and switches working.
- Paint.
- All decals and shields on and correct.
- Hitch pin (supplied).
- Operator's manual in cab.
- Record all serial numbers on back cover of Operator's manual.

OPERATIONAL SERVICE CHECKS
All Operative Checks are to be performed with the tractor at normal operating temperatures.

- Engine oil pressure normal.
- Engine temperature normal.
- Engine low idle (Record.)
- Engine high idle (Record.)
- Throttle and linkage.
- All instruments and gauges operational.
- Starting and Starter Neutral Switch operation
- Steering functions smoothly.
- Air conditioner and heater operation.
- Hydraulic control valves working.
- Windshield wiper/washer operational.
- Fluid and oil leaks.

PERFORMANCE CHECK

- Transmission operation.
- Brake operation.
- Engine operation including throttle and governor operation.
- All optional equipment and accessories.
- Steering Operation.

OPTIONS

Check as required.

THREE-POINT

- Lubricate and adjust as required.
- Fluid leaks.

PTO SYSTEM

- Check master shield operation.
- PTO shaft guard on.
- PTO control and operation.
- Check for fluid leaks.

Technician's Signature: _____

Dealer Comments _____

Owner's Signature _____ **Date** _____

Dealer Copy

STEIGER TRACTOR INC.
P.O. BOX 6006, FARGO, NORTH DAKOTA 58108

Bearcat/Cougar 1000 Series
200 HOUR CHECK

THIS FORM MUST BE FILLED OUT BY THE DEALER AND SIGNED BY THE CUSTOMER WHEN THE 200 HOUR CHECK IS PERFORMED IN ORDER FOR THE WARRANTY TO BE VALID.

OWNER NAME			DEALER NAME		
ADDRESS			ADDRESS		
CITY	COUNTY	STATE	CITY	COUNTY	STATE
TELEPHONE NO.		ZIP CODE	DEALER I.D.		ZIP CODE
MACHINE		MODEL NAME	HOURS		
MODEL NO.		TRACTOR S/N	DATE		
ENGINE MODEL		ENGINE S/N	NOTE: Record Serial Numbers Directly From Tractor		

Check and Adjust as Required.
INOPERATIVE SERVICE CHECKS

- Engine Oil Level.
- Engine coolant level.
- Check all fuel and hydraulic line routings and tightness.
- Brake master cylinder full.
- Hydraulic oil level full.
- Transmission oil sump full.
- Differential oil levels.
- Wheel hub oil levels.
- Grease all lube points as required.
- Air cleaner filters and hose connections (in position and tight).
- Engine air and exhaust stack.
- Tire pressures.
- Battery cables tight and clean.
- Cab air filter (in position).
- All belt tensions.
- Engine mount bolts.
- All driveshaft flange and U-joint bolts torqued.
- Wheel lug bolts torqued.
- Dual bolts torqued.
- Hinge pins tightened.
- Check all electrical cables and wire routings keeping away from sharp edges, moving parts and exhaust heat.
- Cab seat adjustments and operation.
- Cab interior upholstery, trim, mouldings and general appearance.
- Cab mount bolts torqued.
- Door latches and lock operation.
- Cab and door glass seals.

- Steering column adjusts.
- Radio working.
- All lights and switches working.
- Paint.
- All decals and shields on and correct.
- Hitch pin (supplied).
- Operator's manual in cab.
- Record all serial numbers on back cover of Operator's manual.

OPERATIONAL SERVICE CHECKS
All Operative Checks are to be performed with the tractor at normal operating temperatures.

- Engine oil pressure normal.
- Engine temperature normal.
- Engine low idle .(Record.)
- Engine high idle .(Record.)
- Throttle and linkage.
- All instruments and gauges operational.
- Starting and Starter Neutral Switch operation
- Steering functions smoothly.
- Air conditioner and heater operation.
- Hydraulic control valves working.
- Windshield wiper/washer operational.
- Fluid and oil leaks.

PERFORMANCE CHECK

- Transmission operation.
- Brake operation.
- Engine operation including throttle and governor operation.
- All optional equipment and accessories.
- Steering Operation.

OPTIONS

Check as required.

THREE-POINT

- Lubricate and adjust as required.
- Fluid leaks.

PTO SYSTEM

- Check master shield operation.
- PTO shaft guard on.
- PTO control and operation.
- Check for fluid leaks.

Technician's Signature: _____

Dealer Comments _____

Owner's Signature _____ **Date** _____

Buy Now



Our support email:

ebooklibonline@outlook.com