

ORIGINAL INSTRUCTIONS - according to Directive 2006/42/EC, Annex I 1.7.4.1

PUMA 185 CVX
PUMA 200 CVX
PUMA 220 CVX
PUMA 240 CVX
Stage IV
Tractor

OPERATOR'S MANUAL

Part number 47960368

2nd edition English

September 2016

Replaces part number 47584355



Contents

1 GENERAL INFORMATION

Metric and imperial units abbreviations.....	1-1
To the owner.....	1-3
Operator's manual storage.....	1-5
Product identification.....	1-6
Engine identification.....	1-7
Drive line identification.....	1-8
Cab identification.....	1-8
Product identification plate.....	1-8
Ecology and the environment.....	1-9
Noise level information sheet.....	1-10
Programming tractor functions.....	1-10
Before operating the tractor.....	1-11
International symbols.....	1-12
Vibration level information sheet.....	1-13
Machine stability.....	1-14
Selective Catalytic Reduction (SCR) system.....	1-18

2 SAFETY INFORMATION

Safety precautions.....	2-1
Safety decals.....	2-3
Safety rules.....	2-11
Burn prevention.....	2-17
Prevention of fire or explosions.....	2-18
Fire extinguisher.....	2-19
Protection offered by the tractor.....	2-20
Hazardous substances.....	2-23
Emergency exit.....	2-24
Wheel chocks.....	2-25
Intended use statement.....	2-26
Passenger's seat.....	2-28
Safety aspects.....	2-29

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Introduction.....	3-1
Cab air filters.....	3-5
In cab storage (where fitted).....	3-6
Cable and wiring routing.....	3-7
Mobile telephone usage.....	3-7
Implement monitor installation.....	3-8
Cab air pressurisation control (where fitted).....	3-9

OPERATOR'S SEAT

Operator's seat.....	3-10
----------------------	------

Air suspension seat with passive or Dynamic Damping System (DDS).....	3-11
Air suspension seat 'evolution active'	3-17
Seat belt	3-23

PASSENGER'S SEAT

Passenger seat.....	3-24
---------------------	------

FORWARD CONTROLS

Ignition key	3-25
Hazard lights switch	3-25
Lights and turn indicator lever	3-26
Windshield wiper and washer controls	3-27
Electronic parking brake.....	3-28
Anti-lock braking system ABS Operation	3-32
Clutch pedal	3-40
Foot brakes.....	3-40
Exhaust brake (where fitted)	3-41
Steering column	3-42

LEFT-HAND SIDE CONTROLS

Handbrake.....	3-43
----------------	------

RIGHT-HAND SIDE CONTROLS

Integrated control panel	3-44
Multi function handle	3-45

REARWARD CONTROLS

Switches on C-pillar	3-46
Hydraulic master switch	3-47
Heated screens (where fitted).....	3-48
Autoguidance system (where fitted).....	3-49
ISO bus functionality	3-49
Battery isolator switch (where fitted)	3-50
Climate controls	3-51
Manual temperature control	3-52
Automatic Temperature Control (ATC)	3-53

OVERHEAD CONTROLS

Switch panel work lights.....	3-55
Left-hand and right-hand outermost work light switch.....	3-56
Interior light.....	3-57

INSTRUMENT CLUSTER

Integrated control unit	3-58
Gauges	3-58
Indicator and warning lights	3-59
Displays	3-62

Keypad basic	3-63
Keypad enhanced	3-64
Selecting or changing the display settings	3-66
Adjust menu	3-67
Configure menu	3-71
Performance monitor	3-74
Armrest color display	3-82
Pop-up screens on color display	3-83
Performance monitor on color display	3-88
Programming the displays	3-93
Alarm functions	3-96
Accessing stored error codes	3-98
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-99
Warning and advisory symbols	3-108
Warning and advisory symbols	3-122

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Refueling the tractor	4-1
-----------------------------	-----

STARTING THE UNIT

Starting the engine	4-3
Grid heater cold start aid (where fitted)	4-5
Fuel heater (where fitted)	4-5
Coolant immersion heater (where fitted)	4-6
Transmission oil heater (where fitted)	4-7
Boosting the battery	4-8

STOPPING THE UNIT

Stopping the engine	4-9
Automatic engine shut down	4-9
Automatic engine shut down with enhanced keypad (where fitted)	4-10

MOVING THE UNIT

Operating in cold temperatures	4-11
Low idle speed management	4-14
Reversible engine fan	4-15

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Carrying the tractor on a transporter	5-1
Secure the high visibility roof panel	5-1

RECOVERY TRANSPORT

Freeing a stuck tractor	5-2
-------------------------------	-----

Towing the tractor.....	5-3
-------------------------	-----

6 WORKING OPERATIONS

GENERAL INFORMATION

Variable engine power management	6-1
Constant engine speed	6-3
Differential lock	6-6
Four wheel drive.....	6-8
Front axle suspension (where fitted)	6-10
Automated headland functions	6-12
Headland turn sequence - Quick guide.....	6-12
Recording and replaying	6-14
Explanation of symbols.....	6-17
Recording a sequence	6-19
Replaying a sequence.....	6-21
Headland function and color display screen.....	6-25
Deleting a sequence with color display.....	6-28
Automated headland functions	6-29
Headland turn sequence	6-29
Universal Symbols.....	6-30
Recording a sequence	6-31
Replaying a sequence.....	6-35
Saving a sequence	6-38
Edit a sequence	6-41
Recalling a sequence.....	6-45
Deleting a sequence.....	6-49

TRANSMISSION

CVT transmission operation.....	6-52
Transmission operation.....	6-52
Anti jack knife.....	6-53
Stationary control	6-54
Engine speed control	6-55
Shuttle lever	6-57
Transmission controls	6-59
Drive pedal	6-62
Programming maximum speed.....	6-63
Transmission display	6-65
Manual mode	6-66
Automatic mode	6-66
Speed matching	6-67
Fault codes	6-67

REAR POWER TAKE-OFF (PTO)

Power Take-Off (PTO) operating precautions	6-68
Changing the PTO output shaft	6-69
Attaching PTO driven equipment.....	6-70
PTO operation	6-71
PTO shiftable multi speed	6-75

Electronic PTO displays Electronic (where fitted)	6-77
External PTO controls	6-78
Auto PTO operation	6-80

FRONT POWER TAKE OFF

PTO operation	6-83
Auto PTO operation	6-85

REAR HITCH

Electronic Draft Control (EDC)	6-87
Settings and adjustments.....	6-91
Electronic Draft Control (EDC) operation.....	6-93
External hitch controls	6-99

FRONT HITCH

Settings and adjustments.....	6-101
Front hitch operation	6-104
Auxiliary front couplers (where fitted).....	6-110
External hitch controls	6-112
Front hitch management	6-113

HYDRAULIC REMOTE CONTROL VALVES

Remote control valves.....	6-119
Operating with remote valves	6-121
Connecting remote cylinders	6-124

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

Remote control valves.....	6-125
Settings and adjustments.....	6-132
Valve priority.....	6-138
Programming tractor functions	6-140
Connecting remote cylinders	6-147
Operating with remote valves	6-149
Joystick operation with a front loader.....	6-151
Mid mount remote valves.....	6-158
External EHR controls	6-160
EHR implement control setting	6-161
Transmission rear axle and hydraulic system oil level	6-165

HYDRAULIC POWER BEYOND PORT

Power beyond circuit	6-167
Power beyond valve - Static description	6-167
ISO Power beyond couplings.....	6-169

THREE POINT HITCH

Attaching three-point hitch equipment.....	6-170
--	-------

Lift rod adjustment.....	6-172
Top link adjustment.....	6-174
Lower links	6-176
Quick hitch.....	6-177
Lower links	6-179

DRAWBARS AND TOWING ATTACHMENTS

Drawbars and towing attachments	6-183
Swinging drawbar	6-185
Automatic pickup hitch	6-188
Automatic pickup hitch	6-192
Rear trailer hitches	6-196

TRAILER BRAKING SYSTEMS

Air-operated trailer brakes.....	6-203
Air-operated trailer brakes (Italian type)	6-206
Trailer brake bias control	6-207
Trailer brakes air operated	6-207
Hydraulic trailer brakes	6-208
Hydraulic trailer brakes (Italian type)	6-209

WHEEL TRACK ADJUSTMENT

Front wheel track adjustment.....	6-210
Front wheel alignment	6-215
Steering stops	6-216
Front axle oscillation stops	6-217
Front wheel fenders	6-218
Rear wheel track adjustment	6-220
Flange type axle (where fitted)	6-220
Bar type axle (where fitted).....	6-224
Dual rear wheels (where fitted).....	6-231

BALLASTING AND TIRES

Ballasting and tires	6-234
Iron weights (where fitted).....	6-237
Liquid ballast	6-240
Tire inflation.....	6-242
Tire pressures and permissible loads	6-243

AUXILIARY POWER CONNECTIONS

Diagnostic socket.....	6-245
Trailer electrical socket	6-246
Electrical power connectors	6-247
Internal power connectors.....	6-247
External power connectors	6-249
ISO bus classes	6-251
ISO bus functionality	6-253

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Fuel requirement - Diesel fuel	7-2
Fuel - Storage, handling and transport	7-2
Biodiesel fuel	7-3
Engine oil change	7-5
Protective devices	7-6
Tractor jacking points	7-8
Lubricants and coolants	7-9
General specifications	7-10
Capacities	7-11
Organic Acid Technology (OAT) coolant	7-12

MAINTENANCE CHART

Maintenance chart	7-13
-------------------------	------

WHEN THE WARNING LAMP LIGHTS

Engine air cleaner	7-15
Fuel system water separator	7-16
Check the brake fluid level	7-17

EVERY 10 HOURS OR EACH DAY

Coolant level check	7-18
Engine oil level	7-19
Remote valve collection bottle	7-19
Windscreen wash wipe	7-20
Air reservoir	7-20

FIRST 50 HOURS

Service operations	7-21
--------------------------	------

EVERY 50 HOURS

Cab air filters	7-22
Selective Catalytic Reduction (SCR) system	7-24
Clean the coolers	7-25
Grease fittings	7-26
Check the front and the rear wheel nuts	7-33
Tire inflation pressures	7-33

EVERY 100 HOURS

Drive belts - check	7-34
Drive belts - check	7-35

EVERY 300 HOURS

Battery fluid level	7-36
Transmission oil level	7-38
Handbrake	7-39

Front PTO oil level.....	7-39
Front axle oil - Four-Wheel Drive (4WD)	7-40

EVERY 600 HOURS

Change engine oil and filter	7-41
Change the first stage fuel filter and the fuel filter element.....	7-43
Engine air precleaner.....	7-45
Hydraulic return and charge pump filters.....	7-46
Check the air intake system	7-47
Transmission	7-48
DEF/AdBlue® in-line filter	7-48

EVERY 1200 HOURS OR ANNUALLY

Cab air filters	7-49
Change the hydraulic suction pump oil filter.....	7-50
Differential and planetary oil.....	7-51
Front hubs - 4WD.....	7-52
Front PTO change oil.....	7-52
Grease the rear axle shaft bearing	7-53

EVERY 1200 HOURS OR EVERY 2 YEARS

DEF/AdBlue® filter	7-54
Change the engine air cleaner inner element	7-55
Engine tappet valve clearance	7-56
Air-operated trailer brakes.....	7-56
Poly (V) belts change.....	7-57
Change transmission oil.....	7-59

EVERY 2 YEARS

Change the air conditioning receiver drier.....	7-60
---	------

EVERY 1800 HOURS OR EVERY 2 YEARS

Engine - breather filter replacement.....	7-61
---	------

EVERY 3600 HOURS OR EVERY 2 YEARS

DEF/AdBlue® filter	7-61
--------------------------	------

EVERY 3600 HOURS OR EVERY 4 YEARS

Change the engine coolant fluid.....	7-62
--------------------------------------	------

GENERAL MAINTENANCE

Cleaning the tractor.....	7-66
Fuel system water separator	7-68
Bleeding the fuel system	7-68
Hydraulic system hoses	7-69
Brake Pedal	7-69

Cab suspension, if equipped	7-70
Adjust the automatic pickup hitch	7-71
Headlight adjustment	7-72
Work light adjustment	7-72
Bulb replacement	7-73
Fuses and relays	7-76
Protecting the electronic and electrical systems during battery charging or welding ..	7-84
Battery - replacement.....	7-85

STORAGE

Tractor storage	7-86
Removing the machine from storage.....	7-86

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Introduction	8-1
--------------------	-----

ALARM(S)

Fault codes and symbols	8-2
-------------------------------	-----

SYMPTOM(S)

Engine	8-4
Transmission	8-5
Hydraulics	8-6
Three-point hitch	8-6
Brakes	8-7
Cab	8-7
Electrical system	8-8

9 SPECIFICATIONS

General dimensions	9-1
Frame - General specification	9-1
Capacities	9-4
Transmission - Capacity	9-4
Front axle system - Capacity	9-4
Engine	9-5
Transmission	9-6
Rear Power Take-Off (PTO)	9-7
Front Power Take-Off (PTO).....	9-8
Hydraulic system	9-9
Three-point hitch	9-11
Remote control valves	9-11
Three-point hitch	9-11
Brakes	9-12
Steering.....	9-12
Electrical equipment.....	9-13
Minimum hardware tightening torques	9-14

10 ACCESSORIES

Radio (where fitted).....	10-1
External rear view mirrors	10-1
Auxiliary headlights	10-3
Rotating beacon	10-3
Front-end loader fixation points	10-4

11 FORMS AND DECLARATIONS

CE Declaration of conformity	11-1
Service record 1st 50 hour, Owner copy	11-3
Service record 1st 50 hour, Dealer copy	11-5

1 - GENERAL INFORMATION

Metric and imperial units abbreviations

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	ha	acre	ac
	square meter	m ²	square foot	ft ²
			square inch	in ²
	square millimeter	mm ²	square inch	in ²
Electricity				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	μF	microfarad	μF
	ohm	Ω	ohm	Ω
Force				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
Force per length				
	newton per meter	N/m	pound per foot	lb/ft
			pound per inch	lb/in
Frequency				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
Frequency - Rotational				
	revolution per minute	r/min	revolution per minute	r/min ^a
		rpm		rpm
Length				
	kilometer	km	mile	mi
	meter	m	foot	ft
	centimeter	cm	inch	in
	millimeter	mm	inch	in
	micrometer	μm		
Mass				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
Mass per mass				
	milligram per kilogram	mg/ kg	parts per million	ppm
Power				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour	Btu/hr
			Btu per minute	Btu/min
Pressure or stress (Force per area)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH ₂ O
	megapascal	MPa	pound per square inch	psi
	millibar	mbar		
	bar	bar		

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
Torque (includes bending moment, moment of force, and moment of a couple)				
	newton meter	N m	pound foot	lb ft
			pound foot	lb in
Velocity				
	kilometer per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimeter per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
Volume (includes capacity)				
	cubic meter	m ³	cubic yard	yd ³
				cu yd
	liter	l	cubic inch	in ³
	liter	l	US gallon	US gal
			UK gallon	UK gal
			US quart	US qt
			UK quart	UK qt
	milliliter	ml	fluid ounce	fl oz
Volume per time (includes discharge and flow rate)				
	cubic meter per minute	m ³ /min	cubic foot per minute	ft ³ /min
	liter per minute	l/min	US gallon per minute	US gal/min
	milliliter per minute	ml/min	UK gallon per minute	UK gal/min
Sound power level and sound pressure level				
	decibel	dB	decibel	dB
Water hardness				
	German hardness	°dH	English hardness	°e
	French hardness	°fH	parts per million	ppm

Glossary

Acronym	Definition
DEF	Diesel Exhaust Fluid
ISO	International Organization for Standardization
MSDS	Material Safety Data Sheet
NOx	Nitrogen Oxide
PPE	Personal Protective Equipment
SCR	Selective Catalytic Reduction
ULSD	Ultra Low Sulfur Diesel
%	Percent
<	Less than
>	Greater than

Buy Now



Our support email:

ebooklibonline@outlook.com