

ORIGINAL INSTRUCTIONS

OPERATOR'S MANUAL

Workmaster™ 55

Workmaster™ 65

Workmaster™ 75

Tractor

Part number 51590514

1st edition English

February 2019

Replaces part number 51561945



Contents

1 GENERAL INFORMATION

Note to the Owner	1-1
Foreword	1-2
Note to the Owner	1-3
Advice	1-5
Advice	1-7
Product identification	1-8
Product identification TRACTOR IDENTIFICATION INFORMATION	1-10
Advice IMPORTANT INFORMATION ABOUT ENVIRONMENTAL SCIENCE	1-13

2 SAFETY INFORMATION

Safety rules TRACTOR JACK POINTS	2-1
Safety rules PREVENTING FIRE AND EXPLOSION	2-2
Personal safety GETTING IN AND OUT OF THE TRACTOR	2-3
Note to the Owner TRACTOR USE	2-4
Noise level	2-5
Vibration level DANGERS ASSOCIATED WITH EXPOSURE TO VIBRATION	2-6
Dimension TRACTOR BALANCE	2-7
Dimension FIXED PARAMETERS	2-9
Basic instructions SAFETY COVERS AND PROTECTORS	2-11
Safety signs SAFETY LABELS	2-13
International symbols	2-22

3 CONTROLS AND INSTRUMENTS

Access to operator's platform

Cab controls - Localization overview GENERAL INFORMATION, CONTROLLER AND INDICATORS	3-1
---	-----

Operator's seat

Seat function controller - Control identification DRIVER'S SEAT and SEAT ADJUSTMENT	3-1
Operator seat - Adjust	3-3
Pneumatically-adjusted operator seat - Adjust	3-4
Seat restraints - Localization overview	3-6

Instructional seat

Instructional seat - Localization overview	3-7
--	-----

Forward controls

Cab interior - Localization overview Instrument Console Controls	3-8
Instrument cluster - Localization overview	3-9
Multi-Function Handle (MFH) - Control	3-12
Ignition switch - Control identification	3-13
Hazard light switch - Control identification	3-14
Power Take-Off (PTO) - Control identification PTO Safety Button	3-15

Console Front console - Control identification FRONT CONSOLE CONTROLS 3-16

Left-hand side controls

Console Left-hand console - Control identification 3-17

Right-hand side controls

Console Right-hand console - Control identification 3-17

Overhead controls

Console Headliner console - Control identification 3-19

Air conditioning - Warning 3-22

Air conditioning - Operating 3-23

Exterior controls

Cab - Control identification 3-25

Cab - Control identification Cab step 3-26

Fuel tanks - Control identification 3-27

Fenders and guards - Control identification 3-28

Frame positioning folding - Control identification 3-28

Rear-view outside mirrors - Control identification 3-30

Shield - Control identification 3-31

Work light - Control identification 3-32

Display

Instrument cluster Analog-Digital Instrument Cluster (ADIC) - Program 3-34

Instrument cluster - Program 3-35

Instrument cluster - Program 3-37

Instrument cluster - Program 3-39

Instrument cluster - Program 3-40

Instrument cluster - Program 3-41

Instrument cluster - Program 3-43

Instrument cluster - Program 3-44

4 OPERATING INSTRUCTIONS

Starting the unit

Start-up - Product identification BATTERY CIRCUIT BREAKER 4-1

5 TRANSPORT OPERATIONS

Road transport

Brakes and controls - Tow TOWING THE TRACTOR 5-1

Brakes and controls - Tow TRANSPORTING A TRACTOR ON A CARRIER 5-2

6 WORKING OPERATIONS

General information

Safety rules	6-1
Turbocharger - Overview	6-4
Transmission - General specification TRANSMISSION SYSTEM (8 FORWARD + 8 REVERSE 30 km/h)	6-5
Transmission - General specification	6-10
Electro-hydraulic control - Operating	6-14
Differential lock control pedal - Operating REAR DIFFERENTIAL LOCK WITH MECHANICAL CONTROL	6-15
Power Take-Off (PTO) - Localization overview PTO	6-17
Power Take-Off (PTO) - Operating INDEPENDENT ENGINE-POWERED PTO	6-18
Power Take-Off (PTO) - Operating WHEEL-POWERED (SYNCHRONIZED) PTO ..	6-19
Power Take-Off (PTO) - Operating SERVO-ASSISTED PTO USE (OPTIONAL)	6-20
Power Take-Off (PTO) - Operating PTO SPEED	6-21
Power Take-Off (PTO) - Operating TRACTOR MOVING SPEEDS AT STANDARD ENGINE SPEEDS	6-22
Main lift system - Operating	6-28
Rear three-point hitch external controls - Overview THREE-POINT HITCH SYSTEM (CATEGORY 1 and 2)	6-33
Electrical systems - Overview TRAILER SOCKET	6-38
Auxiliary hydraulic valves and lines - General specification QUICK-CONNECTION HYDRAULIC POWER OUTPUTS WITH BUSHING CONNECTORS	6-39

Wheels and Tires

Wheels - Crop setting	6-41
Wheels - Crop setting FRONT WHEEL TRACK WIDTH ADJUSTMENT FOR MFD TRACTORS	6-43
Wheels - Crop setting WIDTH SETTINGS FOR REAR TIRE TRACK	6-44
Front axle system - Crop setting STEERING ANGLE ADJUSTMENT	6-45
Wheels - General specification TIRE USE, MAINTENANCE, AND REPLACEMENT	6-46
Wheels - General specification TIRE LOAD INDEX INFORMATION	6-47
Wheels - General specification SPEED CODES	6-48

TOWBAR

Rear three-point hitch - Operating	6-49
--	------

7 MAINTENANCE

General information

Maintenance - Consumables	7-1
---------------------------------	-----

Maintenance planning

Maintenance chart	7-1
-------------------------	-----

Flexible Maintenance

Radiator - Cleaning	7-4
Engine cooling system - Cleaning RADIATOR, INTERCOOLER, AND AIR-CONDITIONER GAS CONDENSER	7-5

Radiator - Level make up	7-6
Mechanical Front Drive (MFD)	7-7
Mechanical Front Drive (MFD) CHECKING THE COUPLING SLEEVE OF THE FRONT AXLE DRIVE SHAFT	7-7
Front light - Check	7-8
Wiper and washer system - Level make up	7-9
Clutch - Adjust	7-10
Brake pedals - Adjust	7-11
Hand brake lever - Adjust	7-12
Front wheels - Tighten	7-13
Power shuttle transmission hydraulic components - Check	7-14
Wheels - Tire inflating	7-15
Fan and drive - Adjust	7-16
Air conditioning - Check	7-17
Air conditioning - Cleaning	7-18
Radiator - Cleaning	7-19

WHEN THE WARNING LAMP LIGHTS

Air cleaners and lines - Replace	7-20
Air cleaners and lines - Cleaning	7-21
Air filter - Cleaning	7-22
Air cleaners and lines - Cleaning EXTERNAL CARTRIDGE OF DRY AIR FILTER ..	7-23
Brake fluid reservoir - Level make up	7-25

EVERY 10 HOURS OR EACH DAY

Engine lubrication system - Level make up	7-26
---	------

EVERY 50 HOURS

Hydraulic systems - Grease HYDRAULIC LIFTER CONNECTION ARMS	7-27
Mechanical Front Drive (MFD)	7-27
Front axle system - Grease FRONT AXLE REAR TRUNNION	7-27
Front axle system - Grease	7-28
Wheels - Grease DYNAMIC MUDGUARD	7-28
Front axle system - Grease	7-28
Front axle system - Grease	7-29
Front axle system - Grease	7-29
Front axle system - Grease	7-29
Fuel filters - Cleaning FUEL FILTER SEDIMENT BOWL	7-30

EVERY 100 HOURS

Air filter - Cleaning CAB AIR FILTER	7-31
--	------

EVERY 300 HOURS

Transmission - Level make up REAR TRANSMISSION AND HYDRAULIC LIFTER OIL LEVEL	7-32
Oil filters - Replace HYDRAULIC LIFTER OIL FILTER	7-33
Battery - Level make up	7-34

Air cleaners and lines - Cleaning EXTERNAL CARTRIDGE OF DRY AIR FILTER ..	7-35
Front wheels - Level make up	7-37
Front wheels - Grease.....	7-38
Front axle system - Grease FRONT AXLE LINKAGE	7-39
Front axle system - Grease.....	7-40
Fuel filters - Cleaning.....	7-41

EVERY 600 HOURS

Fuel filters - Replace	7-42
Engine oil filter - Replace.....	7-43
Pre-filter - Check	7-44

EVERY 1200 HOURS OR ANNUALLY

Air cleaners and lines - Replace.....	7-45
Cab air filters - Replace	7-46
Fuel tank - Cleaning	7-47
Fuel injectors - Adjust	7-48

EVERY 1200 HOURS OR EVERY 2 YEARS

Mechanical transmission hydraulic components - Replace Transmission — rear axle oil	7-49
Front axle system - Change fluid	7-50
Front axle system - Change fluid	7-51
Air conditioning - Replace	7-52
Fan and drive - Replace	7-53
Engine cooling system - Cleaning.....	7-54

GENERAL MAINTENANCE

Brakes and controls - Bleed	7-58
Headlight - Adjust.....	7-58

Fuse and relay locations

Battery - General specification	7-61
Fuse and relay box - General specification.....	7-63
Fuse and relay box - General specification.....	7-73

8 TROUBLESHOOTING

Fault code resolution

Frame - Troubleshooting ENGINE	8-1
Electrical system - Troubleshooting	8-3
Hydraulic systems - Troubleshooting.....	8-4
Rear three-point hitch - Troubleshooting	8-5
Hydraulic service brakes - Troubleshooting	8-6
Cab climate control - Troubleshooting.....	8-7

Symptom(s)

Instrument cluster - Part identification	8-8
--	-----

9 SPECIFICATIONS

General specification TECHNICAL SPECIFICATIONS	9-1
Accessories - Weight	9-3
Engine - General specification	9-4
Air cleaners and lines - General specification	9-4
Engine cooling system - General specification COOLING SYSTEM	9-4
Engine cooling system - General specification	9-4
Clutch - General specification DRIVE TRAIN	9-4
Transmission - General specification GEARS	9-5
Front axle system - General specification	9-5
Rear axle system - General specification	9-5
Power Take-Off (PTO) - General specification PTO	9-6
Hydraulic systems - General specification	9-6
Control valve - General specification	9-7
Steering - General specification	9-7
Brakes and controls - General specification BRAKING SYSTEM	9-7
Safety - General specification	9-7
Electrical systems - General specification	9-8
Electrical systems - General specification INDICATORS AND ADDITIONAL EQUIPMENT	9-8
Front loader and bucket - General specification	9-9

10 ACCESSORIES

Accessories - Overview Front Loader-Personal Safety	10-1
Accessories - Overview Front Loader-Personal Safety	10-2
Accessories - Operating Front Loader-Joystick	10-3
Accessories - Adjust Front Loader-Bucket Adjust	10-6
Accessories - Operating Front Loader	10-7
Accessories - Install BUCKET CONNECTION	10-11
Accessories - Lock/Unlock REMOVING THE FRONT LOADER	10-13
Accessories - Install BUCKET ATTACHMENT	10-15
Accessories - Lock/Unlock BUCKET REMOVAL	10-16
Accessories - Care BUCKET MAINTENANCE	10-18
Cab radio set - Operating	10-20

11 FORMS AND DECLARATIONS

Service record FIRST 50 HOURS MAINTENANCE FORM – CUSTOMER COPY	11-1
Service record FIRST 50 HOURS MAINTENANCE FORM – DEALERSHIP COPY	11-3

1 - GENERAL INFORMATION

Note to the Owner

This handbook contains information on how to calibrate and maintain your new equipment. You have purchased a reliable vehicle. However, you must maintain and use the vehicle appropriately for high performance and a long operational life. Make sure all operators read this manual carefully. Always have this manual to hand.

Your NEW HOLLAND dealership will provide instructions on the general use of your new equipment. Your seller's staff consists of factory-trained technicians. These technicians will answer any questions you have about the use of your machine.

Your NEW HOLLAND dealership will have a full range of genuine NEW HOLLAND service parts. These parts provide high-quality replacements and are designed specifically for your equipment. All replacement parts go through extensive quality control. You must provide the model and product identity number of your new equipment to your seller when you order parts. Record these numbers below. See the 'General Information' section of this handbook for information on where to find your machine's model information and product identity number.

PLEASE RECORD THE INFORMATION BELOW
Model:
Product Identity Number (PIN):



This is a safety warning symbol. This symbol warns you of potential risks of injury. It may appear with or without text. Adhere to the warnings that this symbol indicates to avoid the risk of injury or death.

<p>⚠ WARNING</p> <p>Illustrations in this manual may show protective shielding open or removed to better illustrate a particular feature or adjustment.</p> <p>Replace all shields before operating the machine.</p> <p>Failure to comply could result in death or serious injury.</p> <p style="text-align: right; font-size: small;">W0012A</p>

Notice on tampering with the engine:

NOTICE: *Your tractor's fuel system and engine are designed in accordance with statutory emissions standards. It is strictly prohibited by law for sellers, customers, operators, or users to tamper with the engine. A failure to follow this requirement may result in statutory fines, restitution fees, invalidation of warranty, legal action, and the potential seizure of the tractor. Only authorized technicians should carry out engine servicing and/or repair!*

Foreword

About this handbook

⚠ DANGER

Improper operation or service of this machine can result in an accident. Do not operate this machine or perform any lubrication, maintenance, or repair on it until you have read and understood the operation, lubrication, maintenance, and repair information. Failure to comply will result in death or serious injury.

D0010A

This handbook contains information on the normal operation and use of your tractor under routine servicing and maintenance. Please read this information. Keep it in good condition and store it in your seat's storage pocket for future reference. This handbook does not contain information about the periodic servicing, resetting, and repair procedures that professional service personnel will perform. The contents page(s) provide an overview of the main topics in the handbook. There is a detailed alphabetized index at the back of this handbook for easier access to certain topics.

Normal operation

- Normal operation refers to the use of the tractor and any mounted or pulled equipment for purposes that the tractor's manufacturer intended. Under normal operation, a knowledgeable operator should use the tractor in accordance with the manufacturer's operational and safety procedures in this handbook. The operator should also use the tractor in accordance with any labelling on equipment.
- Normal operation includes preparation and storage of the tractor, installation or removal of components/equipment, loading and unloading, and calibration of accessories.
- Normal operation also includes adjustment and preparation of the tractor and its equipment to the specific conditions of the field and/or crop.

Routine maintenance

Routine maintenance refers to the daily routine maintenance and safety procedures that an operator with knowledge of the tractor's specifications must carry out. The manufacturer has specified these maintenance and safety procedures in this handbook for the ongoing proper operation of the tractor. Labeling on the tractor also provides information on these maintenance and safety procedures. Routine maintenance includes refuelling, cleaning, washing, maintaining fluid levels, greasing, and replacing consumables such as lamp bulbs.

Resetting, periodic servicing, and repair

- Periodic servicing refers to the processes that trained personnel carry out to extend the operational life of the

tractor in accordance with periodic servicing and safety procedures. The manufacturer provides information on these periodic servicing and safety procedures in this handbook. There is also relevant information in other manufacturer literature.

- Resetting refers to the procedures that professional service staff perform to make the tractor comply with certain specifications. The resetting may use the information that the manufacturer provides in this manual and instructions. It may also use the information in other company literature.
- Repair refers to the repairs that trained personnel carry out in accordance with the repair information that the manufacturer has provided in the seller service handbook in case of a fault or decrease in performance.

Replacement parts

The manufacturer has not tested and does not allow the use of non-genuine parts. The use of these parts will negatively affect your tractor's operation and the safe use of your tractor. The manufacturer takes no responsibility for any damage as a result of the use of non-genuine parts. Do not make any changes to your tractor without the written permission of the manufacturer.

Warranty

Your tractor is under warranty in accordance with your country's laws and your contract with the dealer. In addition to this, if you do not comply with the use and maintenance rules and instructions in this manual, your guarantee becomes invalid.

Cleaning the tractor

Your tractor is equipped with an electro-hydraulic control system. Take care when you clean the tractor, especially if you use pressurized water. Never stand too close to the tractor. Never spray the pressurized water over electrical components, gaskets, grilles, etc. Never spray cold pressurised water on a hot engine or exhaust.

Note to the Owner

US Environmental Protection Agency (EPA) Warranty Statement

TURK TRAKTOR warrants to the ultimate purchaser and each subsequent purchaser that the new nonroad engine family, including all parts of its emission-control system, meets two conditions:

1. It is designed, built, and equipped so as to conform with US Environmental Protection Agency (EPA) regulations applicable at the time of manufacture.
2. It is free from defects in materials and workmanship that may keep it from meeting these regulations for a period of 3000 hours or 5 years, whichever comes first.

The emission related warranty is valid for 3000 hours or five years, whichever comes first.

NOTE: *This warranty applies to all units operated in the United States or Canada.*

Coverage

The model year, class of diesel engine, and emission application determination for your engine are identified on the Emission Control Information Label. This label is affixed to the right-hand side of the oil pan. The warranty period begins on the date the new equipment is sold to the first retail purchaser. The presence of the emission control label is the indication that the engine conforms to the applicable standards. Any emission control system parts which are proven defective during normal use will be repaired or replaced during the warranty period.

The engine owner has responsibility to perform all the required maintenance listed in the Owner's Manual. TURK TRAKTOR will not deny an emission warranty claim solely because no record of maintenance exists; however, a claim may be denied if failure to perform maintenance resulted in the failure of a warranted part.

It is recommended that replacement parts used for maintenance or repairs be TURK TRAKTOR Service Parts to maintain the quality originally designed into your emission certified engine. The use of non- TURK TRAKTOR parts does not invalidate the warranty on other components unless the use of such parts causes damage to warranted parts.

The manufacturer is liable for damages to other engine components caused by the failure of any warranted emission control system part. TURK TRAKTOR is not responsible for failures resulting from improper repair or the use of parts that are not genuine TURK TRAKTOR or TURK TRAKTOR approved parts.

Components:

New engines certified for sale and registered will have the following items covered by the emission warranty, depending on the emission level of the engine, if the items were first installed on the new engine as original equipment:

I. For exhaust emissions, emission-related components include any engine parts related to the following systems:

1. Air-induction system.
2. Fuel system.
3. Ignition system.
4. Exhaust gas recirculation systems.

II. The following parts are also considered emission-related components for exhaust emissions:

1. Aftertreatment devices.
2. Crankcase ventilation valves.
3. Sensors.
4. Electronic control units.

Emissions warranty does not cover

- Repairs arising from storage deterioration, failure to maintain the equipment, negligence, alteration, improper use of the equipment, collision or other accident, vandalism, or other casualty, or operation beyond rated capacity or specification.
- Repairs arising from abuse or neglect, including but not limited to: operation without adequate coolant or lubricants, adjustments to the fuel system outside equipment specifications, over-speeding, improper storage, starting, warm-up, or shutdown practices, incorrect fuel or contaminated fuel, oil or other fluids.
- Normal maintenance services, such as engine tune-ups, engine fuel system cleaning, checks, adjustments, shimming, etc.
- Items replaced due to customer demand.
- Labor charges performed by anyone except a dealer authorized by contract to repair the equipment, unless they qualify under special provisions (i.e. outside labor).
- Any and all travel costs for items such as towing, service calls, or transporting a unit to and from the place where the warranty service is performed.
- Normal maintenance costs, including but not limited to: lubricants, coolants, fluids, fuel, filters, and associated labor. Lubricants, filters, and coolants may qualify for warranty reimbursement if they require replacement as a DIRECT RESULT of a defect in material or workmanship.
- Claims involving the inspection or reconditioning of units after storage or prior use.
- Repairs arising from service performed by agents not approved by TURK TRAKTOR.
- Repairs arising from any unauthorized modification to the product or the use of non- TURK TRAKTOR parts, implements or attachments.
- Removal, replacement, or installation of non- TURK TRAKTOR optional equipment, attachments or components.
- Premiums charged for overtime labor costs or out of shop expenses.
- Economic loss including lost profits, crop loss, equipment rental, or other expense.
- Unauthorized modification or updating machines without a warrantable failure.
- Any and all costs of dealer shop supplies incurred with repairs, including but not limited to: solvents, cleaners, anti-seize lubricants, loctite, sealant, adhesive, oil-dry, shop towels, etc.
- Failure of the machine, its implements or attachments caused by improper field application or loading.
- Any and all costs for coolant, fuel, or lube (oil) analysis including supplies and lab recommendations.
- Cost associated with cleaning of machine in preparation for servicing.

1 - GENERAL INFORMATION

Advice

Class of 2006/42/EC Annex I	DE	CE	CA	EE	EL	EN	ES	ET	FI	FR	IT	LT	LV	NL	NO	PL	
	DECLARATION OF CONFORMITY Deklaracija ES o skladnosti strojev Določila 2006/42/EC	Prohlášení o shodě ES Prohlášení 2006/42/ES	EU-euroonnetusloendeklaratsioon Eiendoheldi deklaratsioon 2006/42/EF	EG-Konformitätserklärung Eiendoheldi Erklärung 2006/42/EG	Abkvietai Tapatvārģiba EK Eiendoheldi deklarācija 2006/42/EK	EC Declaration of conformity According to Directive 2006/42/EC	Declaración CE de conformidad de acuerdo con la Directiva 2006/42/CE	EU vastuvõtmekeskdeklaratsioon Vastuvõtmekeskdeklaratsioon 2006/42/EU	EY-vastuunotuslause Eiendoheldi vastuvõtmekeskdeklaratsioon 2006/42/EY	EC Conformity Declaration Eiendoheldi Erklārung 2006/42/EE	CE Conformiteitsverklaring Overeenkomstig de Richtlijn 2006/42/EG	CE Conformitate Declarație Conformitate Declarație 2006/42/CE	ES Atbilstības deklarācija Atbilstības deklarācija 2006/42/EB	EK Atbilstības deklarācija Atbilstības deklarācija 2006/42/EE	CE Conformiteitsverklaring Overeenkomstig de Richtlijn 2006/42/EG	CE Conformitate Declarație Conformitate Declarație 2006/42/CE	Declaracja zgodności zgodnie z dyrektywą 2006/42/WE
1.A.1	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	
1.A.2	Represented by Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	Representato da Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	Esindatud Giuseppe Gavio pool, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	edustajajamane Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	esindajate par Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	Represented by Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	representado por Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	Esindatud Giuseppe Gavio pool, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	edustajajamane Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	esindajate par Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	representado por Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	Esindatud Giuseppe Gavio pool, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	edustajajamane Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	esindajate par Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	representado por Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	Esindatud Giuseppe Gavio pool, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg	edustajajamane Giuseppe Gavio, CNH Europe Holding S.A., 13, Rue Aldringen, L-1118 Luxembourg
1.A.3	Declaration, with a non-renewable signature, on the responsibility of the signatory	Declaración, con una firma no renovable, sobre la responsabilidad del firmante	Kõikidele osadele, mis on tootja vastutuses	Kõikidele osadele, mis on tootja vastutuses	Kõikidele osadele, mis on tootja vastutuses	Declaration, with a non-renewable signature, on the responsibility of the signatory	Declaración, con una firma no renovable, sobre la responsabilidad del firmante	Kõikidele osadele, mis on tootja vastutuses	Kõikidele osadele, mis on tootja vastutuses	Kõikidele osadele, mis on tootja vastutuses	Declaration, with a non-renewable signature, on the responsibility of the signatory	Declaración, con una firma no renovable, sobre la responsabilidad del firmante	Kõikidele osadele, mis on tootja vastutuses	Kõikidele osadele, mis on tootja vastutuses	Kõikidele osadele, mis on tootja vastutuses	Declaration, with a non-renewable signature, on the responsibility of the signatory	Declaración, con una firma no renovable, sobre la responsabilidad del firmante
1.A.4	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	
1.A.7	ISO 30322-1 part 1 and 2	ISO 30322-1 parte 1 e 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 part 1 and 2	ISO 30322-1 parte 1 e 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 part 1 and 2	ISO 30322-1 parte 1 e 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 osa 1 ja 2	ISO 30322-1 part 1 and 2	ISO 30322-1 parte 1 e 2	
1.A.9	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	
1.A.10	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	Yes [1]	



CNH Industrial Europe Holding S.A.
Boulevard Royal, 24
L-2449, LUXEMBOURG
(Luxembourg)

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

See a sample EC Declaration of Conformity above (EC Declaration of Conformity 2006/42/EC). The EC Declaration of Conformity is the manufacturer's declaration of conformity of the equipment to the relevant EU regulations. Keep the original document in a safe place. Local authorities may ask to see this document for proof of equipment compliance. A translation of the declaration in your language is also included in the original document.

1 - GENERAL INFORMATION

So you can understand the document, the original text is on the following pages along with some explanatory notes.

2006/42/AT Appendix II Article	EN EC Declaration of Conformity according to Directive 2006/42/EC
1.A.1	We [1] ,
1.A.2	Represented by Antoon Vermeulen CNH Industrial Europe Holding S.A. Boulevard Royal, 24 L – 2449 Luxembourg
1.A.3	declare under our sole responsibility that the product: Agricultural tractor Trade name: [2] Model: [3] Type: [4] Serial number: [5]
1.A.4	to which this declaration relates, fulfills all the relevant provisions of the Directive 2006/42/EC, amended by [6].
1.A.7	For the relevant implementation of the provisions of the Directive, the following (harmonized) standards have been applied: • ISO 26322-1 part 1 or 2 Other standards: see User Manual
1.A.9	Place and date of the declaration: [7]
1.A.10	Name and signature of the authorized person: [8]

- CAB is certified Category 1 in accordance with EN 15695-1.
- NOISE EMISSION LEVELS are measured in accordance with 2009/76 /EC • 2009/63/EC directives.
- VIBRATION LEVELS are in the appropriate range in accordance with 78/764/EEC.
- ROPS PROTECTION is approved according to OECD Code 4 in our T1 category tractors, and according to OECD Code 6 in our T2 tractors.

Advice

This tractor complies with European Regulations on electromagnetic emissions. However, electromagnetic interference may occur as a result of additional equipment that does not meet the required standards. This type of interference may cause faults and/or unsafe situations. Please consider the following:

- Make sure that any equipment you mount to the tractor that is not manufactured by NEW HOLLAND carries the CE symbol.
- The maximum power of the emission-generating equipment (radio, telephone, etc.) must not exceed the limits set by the national authorities of the country in which you are using the tractor.
- The electromagnetic field introduced by auxiliary systems must not exceed **24 V/m** in any location near the electronic components at any time.

Failure to follow these rules will void the NEW HOLLAND warranty.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com