

PUMA I 30
PUMA I 45
PUMA I 60
Tractors

OPERATOR'S MANUAL

Part Number 84479523

1st edition English
January 2012



Contents

1 GENERAL INFORMATION

METRIC AND IMPERIAL UNITS ABBREVIATIONS	1-1
TO THE OWNER	1-3
PRODUCT IDENTIFICATION	1-5
ENGINE IDENTIFICATION	1-6
DRIVELINE IDENTIFICATION	1-7
CAB IDENTIFICATION	1-8
ECOLOGY AND THE ENVIRONMENT	1-9
PROGRAMMING TRACTOR FUNCTIONS	1-10
BEFORE OPERATING THE TRACTOR	1-11
INTERNATIONAL SYMBOLS	1-12
MACHINE STABILITY	1-13
INSTRUCTOR'S SEAT	1-17
SELECTIVE CATALYTIC REDUCTION (SCR) SYSTEM	1-18

2 SAFETY INFORMATION

SAFETY PRECAUTIONS	2-1
BEFORE DRIVING THE TRACTOR	2-2
DRIVING THE TRACTOR	2-3
OPERATING THE TRACTOR	2-4
OPERATING THE P.T.O.	2-6
OPERATING THE EXTERNAL CONTROLS	2-6
SERVICING THE TRACTOR	2-7
DIESEL FUEL	2-9
PREVENTION OF FIRE OR EXPLOSION	2-10
FIRE EXTINGUISHER	2-11
PROTECTION OFFERED BY THE TRACTOR	2-12
INTENDED USE STATEMENT	2-15
SAFETY DECALS	2-17

3 CONTROLS/INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

INTRODUCTION	3-1
CAB AIR FILTERS	3-5
IN CAB STORAGE (where fitted)	3-6
CABLE AND WIRING ROUTING	3-7
MOBILE TELEPHONE USAGE	3-7
IMPLEMENT MONITOR INSTALLATION	3-8
CAB AIR PRESSURISATION MONITOR (where fitted)	3-8

OPERATOR'S SEAT

AIR SUSPENSION SEAT DELUXE	3-10
SEAT BELT	3-15

INSTRUCTOR'S SEAT

INSTRUCTIONAL SEAT (where fitted)	3-16
---	------

FORWARD CONTROLS

KEY- START SWITCH	3-17
HAZARD WARNING LIGHT SWITCH.....	3-17
LIGHT-/ TURN LEVER	3-18
FOLLOW ME HOME LIGHTS.....	3-18
WINDSHIELD WIPER AND WASHER CONTROLS	3-19
ELECTRONIC PARK BRAKE	3-20
CLUTCH/ INCHING PEDAL.....	3-24
FOOT BRAKES	3-24
EXHAUST BRAKE (where fitted).....	3-25
STEERING COLUMN	3-26

LEFT-HAND SIDE CONTROLS

HANDBRAKE.....	3-27
----------------	------

RIGHT-HAND SIDE CONTROLS

INTEGRATED CONTROL PANEL	3-28
--------------------------------	------

REARWARD CONTROLS

SWITCHES ON C-PILLAR	3-29
HYDRAULIC MASTER SWITCH.....	3-30
HEATED SCREENS (where fitted).....	3-31
FAST STEERING SYSTEM (where fitted)	3-32
BATTERY ISOLATOR SWITCH.....	3-34
CLIMATE CONTROLS	3-35
MANUAL TEMPERATURE CONTROL	3-36
AUTOMATIC TEMPERATURE CONTROL (ATC).....	3-37

OVERHEAD CONTROLS

SWITCH PANEL WORKLIGHTS.....	3-39
INTERIOR LIGHT	3-40

INSTRUMENT CLUSTER

INTEGRATED CONTROL UNIT.....	3-41
GAUGES	3-41
INDICATOR AND WARNING LIGHTS	3-42
DISPLAYS.....	3-45
TRANSMISSION DISPLAY.....	3-46
KEYPAD BASIC	3-48
KEYPAD ENHANCED	3-49
SELECTING OR CHANGING THE DISPLAY SETTINGS	3-51
ADJUST MENU	3-52
CONFIGURE MENU	3-54
PERFORMANCE MONITOR.....	3-57
ARMREST COLOUR DISPLAY	3-62
POP- UP SCREENS ON COLOUR DISPLAY.....	3-64
PERFORMANCE MONITOR ON COLOUR DISPLAY	3-70
PROGRAMMING THE DISPLAYS	3-73
ALARM FUNCTIONS.....	3-76
ACCESSING STORED ERROR CODES	3-78
WARNING AND ADVISORY SYMBOLS	3-79

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

TRACTOR REFUELLING	4-1
--------------------------	-----

STARTING THE UNIT

STARTING THE ENGINE	4-3
GRID HEATER COLD START AID (where fitted)	4-4
FUEL HEATER (where fitted)	4-5
COOLANT IMMERSION HEATER (where fitted)	4-5
TRANSMISSION OIL HEATER (where fitted)	4-6
BOOSTING THE BATTERY	4-7

STOPPING THE UNIT

STOPPING THE ENGINE	4-8
AUTOMATIC ENGINE SHUTDOWN	4-8
AUTOMATIC ENGINE SHUTDOWN WITH ENHANCED KEYPAD (where fitted)	4-9

MOVING THE UNIT

OPERATING IN COLD TEMPERATURES	4-10
REVERSIBLE ENGINE FAN	4-11

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

CARRYING THE TRACTOR ON A TRANSPORTER	5-1
SECURE THE HIGH VISIBILITY ROOF PANEL	5-1

RECOVERY TRANSPORT

TOWING THE TRACTOR	5-2
--------------------------	-----

6 WORKING OPERATIONS

GENERAL INFORMATION

VARIABLE ENGINE POWER MANAGEMENT	6-1
CONSTANT ENGINE SPEED	6-3
DIFFERENTIAL LOCK	6-6
FOUR WHEEL DRIVE	6-8
FRONT AXLE SUSPENSION (where fitted)	6-10
AUTOMATED HEADLAND FUNCTIONS	6-11
QUICK GUIDE	6-11
EXPLANATION OF SYMBOLS	6-13
RECORDING AND RE-PLAYING	6-14
RECORDING A SEQUENCE	6-17
RE-PLAYING A SEQUENCE	6-19
HEADLAND FUNCTION AND COLOUR DISPLAY SCREENS	6-23
DELETING A SEQUENCE WITH COLOUR DISPLAY	6-26

TRANSMISSION

FOOT THROTTLE PEDAL	6-27
HAND THROTTLE	6-27
SHUTTLE LEVER	6-28
TRANSMISSION DISPLAY	6-30
ERROR CODES	6-32
SEMI POWERSHIFT TRANSMISSION	6-33
TRANSMISSION OPERATION	6-33
POWERSHIFT CONTROL LEVER	6-34
DRIVING THE TRACTOR	6-35
SPEED MATCHING	6-37
AUTO SHIFT FUNCTION	6-38
AUTO SHIFTING IN FIELD MODE	6-39
AUTO SHIFTING IN ROAD MODE	6-42
PROGRAMMING FORWARD AND REVERSE GEAR RATIOS	6-45
SETTING THE SHARP SHUTTLE FUNCTION	6-46
CREEPER GEARS (where fitted)	6-47
FULL POWERSHIFT TRANSMISSION	6-48
TRANSMISSION OPERATION	6-48
POWERSHIFT CONTROL LEVER	6-49
DRIVING THE TRACTOR	6-50
SPEED MATCHING	6-52
AUTO SHIFT FUNCTION	6-53
AUTO SHIFTING IN FIELD MODE	6-54
AUTO SHIFTING IN ROAD MODE	6-57
AUTO SHIFTING AND 'GO TO' MODES	6-60
PROGRAMMING FORWARD AND REVERSE GEAR RATIOS	6-62
CREEPER GEARS (where fitted)	6-63

REAR POWER TAKE-OFF

P.T.O. OPERATING PRECAUTIONS	6-64
CHANGING THE P.T.O. OUTPUT SHAFT	6-64
ATTACHING P.T.O. DRIVEN EQUIPMENT	6-65
P.T.O. OPERATION	6-66
TWO-SPEED P.T.O. SYSTEM	6-71
THREE-SPEED P.T.O. SYSTEM	6-73
GROUND DRIVE P.T.O. (where fitted)	6-74
EXTERNAL P.T.O. CONTROLS	6-75
AUTO P.T.O. OPERATION	6-77

FRONT POWER TAKE OFF

P.T.O. OPERATION	6-80
AUTO P.T.O. OPERATION	6-82

REAR HITCH

ELECTRONIC DRAFT CONTROL	6-84
SETTINGS AND DISPLAY	6-88
ELECTRONIC DRAFT CONTROL OPERATION	6-90
EXTERNAL HITCH CONTROLS	6-96

FRONT HITCH

SETTINGS AND ADJUSTMENTS	6-98
HITCH OPERATION	6-101

AUXILIARY FRONT COUPLERS (where fitted).....	6-106
EXTERNAL HITCH CONTROLS.....	6-108

HYDRAULIC REMOTE CONTROL VALVES

REMOTE CONTROL VALVES	6-109
OPERATING WITH REMOTE VALVES	6-112
CONNECTING REMOTE CYLINDERS	6-115
HYDRAULIC OIL LEVEL WHEN USING REMOTE HYDRAULIC EQUIPMENT	6-117

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

REMOTE CONTROL VALVES	6-119
SETTINGS AND ADJUSTMENTS	6-126
SETTING THE REMOTE VALVE PRIORITY.....	6-132
CREATING TIMER PROGRAMMES.....	6-134
CONNECTING REMOTE CYLINDERS	6-141
OPERATING WITH REMOTE VALVES	6-143
JOYSTICK OPERATION WITH A FRONT LOADER.....	6-145
MID MOUNT REMOTE VALVES	6-148
EXTERNAL EHR CONTROLS	6-150
HYDRAULIC OIL LEVEL WHEN USING REMOTE HYDRAULIC EQUIPMENT	6-151

HYDRAULIC POWER BEYOND PORT

HYDRAULIC POWER BEYOND FOR EXTERNAL SERVICES	6-153
--	-------

THREE POINT HITCH

ATTACHING THREE-POINT HITCH EQUIPMENT	6-156
LIFT ROD ADJUSTMENT	6-158
TOP LINK ADJUSTMENT	6-160
FLEXIBLE LINK END ADJUSTMENT	6-161
QUICK HITCH	6-162
LINKAGE STABILISER ADJUSTMENT	6-164

DRAWBARS AND TOWING ATTACHMENTS

DRAWBARS AND TOWING ATTACHMENTS	6-167
SWINGING DRAWBARS.....	6-170

TRAILER BRAKING SYSTEMS

AIR-OPERATED TRAILER BRAKES	6-173
TRAILER BRAKE BIAS CONTROL	6-176
AUXILIARY AIR SUPPLY CONNECTOR (where fitted).....	6-176
HYDRAULIC TRAILER BRAKES	6-177

WHEEL TRACK ADJUSTMENT

FRONT WHEEL TRACK ADJUSTMENT	6-178
FRONT WHEEL ALIGNMENT	6-181
STEERING STOPS	6-182
FRONT AXLE OSCILLATION STOPS	6-182
FRONT FENDER.....	6-183
REAR WHEEL TRACK ADJUSTMENT	6-185
FLANGE TYPE AXLE (where fitted)	6-185
BAR TYPE AXLE (where fitted)	6-188

DUAL REAR WHEELS (where fitted)	6-193
---------------------------------------	-------

BALLASTING AND TYRES

BALLASTING AND TYRES	6-196
IRON WEIGHTS (where fitted)	6-199
LIQUID BALLAST	6-202
TYRE INFLATION	6-204
TYRE PRESSURES AND PERMISSIBLE LOADS	6-205

AUXILIARY POWER CONNECTIONS

DIAGNOSTIC SOCKET	6-207
TRAILER SOCKET ELECTRICAL	6-207
ELECTRICAL POWER CONNECTORS	6-208
INTERNAL POWER CONNECTORS	6-208
EXTERNAL POWER CONNECTORS	6-210

7 MAINTENANCE

GENERAL INFORMATION

INTRODUCTION	7-1
FUEL REQUIREMENT	7-2
BIODIESEL FUEL - Biodiesel fuels	7-4
ENGINE OIL CHANGE	7-5
PROTECTIVE DEVICES	7-7
LUBRICANTS AND COOLANTS	7-9
TRACTOR JACKING POINTS	7-11
GENERAL SPECIFICATIONS	7-11
CAPACITIES	7-12

MAINTENANCE CHART

Maintenance Chart	7-13
-------------------------	------

WHEN THE WARNING LAMP LIGHTS

CHANGE ENGINE AIR CLEANER OUTER ELEMENT	7-15
DRAIN FUEL SYSTEM WATER SEPARATOR	7-16
CHECK BRAKE FLUID LEVEL	7-17

EVERY 10 HOURS OR EACH DAY

CHECK ENGINE COOLANT LEVEL	7-18
CHECK ENGINE OIL LEVEL	7-19
CHECK REMOTE CONTROL VALVE DRAIN BOTTLES	7-19
CHECK WINDSCREEN WASHER RESERVOIR	7-20
DRAIN AIR RESERVOIR ON AIR OPERATED TRAILER BRAKE	7-20

FIRST 50 HOURS

SERVICE OPERATIONS	7-21
--------------------------	------

EVERY 50 HOURS

CLEAN CAB AIR FILTER	7-23
----------------------------	------

CLEAN SCR COVER AIR DUCTS	7-24
CLEAN COOLER SECTION	7-25
ALL GREASE FITTINGS	7-26
CHECK FRONT AND REAR WHEEL NUTS.....	7-33
CHECK TYRE PRESSURES AND TYRE CONDITION.....	7-33

EVERY 100 HOURS

INSPECT POLY V-BELT	7-34
INSPECT COMPRESSOR DRIVE BELT.....	7-34

EVERY 300 HOURS

CHECK BATTERY FLUID LEVEL.....	7-35
ADJUST HANDBRAKE.....	7-36
CHECK TRANSMISSION/REAR AXLE AND HYDRAULIC OIL LEVEL	7-37
CHECK 4WD FRONT AXLE DIFFERENTIAL AND HUBS OIL LEVEL.....	7-38
CHECK FRONT P.T.O. GEARBOX OIL LEVEL	7-38

EVERY 600 HOURS

CHANGE ENGINE OIL AND FILTER	7-39
CHANGE FUEL PRE-FILTER AND FUEL FILTER ELEMENT.....	7-41
CHANGE ENGINE AIR CLEANER OUTER ELEMENT	7-42
CHANGE CHARGE PUMP OIL FILTER	7-43
CHECK ENGINE AIR INTAKE CONNECTIONS.....	7-44
CHECK TRANSMISSION OIL COOLER PIPE COUPLINGS	7-45
CLEAN DEF/ AdBlue INLINE FILTER.....	7-45

EVERY 1200 HOURS OR ANNUALLY

CHANGE CAB AIR FILTERS.....	7-46
CHANGE MAIN OIL FILTER CARTRIDGE.....	7-47
CHANGE TRANSMISSION/ REAR AXLE AND HYDRAULIC OIL.....	7-48
CHANGE 4WD DIFFERENTIAL OIL	7-49
CHANGE 4WD PLANETARY HUB OIL	7-50
CHANGE FRONT P.T.O. GEARBOX OIL	7-50
GREASE REAR AXLE SHAFT BEARING	7-51

EVERY 1200 HOURS OR EVERY 2 YEARS

CHECK BATTERY FLUID LEVEL.....	7-52
CHANGE DEF/ AdBlue INLINE FILTER.....	7-53
CHANGE ENGINE AIR CLEANER INNER ELEMENT.....	7-54
CHECK VALVE TAPPET CLEARANCE	7-55
CHANGE ENGINE COOLANT FLUID	7-56
CHANGE AIR BRAKE DRIER RESERVOIR.....	7-60
CHANGE POLY V-BELTS	7-61

EVERY 1800 HOURS OR EVERY 2 YEARS

CHANGE ENGINE BREATHER FILTER.....	7-63
------------------------------------	------

EVERY 3600 HOURS OR EVERY 2 YEARS

CHANGE DEF/ AdBlue MAIN FILTER	7-64
--------------------------------------	------

EVERY 36 MONTHS

SERVICE AIR CONDITIONER SYSTEM	7-65
CHECK BATTERY FLUID LEVEL	7-66

GENERAL MAINTENANCE

CLEANING THE TRACTOR.....	7-68
FUEL SYSTEM PRE- FILTER AND WATER TRAP	7-70
BLEEDING FUEL INJECTION SYSTEM.....	7-70
CHECK BRAKE PEDAL LATCHING/UNLATCHING	7-71
ADJUST CAB SUSPENSION (where fitted)	7-72
HEADLIGHT AND WORKLAMP ADJUSTMENT.....	7-73
BULB REPLACEMENT.....	7-74
FUSES AND RELAYS.....	7-78
PROTECTING ELECTRONIC AND ELECTRICAL SYSTEMS DURING BATTERY CHARGING OR WELDING	7-83
BATTERY REMOVAL AND INSTALLATION	7-84

STORAGE

TRACTOR STORAGE.....	7-85
PREPARATION FOR USE AFTER STORAGE	7-85

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

INTRODUCTION	8-1
--------------------	-----

ALARM(S)

FAULT CODES AND SYMBOLS	8-2
-------------------------------	-----

SYMPTOM(S)

ENGINE	8-4
TRANSMISSION	8-5
HYDRAULICS	8-5
THREE POINT HITCH	8-6
BRAKES.....	8-6
CAB.....	8-7
ELECTRICAL SYSTEM	8-7

9 SPECIFICATIONS

GENERAL DIMENSIONS	9-1
MAXIMUM OPERATING ANGLE	9-4
MAXIMUM OPERATING WEIGHTS	9-5
TRACTOR WEIGHTS	9-5
CAPACITIES	9-6
ENGINE	9-7
FUEL SYSTEM.....	9-7
AIR CLEANER SYSTEM	9-8
COOLING SYSTEM.....	9-8
TRANSMISSION	9-8
REAR POWER TAKE-OFF.....	9-9
FRONT POWER TAKE OFF	9-9

HYDRAULIC SYSTEM	9-10
THREE POINT HITCH	9-10
REMOTE CONTROL VALVES	9-12
THREE POINT HITCH FRONT	9-12
FRONT REMOTE VALVE COUPLERS	9-12
BRAKES.....	9-13
STEERING	9-13
ELECTRICAL EQUIPMENT.....	9-14
GROUND SPEED CHART SEMI POWERSHIFT TRANSMISSION	9-15
GROUND SPEED CHART FULL POWERSHIFT TRANSMISSION	9-18
MINIMUM HARDWARE TIGHTENING TORQUES	9-21

10 ACCESSORIES

RADIO (where fitted)	10-1
EXTERNAL REAR VIEW MIRRORS.....	10-1
AUXILIARY HEADLIGHTS	10-3
ROTATING BEACON.....	10-4
FRONT- END LOADER FIXATION POINTS	10-5

11 FORMS AND DECLARATIONS

Service record 1st 50 hour, Owner copy	11-1
Service record 1st 50 hour, Dealer copy	11-3

1 - GENERAL INFORMATION

METRIC AND IMPERIAL UNITS ABBREVIATIONS

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	ha	acre	ac
	square meter	m²	square foot	ft²
			square inch	in²
	square millimeter	mm²	square inch	in²
Electricity				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	µF	microfarad	µF
	ohm	Ω	ohm	Ω
Force				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
Force per length				
	newton per meter	N/m	pound per foot	lb/ft
			pound per inch	lb/in
Frequency				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
Frequency – Rotational				
	revolution per minute	r/min	revolution per minute	r/min ^a
		rpm		rpm
Length				
	kilometer	km	mile	mi
	meter	m	foot	ft
	centimeter	cm	inch	in
	millimeter	mm	inch	in
	micrometer	µm		
Mass				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
Mass per Mass				
	milligram per kilogram	mg/ kg		
Power				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour	Btu/hr
			Btu per minute	Btu/min
Pressure or stress (Force per area)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH2O
	megapascal	MPa	pound per square inch	psi

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than Thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
Torque (includes Bending moment, Moment of force, and Moment of a couple)				
	newton meter	N m	pound foot	lb ft
			pound foot	lb in
Velocity				
	kilometer per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimeter per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
Volume (includes Capacity)				
	cubic meter	m³	cubic yard	yd³
				cu yd
	liter	l	cubic inch	in³
	liter	l	US gallon	US gal
			UK gallon	UK gal
			US quart	US qt
			UK quart	UK qt
	milliliter	ml	fluid ounce	fl oz
Volume per time (includes Discharge and Flow rate)				
	cubic meter per minute	m³/min	cubic foot per minute	ft³/min
	liter per minute	l/min	US gallon per minute	US gal/min
	milliliter per minute	ml/min	UK gallon per minute	UK gal/min
Sound power level and Sound pressure level				
	decibel	dB	decibel	dB

Glossary

Acronym	Definition
DEF	Diesel Exhaust Fluid
ISO	International Organization for Standardization
MSDS	Material Safety Data Sheet
NOx	Nitrogen Oxide
PPE	Personal Protective Equipment
SCR	Selective Catalytic Reduction
ULSD	Ultra Low Sulfur Diesel
%	Percent
<	Less than
>	Greater than

TO THE OWNER

GENERAL INFORMATION

This Manual has been prepared to assist you in the correct procedure for running- in, driving and operating and for the maintenance of your new tractor. Read this Manual carefully. Your tractor is intended for use in normal and customary agricultural applications.

If at any time you require advice concerning your tractor, do not hesitate to contact your authorised dealer. He has factory trained personnel, genuine manufacturers' parts and the necessary equipment to carry out all your service requirements.

The specification are provided for your information and guidance. For further information concerning your tractor and equipment, consult your authorised dealer.

All data given in this manual is subject to production variations. Dimensions and weight are approximate only. The illustrations do not necessarily show tractors in standard condition or imply that these features are available in all countries. For exact information about any particular tractor, please consult your authorised dealer.

Your tractor has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Prior to delivery, the tractor was carefully inspected, both at the factory and by your dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble-free operation, it is important that the routine services, as specified on page 7-13 of this Manual, are carried out at the recommended intervals.

OPERATORS MANUAL STORAGE

The Operators Manual supplied with your tractor is an important source of information and should be stored safely.

The manual is written specifically for your tractor so it is important that you make a note of the print number and issue date which can be found on the cover. In the event the manual is lost or damaged it can be replaced with the correct version.

A storage pocket for the Operators Manual can be found on the rear of the seat. The manual should be kept in this pocket at all times when not in use.

ABOUT THIS MANUAL

This manual gives information for use of your machine, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance.

Read and understand; keep it in good condition and always safely store it in the provided pocket in the back of your seat for later easy retrieval.

This manual does not contain all the information related to periodical service, converting and repairs to be carried out by professional service personnel.

The Table of Contents page(s) are provided to have an overview of main manual's topics. A detailed alphabetic index is available at the end of this manual for locating specific items.

Normal operation

- Normal operation means the use of the tractor for the purpose intended by the manufacturer by an operator familiar with the tractor and the mounted or towed equipment and complying with the information for operation and safe practices, as specified by the manufacturer in this manual and by the decals on the tractor and the equipment.
- Normal operation includes the preparation and storage of the tractor, swinging components into work position and vice versa, adding or removing ballast and picking up and setting off attachments.
- Normal operation includes the adjustment and setting of the tractor and equipment, for the specific condition of the field and/ or the crop.

Routine service

- Routine service and maintenance means activities that must be done daily by an operator familiar with the tractor characteristics and complying with the information for routine service and safe practices, as specified by the manufacturer in this manual and by decals on the tractor, in order to maintain its proper function. Routine service includes activities such as fueling, cleaning, washing, topping up fluid levels, greasing, replacing of consumable articles such as lamp bulbs.

Converting, periodical service and repair

- Periodical service means activities that must be done at defined intervals by trained personnel familiar with the tractor characteristics and which are complying with the information for periodical service and safe practices, as partly specified by the manufacturer in this manual and in other Company literature, in order to maintain the expected life time of the tractor.
- Converting means activities that must be done by professional service personnel familiar with the tractor characteristics and complying with the information for converting, as partly specified by the manufacturer in this manual, in assembly instructions or in other Company literature, in order to fit the tractor to a specific configuration.
- Repair means activities that must be done by professional service personnel only familiar with the

tractor characteristics and complying with the information for repair, as specified by the manufacturer in the dealer's workshop manual, in order to restore the proper function of the tractor after a failure or degradation of performance.

CLEANING THE TRACTOR

Your tractor is a state- of- the- art machine with sophisticated, electronic controls. This should be taken into consideration when cleaning the tractor, particularly if using a high pressure washer. Even though every precaution has been taken to safeguard electronic components and connections, the pressure generated by some of these machines is such that complete protection against water ingress cannot be guaranteed.

When using a high pressure washer, do not stand too close to the tractor and avoid directing the jet at electronic components, electrical connections, breathers, seals, filler caps, etc. Never direct a cold water jet at a hot engine or exhaust.

Failure to comply with these rules will render the warranty null and void.

SAFETY

The pages in Section 2 list the precautions to be observed to ensure your safety and the safety of others. Read the safety precautions and follow the advice offered before operating the tractor.

FIRST 50 HOUR SERVICE

In Section 11, at the back of this Manual, you will find the 50- hour service reports.

NOTICE: *It is important the 50 hour service is carried out as recommended to ensure your tractor provides optimum performance and efficiency.*

After you have operated the tractor for 50 hours, take your tractor, together with this Manual, to your dealer. He will then perform the factory recommended 50 hour service and complete the service report sheets (pages **11-1**

and **11-3**). The first sheet (page **11-1**) is your copy of the service performed. The second sheet (page **11-3**) is the dealer's copy and should be removed by the dealer after the service has been carried out. Ensure that you and the dealer sign both copies.

SERVICE PARTS

It should be pointed out that genuine parts have been examined and approved by the Company. The installation and/ or use of 'non- genuine' products could have negative effects upon the design characteristics of your tractor and thereby affect its safety. The Company is not liable for any damage caused by the use of 'non- genuine' parts and accessories. Only genuine replacement parts should be used. The use of non- genuine parts may invalidate legal approvals associated with this product.

It is prohibited to carry out any modifications to the tractor unless specifically authorised, in writing, by the After Sales Service department of the Company.

WARRANTY

Your tractor is warranted according to legal rights in your country and the contractual agreement with the selling dealer. No warranty shall, however, apply if the tractor has not been used, adjusted and maintained according to the instructions given in the Operator's Manual.

USE OF BIODIESEL FUELS

NOTICE: *Before using Biodiesel fuels in your tractor, refer to the information on page 7-4 regarding the storage and use of Bio diesel fuels.*

EMISSION CONTROLS


NOTE: *The engine and fuel system on your machine is designed and built to government emissions standards. Tampering by dealers, customers, operators and users is strictly prohibited by law. Failure to comply could result in government fines, rework charges, invalid warranty, legal action and possible confiscation of the machine until rework to original condition is completed. Engine service and/ or repairs must be done by a certified technician only!*

PRODUCT IDENTIFICATION

The tractor and major components are identified using serial numbers and/ or manufacturing codes.

Tractor identification data must be supplied to the dealer when requesting parts or service and will also be needed to aid in identifying the tractor if it is ever stolen.

The following provides the locations of the identification data.



SS10J178 1

Vehicle Identification Plate


The vehicle identification plate (1) is located on the left-hand radiator support. Record the information on the sample identification plate provided below.

CNH INTERNATIONAL S.A.	TRACTOR NUMBER	
	[]	
	MODEL	DRIVELINE
	[]	[]
	ENGINE	HYDRAULIC PUMP
	[]	[]
	HYDRAULIC LIFT	FRONT AXLE
	[]	[]
Made in England		

SS10D342 2

Tractor Identification

The serial number and model identification information is stamped on the front support (1). These numbers are also repeated on the vehicle identification plate reproduced above.



BRL6441B 3

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com