

# **787 Air Seeding Systems**

**John Deere Des Moines Works  
TM1577 (19JUN02)**

LITHO IN U.S.A.  
ENGLISH

# Introduction

## FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

This manual is part of a total product support program.

## FOS MANUALS—REFERENCE

## TECHNICAL MANUALS—MACHINE SERVICE

## COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

# Contents

## SECTION 10—SAFETY AND GENERAL INFORMATION

- Group 05—Safety
- Group 10—Lubricants
- Group 15—General Information
- Group 20—Repair Specifications

## SECTION 20—WELDING

- Group 05—Repair and Welding

## SECTION 30—AIR SYSTEM

- Group 05—System and Component Repair

## SECTION 40—ELECTRICAL AND MONITOR SYSTEMS

- Group 05—Component Replacement
- Group 10—Connector Repair

## SECTION 50—METER DRIVE SYSTEM

- Group 05—Meter Drive Repair

## SECTION 60—CASTER AND WHEEL BEARINGS

- Group 05—Caster and Wheel Bearings

## SECTION 70—HYDRAULIC SYSTEM COMPONENTS

- Group 05—Component Repair

## SECTION 80—MISCELLANEOUS

- Group 05—Auger Repair

## SECTION 230—AIR SYSTEM THEORY OF OPERATION, TESTS AND TROUBLESHOOTING

- Group 05—Air System Theory of Operation
- Group 10—Tests
- Group 15—Troubleshooting

## SECTION 240—ELECTRICAL AND MONITOR DIAGNOSIS AND TESTS

- Group 05—Electrical and Monitor Systems Component Identification

- Group 10—Wiring Diagrams—170/230 Bushel and Third Tank

- Group 11—Wiring Diagrams—130 Bushel

- Group 15—170/230 Bushel and Third Tank Monitor System Troubleshooting

- Group 16—130 Bushel Monitor System Troubleshooting

- Group 17—Monitor System Component Tests

- Group 20—Electrical System Component Tests and Troubleshooting

## SECTION 250—METER DRIVE THEORY OF OPERATION, TESTS AND TROUBLESHOOTING

- Group 05—Meter Drive Theory of Operation

- Group 10—Tests and Adjustments

- Group 15—Troubleshooting

## SECTION 260—CASTER WHEEL ADJUSTMENTS

- Group 05—Brake Pad Adjustment

## SECTION 270—HYDRAULIC SYSTEM

- Group 05—Hydraulic Requirements, Schematics and Troubleshooting

## SECTION 280—MISCELLANEOUS

- Group 05—Auger Adjustments and Troubleshooting

## Index

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

TM1577-19-19JUN02

COPYRIGHT© 1994  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION® Manual

# Section 10 SAFETY AND GENERAL INFORMATION


## Contents

	Page
<b>Group 05—Safety</b> . . . . .	10-05-1
<b>Group 10—Lubricants</b> . . . . .	10-10-1
<b>Group 15—General Information</b>	
Unauthorized Modifications . . . . .	10-15-1
Configuration Identification . . . . .	10-15-1
Product Identification	
130 Bushel . . . . .	10-15-2
170/230 Bushel . . . . .	10-15-2
Third Tank . . . . .	10-15-3
Compatible Tillage Equipment	
610 Seeding Tool . . . . .	10-15-3
1060 Seeding Tool . . . . .	10-15-4
730 Air Disk Drill . . . . .	10-15-4
735 Seeding Tool . . . . .	10-15-5
737 Air Hoe Drill . . . . .	10-15-5
Machine Specifications	
130 Bushel . . . . .	10-15-6
170 Bushel . . . . .	10-15-7
230 Bushel . . . . .	10-15-8
Third Tank . . . . .	10-15-9
Tractor Specifications . . . . .	10-15-9
Tractor Hydraulic System Requirements . .	10-15-10
<b>Group 20—Repair Specifications</b>	
Metric Bolt and Cap Screw Torque	
Values . . . . .	10-20-1
Unified Inch Bolt and Cap Screw Torque	
Values . . . . .	10-20-2
O-Ring Fitting Torques . . . . .	10-20-3
Flare-Type Tube Fitting Torque Chart . . .	10-20-4
Flare-Type Hose Fitting Torque Chart . . .	10-20-4

### RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389 -UN-07DEC88

### UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187 -19-30SEP88


### AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93

X9811 -UN-23AUG88

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)