

DV207
Vibratory Roller

SERVICE MANUAL

Part number 845571 IA

English
April 2012



DV207

Service Manual

Print No. 8455711A



QUICK REFERENCE – CHAPTER GUIDE

SECTION 00 – MAINTENANCE

GENERAL INSTRUCTIONS

1. Introduction
2. Safety precautions
3. Repair safety precautions
4. Product identification
5. Check the tightening of bolted joints

SECTION 00 – MAINTENANCE

GENERAL SPECIFICATIONS

6. Description of the machine
7. Tooling

SECTION 10 – ENGINE

8. Removing the engine
9. Removing the cooler

SECTION 35 – HYDRAULIC SYSTEM

10. Hydraulic system
11. Hydraulics

SECTION 39 – FRAMES

12. Articulated joint
13. Removing the hood

SECTION 41 - STEERING

14. Steering cylinder

SECTION 44 – AXLES AND WHEELS

15. Removing the drum

SECTION 50 – CAB CLIMATE CONTROL

16. Removing the heater/cooling air fans

SECTION 55 – ELECTRICAL SYSTEM

17. Electrical installation
18. Electrical system

SECTION 90 – CAB

19. Cab

INDEX

Contents

SECTION 00 – MAINTENANCE

GENERAL INSTRUCTIONS

1. Introduction1-1

2. Safety precautions2-1

2.1. Safety section2-2

2.1.1. Precautionary statements – personal safety signal words.....2-2

2.1.2. Machine safety and information signal words.....2-2

2.1.3. General safety rules.....2-3

2.1.4. General operating safety2-4

2.2. Safety sign location overview2-5

2.2.1. Safety signs2-6

2.3. General maintenance safety2-10

2.3.1. Fire and explosion prevention.....2-10

2.3.2. Hazardous chemicals2-11

2.3.3. Battery safety2-11

2.3.4. Air conditioning system2-12

2.3.5. Transportation safety2-12

2.3.6. Proper entry and exit2-12

2.3.7. Operator presence system2-12

2.3.8. Operator protective structure2-13

2.3.9. Utility safety2-13

2.4. Hand signals2-14

3. Repair safety precautions3-1

3.1. Safety regulations3-2

3.2. Ecological measures & hygiene principles3-6

3.3. Fire measures3-7

4. Product identification4-1

4.1. Summary of applications4-2

5. Check the tightening of bolted joints5-1

5.1. Check the tightening of bolted joints.....5-2

SECTION 00 – MAINTENANCE

GENERAL SPECIFICATIONS

6. Description of the machine6-1

6.1. Machine construction6-2

6.2. Fluid/lubricant specifications6-3

6.2.1. Engine oil6-3

6.2.2. Fuel6-4

6.2.3. Coolant6-5

6.2.4. Hydraulic oil6-5

6.2.5. Lube grease6-5

6.2.6. Washer fluid6-5

6.2.7. Gear oil6-5

6.3. Technical data DV2076-6

6.4. Dimensional diagram DV2076-8

TABLE OF CONTENTS

7. Tooling	7-1
7.1. Tooling and equipment.....	7-2

SECTION 10 – ENGINE

8. Removing the engine	8-1
9. Removing the cooler	9-1

SECTION 35 – HYDRAULIC SYSTEM

10. Hydraulic system	10-1
10.1. Hydraulic diagram.....	10-3
11. Hydraulics.....	11-1
11.1. Removing the cooling hydromotor	11-4
11.2. Removing the gear pump for steering	11-8
11.3. Removing the tandem pumps for vibration and travel	11-14
11.3.1. Vibration pump.....	11-14
11.3.2. Travel pump	11-16
11.4. Adjusting vibration frequency.....	11-18
11.5. Adjusting pulse sensors.....	11-19
11.6. Measuring hydraulic circuit safety pressures	11-20

SECTION 39 – FRAMES

12. Articulated joint	12-1
12.1. Preparation work.....	12-4
12.2. Removing the steering joint	12-10
12.3. Removing the slewing ring bearing.....	12-15
12.4. Removing the steering joint bearing	12-16
12.5. Installing the steering joint bearing	12-19
12.6. Adjusting the zero position of the steering joint	12-22
13. Removing the hood.....	13-1

SECTION 41 - STEERING

14. Steering cylinder	14-1
14.1. Removing hydraulic cylinders for steering and CRAB	14-4
14.2. Replacing packing material for steering or Crab hydraulic cylinders	14-5

SECTION 44 – AXLES AND WHEELS

15. Removing the drum	15-1
15.1. Removing the vibration hydromotor.....	15-12
15.2. Removing the travel hydromotor.....	15-14
15.3. Removing the auxiliary transmission	15-16
15.4. Removing the front drum	15-18
15.5. Replacing the rubber mounting of the drum	15-30

SECTION 50 – CAB CLIMATE CONTROL

16. Removing the heater/cooling air fans	16-1
16.1. Removing the heater	16-4
16.2. Removing cooling air fans	16-8

SECTION 55 – ELECTRICAL SYSTEM

17. Electrical installation17-1

- 17.1. Fuses 17-2
- 17.2. Storage battery 17-4
- 17.3. Alternator 17-5
- 17.4. Starter motor 17-7
- 17.5. Layout of wiring elements in the machine..... 17-10

18. Electrical system.....18-1

- 18.1. Wiring diagram DV207..... 18-3

SECTION 90 – CAB

19. Cab19-1

- 19.1. Idle and parking brake position sensor 19-4
- 19.2. Left-hand control panel, reversing horn sensor 19-4
- 19.3. Seat platform 19-8
- 19.4. Power steering servo 19-12
- 19.5. Seat switch 19-16

INDEX

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com