



**Bobcat®**

# Service Manual

## G Series

S/N 514140001 & Above  
S/N 514240001 & Above  
S/N 517911001 & Above

S/N 520111001 & Above  
S/N 520211001 & Above


**TURBO**

**873**

**TURBO**

**883**

**INCLUDES HIGH FLOW**



## CONTENTS

FORWORD . . . . .	II
SAFETY INSTRUCTIONS . . . . .	V
SERIAL NUMBER LOCATION . . . . .	IX
DELIVERY REPORT . . . . .	X
BOBCAT LOADER IDENTIFICATION . . . . .	XI
SAFETY & MAINTENANCE . . . . .	10-01
HYDRAULIC SYSTEM . . . . .	20-01
HYDROSTATIC SYSTEM . . . . .	30-01
DRIVE SYSTEM . . . . .	40-01
MAIN FRAME . . . . .	50-01
ELECTRICAL SYSTEM & ANALYSIS . . . . .	60-01
ENGINE SERVICE . . . . .	70-01
HEATING, VENTILATION, AIR CONDITIONING . . . . .	80-01
SPECIFICATIONS . . . . .	SPEC-01

**SAFETY &  
MAINTENANCE**

**HYDRAULIC  
SYSTEM**

**HYDROSTATIC  
SYSTEM**

**DRIVE  
SYSTEM**

**MAIN FRAME**

**ELECTRICAL  
SYSTEM &  
ANALYSIS**

**ENGINE  
SERVICE**

**HVAC**

**SPECIFICATIONS**

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)