

SERVICE MANUAL

CR6.80 / CR6.90 / CR7.90 /

CR8.90 / CR9.90

Tier 4B (final)

Combine

Part number 47865347

1st edition English

April 2015



Link Product / Engine

Product	Market Product	Engine
CR6.80 TIER 4B	North America	F2CFE613C*B006
CR6.90 TIER 4B	North America	F2CFE613C*B006
CR7.90 TIER 4B	North America	F2CFE613A*B
CR8.90 TIER 4B	North America	F3GFE613B*B001
CR9.90 TIER 4B	North America	F3HFE613A*B003

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.304] Engine lubrication system.....	10.3
[10.310] Aftercooler.....	10.4
[10.400] Engine cooling system	10.5
[10.414] Fan and drive	10.6
[10.418] Rotary screen	10.7
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.8
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Transmission	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.145] Gearbox internal components.....	21.3
[21.182] Differential.....	21.4
Front axle system	25
[25.100] Powered front axle	25.1
[25.108] Final drive hub, steering knuckles, and shafts	25.2
[25.310] Final drives	25.3
Rear axle system	27
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts	27.2
Hydrostatic drive	29
[29.100] Transmission and steering hydrostatic control	29.1

[29.134] Two-speed assembly	29.2
[29.202] Hydrostatic transmission	29.3
[29.204] Reservoir, cooler, and lines	29.4
[29.218] Pump and motor components.....	29.5
[29.300] Rear hydrostatic transmission.....	29.6
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump	35.3
[35.220] Auxiliary hydraulic pump and lines	35.4
[35.300] Reservoir, cooler, and filters.....	35.5
[35.359] Main control valve.....	35.6
[35.410] Header or attachment height system	35.7
[35.440] Grain tank unload system	35.8
[35.450] Traction variator system.....	35.9
[35.518] Reel control system	35.10
[35.536] Crop processor system	35.11
[35.602] Header or attachment leveling system	35.12
[35.760] Header reverser drive	35.13
[35.796] Chaff spreader control	35.14
Pneumatic system	36
[36.100] Pneumatic system.....	36.1
Steering.....	41
[41.101] Steering control	41.1
[41.200] Hydraulic control components.....	41.2

[41.206] Pump	41.3
[41.216] Cylinders	41.4
[41.432] Autoguidance steering	41.5
Tracks and track suspension	48
[48.100] Tracks	48.1
[48.130] Track frame and driving wheels	48.2
[48.134] Track tension units	48.3
[48.138] Track rollers	48.4
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.2
[55.100] Harnesses and connectors.....	55.3
[55.201] Engine starting system	55.4
[55.301] Alternator	55.5
[55.302] Battery.....	55.6
[55.408] Warning indicators, alarms, and instruments	55.7
[55.421] Feeding control system	55.8
[55.423] Cleaning control system.....	55.9
[55.426] Harvest material flow control system.....	55.10
[55.610] Ground speed control	55.11
[55.624] Residue handling control.....	55.12
[55.640] Electronic modules	55.13
[55.662] Header height control	55.14
[55.675] Reel speed and position control.....	55.15

[55.780] Shaker shoe leveling system control.....	55.16
[55.785] Precision farming system	55.17
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.18
[55.DTC] FAULT CODES.....	55.19
Product feeding	60
[60.105] Floating roll, feed chain, and drive	60.1
[60.110] Feeder housing	60.2
[60.112] Stone trapping system	60.3
[60.130] Feeder housing shafts	60.4
[60.150] Feeder drive system	60.5
Threshing	66
[66.000] Threshing	66.1
[66.101] Concave conveyor plate	66.2
[66.105] Concave.....	66.3
[66.110] Concave control system.....	66.4
[66.260] Threshing mechanism drive system	66.5
[66.321] Drum/Rotor variator with electrical control	66.6
[66.331] Rotor	66.7
[66.360] Drum/Rotor housing.....	66.8
Separation	72
[72.101] Straw walkers and shafts	72.1
[72.110] Straw walker drive system	72.2
[72.220] Discharge beater.....	72.3
[72.350] Beater	72.4
[72.420] Rotary separator	72.5
Residue handling.....	73
[73.210] Straw chopper drive system.....	73.1
[73.220] Straw chopper frame	73.2

[73.230] Straw chopper.....	73.3
[73.300] Positive Straw Discharge (PSD)	73.4
[73.335] Chaff spreader	73.5
[73.410] Opti-Spread™ system.....	73.6
Cleaning	74
[74.000] Cleaning.....	74.1
[74.100] Self-leveling frame	74.2
[74.101] Cleaning drive systems	74.3
[74.110] Grain pan.....	74.4
[74.114] Upper shaker shoe	74.5
[74.118] Lower shaker shoe	74.6
[74.130] Fan housing	74.7
[74.136] Fan drive system	74.8
[74.140] Tailings return system	74.9
Crop storage / Unloading	80
[80.101] Clean grain elevator.....	80.1
[80.150] Grain tank	80.2
[80.175] Grain tank unload drive system	80.3
[80.180] Grain tank unload	80.4
Platform, cab, bodywork, and decals	90
[90.100] Engine hood and panels	90.1
[90.105] Machine shields and guards	90.2
[90.118] Protections and footboards.....	90.3
[90.124] Pneumatically-adjusted operator seat.....	90.4
[90.150] Cab.....	90.5
[90.151] Cab interior.....	90.6

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com