

**AXIAL-FLOW® 7230**  
**AXIAL-FLOW® 8230**  
**AXIAL-FLOW® 9230**  
Rotary Combine

**SERVICE MANUAL**

Part number 48040837

English

August 2017

© 2017 CNH Industrial Latin America LTDA. All Rights Reserved.





## **SERVICE MANUAL**

**AXIAL-FLOW® 7230 Machine Standard Tier III produced in Brazil.,  
AXIAL-FLOW® 7230 Machine with Power Guide Axle Tier III produced in  
Brazil, AXIAL-FLOW® 8230 Machine Standard Tier III produced in Brazil.,  
AXIAL-FLOW® 8230 Machine with Power Guide Axle Tier III produced in  
Brazil. , AXIAL-FLOW® 9230 Machine Standard Tier III produced in Brazil.,  
AXIAL-FLOW® 9230 Machine with Power Guide Axle Tier III produced in  
Brazil.**

## Link Product / Engine

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
AXIAL-FLOW® 7230 Máquina com Power Guide Axle Tier III produzida no Brasil	Latin America	F3AE9684A*E001
AXIAL-FLOW® 7230 Máquina com Power Guide Axle Tier III produzida no Brasil	Latin America	F3AE9684A*E001
AXIAL-FLOW® 8230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684A*E001
AXIAL-FLOW® 8230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684A*E001
AXIAL-FLOW® 9230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684B*E002
AXIAL-FLOW® 9230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684B*E002

# Contents

---

## INTRODUCTION

<b>Engine</b> .....	<b>10</b>
[10.202] Air cleaners and lines .....	10.1
[10.216] Fuel tanks .....	10.2
[10.218] Fuel injection system.....	10.3
[10.310] Aftercooler.....	10.4
[10.400] Engine cooling system .....	10.5
[10.414] Fan and drive .....	10.6
[10.418] Rotary screen .....	10.7
[10.450] Engine air compressor .....	10.8
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.9
<b>Main gearbox and drive</b> .....	<b>14</b>
[14.100] Main gearbox and drive .....	14.1
<b>Transmission</b> .....	<b>21</b>
[21.100] Mechanical transmission hydraulic components .....	21.1
[21.114] Mechanical transmission .....	21.2
[21.130] Mechanical transmission external controls.....	21.3
[21.145] Gearbox internal components.....	21.4
[21.182] Differential .....	21.5
<b>Front axle system</b> .....	<b>25</b>
[25.100] Powered front axle .....	25.1
[25.108] Final drive hub, steering knuckles, and shafts .....	25.2
[25.310] Final drives .....	25.3
<b>Rear axle system</b> .....	<b>27</b>
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts .....	27.2

[27.550] Non-powered rear axle .....	27.3
<b>Hydrostatic drive</b> .....	<b>29</b>
[29.100] Transmission and steering hydrostatic control .....	29.1
[29.134] Two-speed assembly .....	29.2
[29.202] Hydrostatic transmission .....	29.3
[29.218] Pump and motor components .....	29.4
[29.300] Rear hydrostatic transmission .....	29.5
<b>Power Take-Off (PTO)</b> .....	<b>31</b>
[31.146] Front Power Take-Off (PTO) .....	31.1
<b>Brakes and controls</b> .....	<b>33</b>
[33.110] Parking brake or parking lock .....	33.1
[33.202] Hydraulic service brakes .....	33.2
<b>Hydraulic systems</b> .....	<b>35</b>
[35.000] Hydraulic systems .....	35.1
[35.102] Pump control valves .....	35.2
[35.106] Variable displacement pump .....	35.3
[35.220] Auxiliary hydraulic pump .....	35.4
[35.300] Reservoir, cooler, and filters .....	35.5
[35.350] Safety and main relief valves .....	35.6
[35.359] Main control valve .....	35.7
[35.410] Header or attachment height system .....	35.8
[35.415] Header or attachment tilting system .....	35.9
[35.440] Grain tank unload system .....	35.10
[35.518] Reel control system .....	35.11
[35.536] Crop processor system .....	35.12
[35.796] Chaff spreader control .....	35.13
<b>Steering</b> .....	<b>41</b>
[41.101] Steering control .....	41.1

[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders .....	41.3
[41.432] Autoguidance steering .....	41.4
<b>Wheels.....</b>	<b>44</b>
[44.511] Front wheels.....	44.1
[44.520] Rear wheels .....	44.2
<b>Tracks and track suspension.....</b>	<b>48</b>
[48.130] Track frame and driving wheels .....	48.1
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.104] Ventilation .....	50.2
[50.200] Air conditioning.....	50.3
<b>Electrical systems .....</b>	<b>55</b>
[55.015] Engine control system.....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.408] Warning indicators, alarms, and instruments .....	55.3
[55.988] Selective Catalytic Reduction (SCR) electrical system .....	55.4
[55.DTC] FAULT CODES.....	55.5
<b>Attachments/Headers.....</b>	<b>58</b>
[58.130] Attachment/Header frame.....	58.1
<b>Product feeding .....</b>	<b>60</b>
[60.105] Floating roll, feed chain, and drive .....	60.1
[60.110] Feeder housing.....	60.2
[60.112] Stone trapping system .....	60.3
[60.122] Length-of-cut gearbox.....	60.4
[60.150] Feeder drive system .....	60.5
[60.220] Pickup .....	60.6

<b>Threshing</b> .....	<b>66</b>
[66.000] Threshing .....	66.1
[66.105] Concave .....	66.2
[66.110] Concave control system .....	66.3
[66.260] Threshing mechanism drive system .....	66.4
[66.331] Rotor .....	66.5
<b>Separation</b> .....	<b>72</b>
[72.220] Discharge beater .....	72.1
[72.420] Rotary separator .....	72.2
<b>Residue handling</b> .....	<b>73</b>
[73.210] Straw chopper drive system .....	73.1
[73.215] Straw chopper electro-magnetic clutch support .....	73.2
[73.230] Straw chopper .....	73.3
[73.AAA] Residue handling generic sub-group .....	73.4
[73.430] Straw spreader .....	73.5
<b>Cleaning</b> .....	<b>74</b>
[74.000] Cleaning .....	74.1
[74.100] Self-leveling frame .....	74.2
[74.101] Cleaning drive systems .....	74.3
[74.110] Grain pan .....	74.4
[74.114] Upper shaker shoe .....	74.5
[74.118] Lower shaker shoe .....	74.6
[74.130] Fan housing .....	74.7
[74.136] Fan drive system .....	74.8
[74.140] Tailings return system .....	74.9
<b>Crop storage / Unloading</b> .....	<b>80</b>
[80.101] Clean grain elevator .....	80.1
[80.150] Grain tank .....	80.2

[80.175] Grain tank unload drive system .....	80.3
[80.180] Grain tank unload .....	80.4
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.105] Machine shields and guards .....	90.1
[90.118] Protections and footboards.....	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.150] Cab.....	90.4
[90.151] Cab interior.....	90.5



Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)