

SERVICE MANUAL

CX5.80 / CX5.90 / CX5.90 Laterale
CX5.90 Hillside / CX6.80 / CX6.90
CX6.90 Laterale
Combine

Part number 51666608

English
September 2019





SERVICE MANUAL

CX5.80 FPT NEF 6 Stage V, CX5.80 FPT NEF 6 Stage V, CX5.90 FPT NEF 6 Stage V, CX5.90 FPT NEF 6 Tier 3, CX5.90 Hillside FPT NEF 6 Stage V, CX5.90 Laterale FPT NEF 6 Stage V, CX6.80 FPT NEF 6 Stage V, CX6.80 FPT NEF 6 Stage V, CX6.80 FPT NEF 6 Tier 3, CX6.90 FPT Cursor® 9 Stage V, CX6.90 FPT Cursor® 9 Stage V, CX6.90 FPT Cursor® 9 Tier 3, CX6.90 FPT Cursor® 9 Tier 3, CX6.90 Laterale FPT Cursor® 9 Stage V

Link Product / Engine

Product	Market Product	Engine
CX5.80 FPT NEF 6 Stage V	Europe	F4HGE613B*V009
CX5.80 FPT NEF 6 Stage V	Europe	F4HGE613B*V009
CX5.90 FPT NEF 6 Tier 3	Europe	F4HE9687G*J104
CX5.90 FPT NEF 6 Tier 3	Middle East Africa	F4HE9687G*J104
CX5.90 FPT NEF 6 Tier 3	Asia Pacific	F4HE9687G*J104
CX5.90 FPT NEF 6 Stage V	Europe	F4HGE613A*V005
CX5.90 Hillside FPT NEF 6 Stage V	Europe	F4HGE613A*V005
CX5.90 Laterale FPT NEF 6 Stage V	Middle East Africa	F4HGE613A*V005
CX5.90 Laterale FPT NEF 6 Stage V	Europe	F4HGE613A*V005
CX5.90 Laterale FPT NEF 6 Stage V	Asia Pacific	F4HGE613A*V005
CX6.80 FPT NEF 6 Tier 3	Asia Pacific	F4HE9687G*J104
CX6.80 FPT NEF 6 Tier 3	Middle East Africa	F4HE9687G*J104
CX6.80 FPT NEF 6 Tier 3	Europe	F4HE9687G*J104
CX6.80 FPT NEF 6 Stage V	Europe	F4HGE613A*V005
CX6.80 FPT NEF 6 Stage V	Europe	F4HGE613A*V005
CX6.90 FPT Cursor® 9 Tier 3	Europe	F2CE9684C*E030
CX6.90 FPT Cursor® 9 Tier 3	Asia Pacific	F2CE9684C*E030
CX6.90 FPT Cursor® 9 Tier 3	Middle East Africa	F2CE9684C*E030
CX6.90 FPT Cursor® 9 Tier 3	Asia Pacific	F2CE9684C*E030
CX6.90 FPT Cursor® 9 Stage V	Europe	F2CGE613A*V004
CX6.90 FPT Cursor® 9 Stage V	Europe	F2CGE613A*V004

Contents

INTRODUCTION

Machine completion and equipment	05
[05.102] Machine completion	05.1
Engine.....	10
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.1
[10.001] Engine and crankcase	10.2
[10.450] Engine air compressor	10.3
[10.216] Fuel tanks	10.4
[10.418] Rotary screen	10.5
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.145] Gearbox internal components.....	21.3
[21.182] Differential.....	21.4
Front axle system	25
[25.310] Final drives	25.1
Rear axle system.....	27
[27.550] Non-powered rear axle.....	27.1
[27.100] Powered rear axle.....	27.2
Hydrostatic drive.....	29
[29.204] Reservoir, cooler, and lines	29.1
[29.218] Pump and motor components.....	29.2
[29.202] Hydrostatic transmission	29.3
[29.300] Rear hydrostatic transmission.....	29.4

Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump	35.3
[35.204] Remote control valves	35.4
[35.359] Main control valve.....	35.5
[35.610] Machine leveling control system	35.6
[35.630] Machine lateral leveling system.....	35.7
[35.640] Machine longitudinal leveling system	35.8
[35.410] Header or attachment height system	35.9
[35.602] Header or attachment leveling system.....	35.10
[35.518] Reel control system	35.11
[35.760] Header reverser drive	35.12
[35.420] Reel vertical positioning system.....	35.13
[35.430] Reel fore-and-aft positioning system.....	35.14
[35.440] Grain tank unloading system.....	35.15
[35.415] Header or attachment tilting system	35.16
Steering.....	41
[41.101] Steering control	41.1
[41.200] Hydraulic control components.....	41.2
[41.206] Pump	41.3
[41.216] Cylinders	41.4
[41.432] Autoguidance steering	41.5
Cab climate control	50
[50.100] Heating.....	50.1

[50.200] Air conditioning.....	50.2
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.3
[55.640] Electronic modules	55.4
[55.019] Hydrostatic drive control system	55.5
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls.....	55.6
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.7
[55.512] Cab controls.....	55.8
[55.834] Sieve electric control	55.9
[55.408] Warning indicators, alarms, and instruments	55.10
[55.785] Precision farming system	55.11
[55.426] Harvest material flow control system.....	55.12
[55.746] Leveling system electrical components	55.13
[55.047] Steering control system	55.14
[55.DTC] FAULT CODES.....	55.15
Attachments/Headers.....	58
[58.105] Attachment/Header reel control system.....	58.1
[58.900] Belt feeding	58.2
Product feeding	60
[60.000] Product feeding	60.1
[60.101] Feed roll.....	60.2
[60.105] Floating roll, feed chain, and drive	60.3
[60.110] Feeder housing.....	60.4
[60.150] Feeder drive system	60.5
[60.120] Header drive system	60.6
Threshing	66

[66.000] Threshing	66.1
[66.330] Drum	66.2
[66.321] Drum/Rotor variator with electrical control	66.3
[66.105] Concave	66.4
[66.110] Concave control system	66.5
Separation	72
[72.000] Separation	72.1
[72.350] Beater	72.2
[72.420] Rotary separator	72.3
[72.410] Rotary separator drive system	72.4
[72.440] Straw-flow beater	72.5
[72.101] Straw walkers and shafts	72.6
[72.110] Straw walker drive system	72.7
Residue handling	73
[73.000] Residue handling	73.1
[73.230] Straw chopper	73.2
[73.210] Straw chopper drive system	73.3
[73.335] Chaff spreader	73.4
Cleaning	74
[74.000] Cleaning	74.1
[74.101] Cleaning drive systems	74.2
[74.110] Grain pan	74.3
[74.114] Upper shaker shoe	74.4
[74.118] Lower shaker shoe	74.5
[74.130] Fan housing	74.6
[74.136] Fan drive system	74.7
[74.140] Tailings return system	74.8
Crop storage / Unloading	80

[80.101] Clean grain elevator.....	80.1
[80.150] Grain tank	80.2
[80.175] Grain tank unload drive system	80.3
[80.180] Grain tank unload	80.4
Platform, cab, bodywork, and decals.....	90
[90.154] Cab doors and hatches	90.1
[90.105] Machine shields and guards	90.2
[90.150] Cab.....	90.3

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com