# 

#### EXPLORER 115.4 -> ZKDAV90200TS10001

Section: B0 - ENGINE Ref: B0.01.0 (1)


CRANKCASE

Fig.	P/n	QTY	Name

#### Note

[EXPLORER 115.4 2WD -> ZKDAV90100TS10001] [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]


1.1	0.020.4332.3/20	1	crankcase
1.1.1	0.019.5106.3	1	support
1.1.1.2	2.1699.165.0	1	bush 12.3x15x16
1.1.2	0.019.5107.7	3	support
1.1.3	0.019.5108.3	1	support
1.1.3.2	2.1699.165.0	1	bush 12.3x15x16
1.1.5	0.065.1140.0	4	special bushing 59X55X20
1.1.6	0.065.1141.0	1	special bushing 59X55X30
1.1.7	0.019.4412.0	1	pin
1.2	2.3130.001.7	15	plug
1.3	2.3130.002.7	2	plug 1/4" gas
1.4	2.3130.003.7	4	plug 3/8" gas
1.5	2.3130.005.7	3	plug
1.6	0.019.4146.0	1	tube
1.7	0.019.6173.0	1	tube
1.8	2.3179.012.0	1	plug 60
1.9	2.3171.010.4	5	plug 25
9	0.019.4415.0/10	1	tube
10	0.066.1152.0/10	4	gasket
11	2.1011.405.2	2	nut m 8 p.1
12	2.1470.004.2	4	lock washer 8
13	2.1651.305.0	4	pin 4 x 12
14	2.1651.507.0	4	pin 6 x 16
15	2.1560.027.0	1	copper gasket 38.3x44
16	2.3139.031.2	1	plug
17	2.1560.010.0	1	gasket 14.2 x 20
18	2.3199.292.0	1	plug 1/4" gas
24	2.3139.024.2	1	plug m 12 p.1.5 ( -> 10002 )
25	2.0399.367.7	10	screw



Section: B0 - ENGINE Ref: B0.01.1 (1)

# **CYLINDER LINER O-RING**

Fig.	P/n	QTY	Name
Notes: [EXPLORER	115.4 2WD -> ZKDA\	/90100TS1000	[EXPLORER 115.4 4WD -> ZKDAV90200TS10001]
16	2.1539.259.0	8	special oil seal 107.62x2.62



9\_K8015\_03\_0-B-001

#### EXPLORER 115.4 -> ZKDAV90200TS10001

Section: B0 - ENGINE Ref: B0.01.2 (1)


# SIDE PLUG FOR CYLINDER BLOCK

Fig.	P/n	QTY	Name

#### Notes:

- FOR TYPES WITH PNEUMATIC BRAKE [EXPLORER 115.4 2WD -> ZKDAV90100TS10001] - FOR TYPES WITH PNEUMATIC BRAKE [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]


12	2.1560.018.0	1	gasket 22.2 x 29
13	2.3120.102.0	1	plug



Section: B0 - ENGINE Ref: B0.01.3 (1)

# MONOBLOC ENGINE-GEARBOX CONNECTING FLANGE


Fig.	P/n	QIY	Name
Notes:			
[EXPLORI	ER 115.4 2WD -> ZKDAV9	0100TS100	[EXPLORER 115.4 4WD -> ZKDAV90200TS10001]
1	2.1475.005.2	2	washer 14
2	2.0112.524.2	2	screw m 14 p.2 x 75
3	2.0112.624.2	2	screw m 16 p.2 x 75
4	2.1475.006.2	2	spring washer 16
6	2.0439.250.7	1	stud bolt m 12 / m 10 x 30
7	0.011.9294.0/10	1	bush
25	0.019.1488.0	1	flange
26	2.0112.511.2	8	screw m 14 p.2 x 30
27	2.1651.912.0	2	cylindrical plug 12x28
28	2.1651.917.0	1	cylindrical plug 12x40
29	2.0432.257.7	1	stud bolt m 12 p.1.75 - 1.25 x 30



Ref: B0.02.0 (1) Section: B0 - ENGINE

# CRANKSHAFT PULLEY

Fig.	<u> </u>	QTY	Name
Notes:			
[EXPLOR	ER 115.4 2WD -> ZKDAV	90100TS10	001] [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]
1	0.019.9925.0	1	pulley
2	0.019.6668.0	1	flange
3	0.065.1256.0	2	ring 45x52
4	2.1579.865.0	1	spacer 45.2x51.8x10
5	2.0439.195.7	1	stud bolt m 20 p.1.5x80
6	2.1019.094.7	1	nut m 20 p.1.5
7	2.0112.320.2	6	screw m 10 p.1.5 x 55
8	2.1470.006.2	6	lock washer 10
9	2.1720.006.0	1	key 4x6.5
10	0.019.6413.0	1	gear wheel
11	2.1651.505.0	1	cylindrical plug 6x12



Section: B0 - ENGINE Ref: B0.02.1 (2)


# BELT AND TENSIONER

Fig. P/n QTY Name				
	Fig.	P/n	QTY	Name

#### Notes:

- WITH MANUAL AIR CONDITIONING [EXPLORER 115.4 2WD -> ZKDAV90100TS10001] - WITH MANUAL AIR CONDITIONING [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]

1	2.4119.218.0/10	1	belt PK 10 L=2017	
3	0.019.9869.4/10	3	pulley guide	
4	2.0312.214.2	5	screw m 8 p.1.25 x 40	
5	0.020.4604.0	1	support	
7	2.0399.380.2	1	screw	
8	2.0399.379.2	1	small column	
9	2.1480.015.2	1	washer 10	
10	2.1480.014.2	5	washer 8	
11	2.1310.004.2	2	flat washer 8.4x17	
13	2.0112.209.2	2	screw m 8 p 1.25 x 25	



Section: B0 - ENGINE Ref: B0.02.2 (2)


# BELT AND TENSIONER

Fig. P/n QTY Name				
	Fig.	P/n	QTY	Name

#### Notes:

WITHOUT AIR-CONDITIONING [EXPLORER 115.4 2WD -> ZKDAV90100TS10001] WITHOUT AIR-CONDITIONING [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]

1	2.4119.219.0	1	belt PK 10 L=1498
3	0.019.9869.4/10	2	pulley guide
4	2.0312.214.2	5	screw m 8 p.1.25 x 40
5	0.020.4604.0	1	support
7	2.0399.380.2	1	screw
8	2.0399.379.2	1	small column
9	2.1480.015.2	1	washer 10
10	2.1480.014.2	5	washer 8
11	2.1310.004.2	2	flat washer 8.4x17
13	2.0112.209.2	2	screw m 8 p 1.25 x 25




9\_IB117\_10\_0-A-001

# **EXPLORER 115.4 -> ZKDAV90200TS10001**

Section: B0 - ENGINE Ref: B0.02.3 (1)

# TENSION ROLLER

Fig.	P/n	QTY	' Name
Notes: [EXPLOR	RER 115.4 2WD -> ZKDAV	90100TS10	0001] [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]
1	0.019.9867.4	1	tensioner
2	2.1310.006.2	1	flat washer 10.5x21
3	2 0314 322 2	1	screw



Section: B0 - ENGINE Ref: B0.02.5 (1)

# ENGINE FLYWHEEL

Fig.	P/n	QTY	Name	
Notes:				
	ER 115.4 2WD -> ZKDAV9	0100 <b>TS</b> 10	0001] [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]	
1	0.020.7681.3	1	flywheel	
1.2	0.069.1242.0	1	crown wheel $Z = 121$	
2	0.255.2525.0/10	1	flange	
3	2.0399.371.0	6	screw	

# 2 3 3 2 2 1.2 — 1.

# **EXPLORER 115.4 -> ZKDAV90200TS10001**

Section: B0 - ENGINE Ref: B0.02.6 (1)

# ENGINE FLYWHEEL

Fig.	P/n	QTY	Name
Notes: [EXPLOR	ER 115.4 2WD -> ZKDAV9	0100TS10	0001] [EXPLORER 115.4 4WD -> ZKDAV90200TS10001]
1	0.010.2000.2	1	
1	0.019.2098.3	1	flywheel
1.2	0.065.1242.0	1	crown wheel $Z = 123$
2	0.255.2525.0/10	1	flange
3	2.0399.371.0	6	screw

# 15 14 11 13 14 11 13 14 11 11 20 14 21

## EXPLORER 115.4 -> ZKDAV90200TS10001

Section: B0 - ENGINE Ref: B0.02.7 (2)

# **CRANKSHAFT**

1001

1002

0.065.1218.7

0.065.1218.8

Fig.	P/n	QTY	Name
Notes: [EXPLOR	ER 115.4 2WD -> ZKDAV9	0100TS1000	[EXPLORER 115.4 4WD -> ZKDAV90200TS10001]
1	0.019.2251.3/10	1	crankshaft
1.2	0.065.1211.0/10	1	crown wheel
1.3	2.1630.608.0	1	pin 6x16
1.4	2.1651.915.0	1	pin 12x35
1.5	0.007.0855.0/10	1	gear
7	0.019.5456.0	5	main half bushing STANDARD
8	0.019.5455.0	5	main half bushing STANDARD
9	2.1599.524.7	1	washer 21x60x12
10	0.065.1218.0	4	shim STANDARD
11	2.1529.073.0	1	special oil seal 110x130x13
12	0.065.1254.0/20	1	gasket
13	0.007.0851.0/10	1	cover
14	2.1475.002.2	9	conical washer 8
15	2.0112.207.2	7	screw m 8 p 1.25 x 20
20	2.0432.003.7	2	stud bolt m 8 p.1.25 / p.1 x 20
21	2.1011.405.2	2	nut m 8 p.1
1001	0.065.1010.5		0.10

shim + mm 0.10 shim + mm 0.15 Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com