

# 465 SKID STEER PARTS CATALOG

Publication Part Number: 7-9551 NA



Photograph may show installation of optional equipment.

DB05A000

This unit first became available in 01-2005.

- Table of Contents
- General Information
- Section 2 – Engine
- Section 3 – Fuel System
- Section 4 – Electrical System
- Section 5 – Tracks / Steering
- Section 6 – Power train
- Section 7 – Brakes
- Section 8 – Hydraulics
- Section 9 – Chassis/Attachments
- Index

---

CNH America, LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History			
Issue	Issue Date	Applicable Machines	Remarks
First Edition	11-2004	465	7-9550NA
Revision 1	01-2006	465	7-9551 NA

---

# TABLE OF CONTENTS

---

02-01	RADIATOR - COOLANT RECOVERY SYSTEM
02-02	FAN - FAN BELT
02-03	EXHAUST SYSTEM
02-04	ENGINE - AIR CLEANER
02-05	GRID HEATER
02-06	ENGINE - MOUNTING
02-06A	OIL FILL, ENGINE
02-07	ENGINE - PUMP DRIVE (WITH SPLIT PUMP CONFIGURATION)
02-07A	ENGINE - PUMP DRIVE (WITH TANDEM PUMP CONFIGURATION)
02-08	ENGINE
02-08A	ENGINE - BLOCK HEATER
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CYLINDER BLOCK - COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	MANIFOLD - EXHAUST
02-20A	TURBOCHARGER
02-21	CRANKSHAFT
02-22	PISTONS - CONNECTING ROD
02-23	PISTONS - CONNECTING ROD
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	CAMSHAFT
02-27	ENGINE, OIL
02-27A	TURBOCHARGER, PIPES AND CONNECTIONS
02-28	OIL PUMP - ENGINE
02-29	OIL FILTERS - ENGINE
02-30	OIL FILTER AND COOLER
02-31	WATER PUMP
02-32	COOLING SYSTEM - ENGINE
02-33	THERMOSTAT - ENGINE COOLING SYSTEM
02-34	WATER PUMP - CONTROL
02-35	FAN DRIVE
02-36	POWER TAKE OFF
02-37	ENGINE - LIFT HOOK
03-01	FUEL LINES
03-02	CONTROLS - THROTTLE
03-03	FUEL INJECTION PUMP
03-04	FUEL INJECTION SYSTEM
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	FUEL FILTER
03-08	FUEL PUMP
03-09	FUEL INJECTION SYSTEM
03-10	FUEL INJECTION SYSTEM

---

# TABLE OF CONTENTS

---

04-01	STARTER
04-02	ALTERNATOR
04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	BATTERY - CABLES
04-05	DISCONNECT SWITCH - REMOTE JUMP START
04-06	HARNESS, FRONT - CHASSIS
04-07	HARNESS, REAR - CHASSIS
04-09	SWITCH MOUNTING - CHASSIS OPTIONS
04-11	HARNESS - CAB, SEAT BAR
04-12	HARNESS - DOOR, FRONT
04-13	HARNESS, FRONT - AUXILIARY
04-14	WIPER, WINDSHIELD
04-15	CONTROLS, RIGHT HAND - HANDLE
04-15A	CONTROLS, RIGHT HAND - HANDLE
04-16	CONTROLS, LEFT HAND - HANDLE
04-16A	CONTROLS, LEFT HAND - HANDLE
04-17	LAMP ASSY - BEACON, ROTATING
04-18	HORN - MOUNTING
04-19	BACKUP ALARM
04-20	ELECTRICAL ACCESSORIES SOCKET
06-01	HYDROSTATICS - PUMP, SUPPLY AND RETURN (SPLIT PUMP CONFIGURATION)
06-01A	PUMP, TANDEM - MOUNTING (TANDEM PUMP CONFIGURATION)
06-01B	HYDROSTATICS - PUMP, SUPPLY AND RETURN (TANDEM PUMP CONFIGURATION)
06-02	OIL COOLER - MOUNTING
06-03	OIL COOLER - MOUNTING (HIGH FLOW)
06-04	HYDROSTATICS - CASE DRAIN
06-05	HYDROSTATICS - DRIVE MOTORS (WITH SPLIT PUMP CONFIGURATION)
06-05A	HYDROSTATICS - DRIVE MOTORS (WITH TANDEM PUMP CONFIGURATION)
06-06	HYDROSTATICS - TWO SPEED (SPLIT PUMP CONFIGURATION)
06-06A	HYDROSTATICS - TWO SPEED (TANDEM PUMP CONFIGURATION)
06-07	HYDROSTATICS - TWO SPEED, VALVE ASSY
06-08	FILTER ASSY - MOUNTING
06-09	TANDEM PUMP
06-10	TANDEM PUMP
06-11	TANDEM PUMP
06-12	TANDEM PUMP
06-13	TANDEM PUMP
06-14	TANDEM PUMP
06-15	TANDEM PUMP
06-16	TANDEM PUMP
06-17	PUMP, GEAR
06-17A	PUMP, GEAR (TANDEM PUMP CONFIGURATION)
06-18	PUMP, GEAR (HIGH FLOW)
06-19	MOTOR ASSY - SINGLE SPEED
06-20	MOTOR ASSY - SINGLE SPEED
06-21	MOTOR ASSY - SINGLE SPEED
06-22	MOTOR ASSY - TWO SPEED
06-23	MOTOR ASSY - TWO SPEED
06-24	MOTOR ASSY - TWO SPEED
06-25	MOTOR ASSY - TWO SPEED
06-26	MOTOR ASSY - TWO SPEED
06-27	MOTOR ASSY - TWO SPEED

---

# TABLE OF CONTENTS

---

06-28	PUMP, TANDEM (87350025)
06-29	PUMP, TANDEM (87350025)
06-30	PUMP, TANDEM (87350025)
06-31	PUMP, TANDEM (87350025)
06-32	PUMP, TANDEM (87350025)
06-33	PUMP, TANDEM (87350025)
06-34	AXLE ASSY
06-35	DRIVE LINE
06-36	WHEELS
07-01	BRAKE SYSTEM - HYDRAULIC
07-02	BRAKE SYSTEM - HYDRAULIC (WITH TANDEM PUMP CONFIGURATION)
08-01	HYDRAULICS - LOADER LIFT (WITH SPLIT PUMP CONFIGURATION)
08-01A	HYDRAULICS - LOADER LIFT (WITH TANDEM PUMP CONFIGURATION)
08-02	HYDRAULICS - LOADER BUCKET (WITH SPLIT PUMP CONFIGURATION)
08-02A	HYDRAULICS - LOADER BUCKET (WITH TANDEM PUMP CONFIGURATION)
08-03	HYDRAULICS - SELF-LEVELING
08-04	VALVE ASSY, SELF LEVEL
08-05	HYDRAULICS - AUXILIARY SYSTEM
08-06	HYDRAULICS - RIDE CONTROL
08-07	HYDRAULICS - COUPLER SYSTEM
08-08	VALVE ASSY, CONTROL - HIGH FLOW
08-09	VALVE ASSY, CONTROL - LOADER
08-10	VALVE ASSY, CONTROL - LOADER
08-11	CYLINDER - LOADER LIFT
08-12	CYLINDER - LOADER BUCKET
08-13	HYDRAULIC ATTACHMENTS - CONTROLS
08-14	HIGH FLOW (SPLIT PUMP CONFIGURATION)
08-14A	HIGH FLOW (TANDEM PUMP CONFIGURATION)
08-15	COMBINATION VALVE - HIGH FLOW
08-16	HIGH FLOW - AUXILIARY SYSTEM
08-17	SECONDARY FRONT AUXILIARY
08-18	SECONDARY FRONT AUXILIARY - VALVE ASSY
08-19	SECONDARY FRONT AUXILIARY
08-20	VALVE ASSY, CONTROL - HIGH FLOW
09-01	FRAME - LOADER LIFT
09-02	SUPPORT - LOADER FRAME
09-04	COUPLER, MECHANICAL
09-05	COUPLER, HYDRAULIC
09-06	BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET
09-06A	BUCKETS, LOADER - 2083 MM (82 IN) WIDE BUCKET
09-07	BUCKETS, LOADER - 2134 MM (84 IN) WIDE BUCKET
09-07A	BUCKET, CUTTING EDGE (BOLT-ON CUTTING EDGE)
09-07B	PALLET FORK
09-08	CHASSIS
09-09	PLATES, FLOOR
09-10	CONSOLE, CONTROL
09-11	CONTROLS - LOADER AND GROUND DRIVE
09-12	LINKAGE - LOADER AND GROUND DRIVE (SPLIT PUMP CONFIGURATION)
09-12A	LINKAGE - LOADER AND GROUND DRIVE (TANDEM PUMP CONFIGURATION)
09-13	LINKAGE - AUXILIARY SYSTEM
09-14	HOOD
09-15	DOOR, REAR

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)