



## **OPERATORS MANUAL**

F930H Hydraulic Wheel Drawbar Cart and Drawbar Attachments

OMA12479 C1 English

OMA12479 C1

LITHO IN U.S.A.





## to the purchaser

The purpose of this manual is to furnish valuable information about your new F930H Drawbar Cart and drawbar attachments. In it you will find instructions and helpful suggestions for operating, transporting, adjusting, lubricating, assembling, and servicing your new drawbar cart and drawbar attachments.

Keep this manual in a convenient place for quick and easy reference. Use it as a guide whenever questions arise.

You have purchased a dependable, sturdy machine, but only by proper care and operation can you expect to receive the service and long life designed and built into it.

If you need additional information, or if your drawbar cart and attachments require special servicing, see your John Deere dealer—he has all the facilities required to keep them

in A-1 condition. He will be glad to serve you.

Sometime in the future your drawbar cart and attachments may need new parts to replace worn or broken parts. If so, go to your John Deere dealer to obtain high-quality genuine John Deere parts. Inform your dealer concerning the type of drawbar cart and attachment you own and the date they were purchased. This information will help him to identify the part you need. We suggest that you record this information in the space provided below, thereby making it available for future reference.

## Location reference


Right- and left-hand sides referred to in this manual are determined from a position at the rear of the machine facing in the direction of travel.

JOHN DEERE F930H HYDRAULIC
WHEEL DRAWBAR CART
No. 3 DRAWBAR ATTACHMENT
No. 4 DRAWBAR ATTACHMENT
No. 5 DRAWBAR ATTACHMENT
No. 6 DRAWBAR ATTACHMENT
No. 7 DRAWBAR ATTACHMENT
No. 8 DRAWBAR ATTACHMENT
No. 9 DRAWBAR ATTACHMENT
(Check Attachments Purchased)
Date Purchased
(To be filled in by Purchaser)




## contents


**************************************	Page
IDENTIFICATION VIEWS	2-8
SPECIFICATIONS	9-11
OPERATION	12-42
General	12
Preparing the Drawbar Cart and Attachments	12-13
Preparing and Adjusting Tractor	14
Hitching to Tractor	15
Outer Wheel Adjustment	15
Hydraulic Controls	16
Field Transport Position	17
Road Transport Position	17-25
Field Operating Position	26-30
Storage Position	31-32
Tine-Tooth Harrow Adjustments	33-36
Spike-Tooth Harrow Adjustments	<b>3</b> 6
Rotary-Hoe Adjustments	37
Spring-Tooth Harrow Adjustments	38
Spring Teeth	39
Detaching and Attaching Drawbar Attachments	40-41
Transporting	42
Safety Rules	42
MAINTENANCE	43
LUBRICATION	44-45
ASSEMBLY	46-74
GIIIDDING DIMIDI EG	40 45




John Deere F930H Hydraulic Wheel Drawbar Cart with No. 3 Drawbar Attachment and Five No. 12A Tine-Tooth Harrow Sections in Working Position




John Deere F930H Hydraulic Wheel Drawbar Cart with No. 4 Drawbar Attachment and Seven No. 12A Tine-Tooth Harrow Sections in Storage Position




John Deere F930H Hydraulic Wheel Drawbar Cart with No. 5 Drawbar Attachment and four No. 12 Rotary Hoe Sections in field operating position




John Deere F930H Hydraulic Wheel Drawbar Cart with No. 6 Drawbar Attachment and four No. 14 Rotary Hoe Sections in field transport position



John Deere F930H Hydraulic Wheel Drawbar Cart with No. 7 Drawbar Attachment and five No. 30 Spike-Tooth Harrow Sections in working position



John Deere F930H Hydraulic Wheel Drawbar Cart with No. 8 Drawbar Attachment with Caster Ourer Wheels (Special equipment) and seven No. 30 Spike-Tooth Harrow Sections in working position



John Deere F930H Hydraulic Wheel Drawbar Cart with No. 9 Drawbar Attachment and four Spring-Tooth Harrow Sections in working position

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com