

NO. 2 SWATH FLUFFER



OPERATORS MANUAL NO. 2 SWATH FLUFFER


OME15501 (01SEP60) English

OME15501 (01SEP60)

LITHO IN THE U.S.A.
ENGLISH



INTRODUCTION



E 584

Your new John Deere No. 2 Swath Fluffer is a dependable machine, and with proper care and operation you can expect to receive the service and long life designed and built into it. Like any precision machine, your fluffer will require a certain amount of attention at regular intervals. When any questions arise regarding lubrication, operation, or maintenance, use your manual as a guide to service your machine the RIGHT WAY.

If you find yourself in need of additional information or special servicing not covered in this manual, see your John Deere dealer. He is in a position to answer your questions for you, or to secure the correct information.

When in need of parts, either to replace worn parts or to make emer-

gency repairs, see your local John Deere dealer.

When ordering parts, provide your dealer with the serial number of your Swath Fluffer. This information will help him to give you prompt and efficient service.

The serial number of your machine is located on the rear right-hand side of the tongue. (Record it in the space below.)





TABLE OF CONTENTS

	Page
IDENTIFICATION VIEW	2
SPECIFICATIONS	2
OPERATION AND ADJUSTMENTS	3-6
Before Operation	3
Field Operation	4
Reel Height	5
Hand Clutch	5
Transporting	6
Safety Precautions	6
LUBRICATION	7
ASSEMBLY	R





John Deere No. 2 Swath Fluffer

SPECIFICATIONS

Operating Speed
Over-All Height
Over-All Length
Over-All Width
Number of Teeth
Reel Diameter
Reel Width 7 Ft.
Size of Pneumatic Tires
Tire Pressure
Weight230 Lbs.

NOTE: Right- and left-hand sides referred to in this manual are determined from a position at the rear of the machine facing in the direction of travel.

 $(Specifications\ and\ design\ subject\ to\ change\ without\ notice.)$

OPERATION AND ADJUSTMENTS

BEFORE OPERATION

On the following pages you will find information on how to operate your John Deere No. 2 Swath Fluffer to the best advantage. If you carefully read and use this information, your swath fluffer will give years of dependable and economical service.

The John Deere No. 2 Swath Fluffer is a modern, ground-driven machine, designed for today's high-speed farming methods. It is a big-capacity machine with a 7-foot reel. The swath fluffer will permit you to operate at maximum speed with a minimum handling of your crop.

Once the machine is adjusted to suit field conditions, it is easy to operate. The only adjustment required for satisfactory operation is the height of the teeth in relation to the ground.

When starting a new swath fluffer, disengage the hand clutch, then turn the reel by hand to be sure it revolves freely and the teeth do not strike the strippers. Engage the reel with the hand clutch.


Before starting, make sure that all bolts are tight, cotter pins are spread, and the machine has been properly assembled.

Be sure the machine has been lubricated as shown in the lubrication chart.

The turning radius of the tractor and swath fluffer combination can be reduced by moving the tractor rear wheels to a more narrow setting. Doing this will make shorter turns possible and prevent damage resulting from the swath fluffer frame striking the tractor tires on extremely short turns.

An occasional thorough inspection for loose nuts and worn parts will add to the efficiency of your swath fluffer.

Breakage of parts, which causes serious delay and additional expense, can be avoided by taking the foregoing precautions before entering the field.



Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com