127 CORN PICKER ONE-ROW MOUNTED FOR MODELS 40, 50, 60, A AND B (SERIAL NO. 127-352)





OPERATORS MANUAL

127 CORN PICKER ONE-ROW MOUNTED FOR MODELS 40, 50, 60, A AND B (SERIAL NO. 127-352)

OMN24354 C4 English

JOHN DEERE DES MOINES WORKS OMN24354 C4

LITHO IN THE U.S.A. (REVISED) ENGLISH



FOREWORD

The purpose of this book is to give you useful information on how best to operate your new John Deere No. 127 Corn Picker in the many field and crop conditions under which corn is grown.

A Corn Picker must be built to handle a wide range of conditions. Average conditions can be handled by the standard equipment with which picker is shipped. However, unusual conditions may require some special equipment. Your new No. 127 will do a type of work directly proportional to the amount of care you use in operating it.

Field conditions vary from year to year, from day to day and even from hour to hour. Different varieties of corn present widely different picking problems. A careful study of adjustments on your picker and what they accomplish under different conditions will allow you to reap the many benefits and economies that a picker can provide.


If you find you need information not covered in this manual, see your John Deere dealer. He has the latest information on how to get the best service from your picker and can give you prompt "know-how" service in the field or in his shop.

When in need of parts, go to your John Deere dealer who carries genuine John Deere parts for your corn picker. Be sure to give him the serial number of your corn picker and the year purchased. This information should be recorded in the space provided on this page as soon as you have received your picker.

Location Reference: Right and Left-hand referred to in this manual, are determined from a position at the rear of the machine facing in the direction of travel.

Serial Number of This Picker is:							
127—							
Date Purchased							

You will find the Serial Number Plate on the outer main frame as illustrated at the right.



JOHN DEERE DEALER'S DELIVERY REPORT

on the

No. 127 CORN PICKER

The John Deere No. 127 Corn Picker has been designed and built to give years of satisfactory service. Intelligent operation, proper adjustment, and regular care by the operator are important factors in obtaining peak performance and long service from the picker.

By the use of this delivery report you can insure that your customer understands the operation, adjustment, and care of his new corn picker. It will also provide valuable information that will enable us to continue to design and build corn pickers to meet your customer's needs.

The delivery report is divided into three parts. The use and purpose of each part is explained below:

Part 1, below, provides space for recording the customer's and dealer's names and addresses, and the serial number of the corn picker. This information should be recorded before delivering the corn picker.

Part 2, on the reverse side, is a delivery check list of the points which should be explained to the owner about his new corn picker. Discuss each point fully to be sure the owner understands the use of the corn picker. Point out that each item is discussed in the operator's manual. (It would be a good idea to go through the manual with him.) As each point is discussed, put a cross (X) in the box provided.

Part 3, also on the reverse side, covers the farming operations of the new owner. The information obtained about his farming operations will help us continue to produce corn pickers best suited to the various types of farming and the use which will be made of the picker. Please record accurate answers to each question in the appropriate boxes.

When the delivery report has been completed, it should be signed by both the owner and the dealer. Give the completed form to your John Deere territory manager who will see to it that the form is returned to the Company.

Thank you.

JOHN DEERE

Moline, Illinois

1. OWNER REGISTRATION						
Delivered to	(Purchaser's Name)	Dealer Making Delivery(Name of Dealership)				
Address	(Street Number, R.R., Etc.)	Address (Street Number, R.R., Etc.)				
City		City				
County		County				
State		State				

Please Fill Out Parts 2 and 3 on the Reverse Side of This Report When the Corn Picker Is Delivered.

JOHN DEERE No. 127 CORN PICKER DELIVERY REPORT

Fill in This Information at the Customer's Farm

2. DELIVERY CHECK LIST

At the time of delivery, explain to the customer all of the operations and adjustments listed below. Use the operator's manual as a guide and put a cross (X) in the appropriate box in front of each item as you discuss it.

	Ву			By.			
		(Owner)		O.g.		(Dealer)	
Date:	Signed			Sign	ned		
I have taken delivery of the	above machine an	ıd have been instr	ructed i	in its operatio	n and mainte	enance.	
expect to pick?	OM WOLK GOES HE	(Acres)	17.			Age.	
8. How many acres of cust		ļ] : 1 4	What tracto	or will custom	er use with his N	No. 127 picker
His own and custor	n work	- 1	}	Make	Mode	1Age_	Yrs
Custom work only_			13.	If it is repla	cing another,	what is it?	
Pick own corn only	·	_					_
7. Will the customer:		į	 			No.	7
6. How many acres does he	usually cut for silag	ge?	12.	Is the John another p	Deere No. 12 icker? (Check		
		(Bu. per Acre)					
5. What yield does custome	er usually expect?			Make		Model	
		(Acres)	į			Model	
4. How many acres does cu	istomer put in corr	1?		Make		Model	
	No		11.	If this isn't others doe	his only corn es he have?	picker, what	
	Yes						
3. Does the customer conto	our his farm?					No	
	Level	_ U			•	Yes	
	Rolling		10.	Is this his o	nly corn pick	er? (Check one)	
•	Hilly					140	
2. Is the farm mostly: (Che						No.	
_		(Acres)	-		1? (Check one		
Total acreage in customs			g,	Is this the fir	st corp picker	the customer	
continue to design and build following questions about th	l corn pickers to m	neet his needs. To					
The John Deere No. 127 Co		STOMER'S FAI en designed to ser				y and effectively	y. We want to
	2 611	STOMEDIS FAI	DAGING	CORFRITI	ONE	<u> </u>	
Wagon elevator throw-	out adjustment.	3	□ ′	I'ractor tire p	ressures and	rear wheel tread.	
Lift adjustment.		Comprehense	_	Mounting and			
Husking roll adjustmen	nt.	i		Wagon elevat	or height.		
Snapping roll adjustme	ent.	j	_	Fan belt idler	•		
Lubrication and check	for loose bolts.			Slip clutches-	_		
Picker Service		!		Main drive sp			
D: 1 C :		ļ	_	Main drive ch			
Post-season service and	i storage.	ĺ	٠, ا	Wagon elevate	or chain tight	eners.	
Crop and weather cond	litions.	age.		First elevator ment.	chain tighter	ner and hold-dov	wn rod adjust
Safety precautions.				Gatherer thro	at adjustmen	t.	
Operator's manual.		l l		Gatherer chair	n tighteners a	and lug spacing.	
General				Gatherer poin	t setting.		

TABLE OF CONTENTS

SPECIFICATIONS AND DATA	Page 4
LUBRICATION	5-11
OPERATION	12-23
General Instructions Gatherers Row Width Adjustment Snapping Rolls First Elevator Conveyor Chain Husking Rolls Husk Auger Fan Wagon Elevator Chains Slip Clutches Safety First	12 13-14 14 15 16 17 18 18 19 20 21
Radiator Screen and Engine Side Shields Service—When the Season is Over Service—At the Beginning of the Season	22 23 23
REMOVING PICKER FROM MODEL "40" TRACTOR	24-30
REMOVING PICKER FROM MODELS "A", "B", "50" AND "60" TRACTORS	
MOUNTING PICKER ON MODELS "A", "B", "50" AND "60" TRACTORS	51-63
GUIDE TO BETTER CORN PICKING	64-67
EXTRA EQUIPMENT	68–69
Gatherer Fender Rods Wagon Box Steel Flareboards Spiral Strips for Snapping Rolls Tractor Light Extension Brackets Tractor Clutch Lever Extension Trash Knives No. 1 Trash Mover Special First Elevator Flights and Stripper	68 68 69 70–72 72
Gatherer Extension	73

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com