

**AXIAL-FLOW<sup>®</sup> 7240**  
**AXIAL-FLOW<sup>®</sup> 8240**  
**AXIAL-FLOW<sup>®</sup> 9240**  
**Tier 4B (final)**  
Combine

**SERVICE MANUAL**

Part number 47800118

1<sup>st</sup> edition English

November 2014

Copyright © 2014 CNH Industrial America LLC. All Rights Reserved.



## Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
AXIAL-FLOW® 7240 Tier 4b engine, for European market	Europe	F3GFE613A*B001
AXIAL-FLOW® 8240 Tier 4b engine, for EU market	Europe	F3HFE613A*B003
AXIAL-FLOW® 9240 Tier 4b engine, for EU market	Europe	F3JFE613A*B001

# Contents

---

## INTRODUCTION

<b>Engine</b> .....	<b>10</b>
[10.001] Engine and crankcase .....	10.1
[10.202] Air cleaners and lines .....	10.2
[10.210] Lift pump and lines .....	10.3
[10.216] Fuel tanks .....	10.4
[10.254] Intake and exhaust manifolds and muffler .....	10.5
[10.310] Aftercooler.....	10.6
[10.400] Engine cooling system .....	10.7
[10.414] Fan and drive .....	10.8
[10.418] Rotary screen .....	10.9
[10.419] Stationary air screen .....	10.10
[10.450] Engine air compressor .....	10.11
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.12
<b>Main gearbox and drive</b> .....	<b>14</b>
[14.100] Main gearbox and drive .....	14.1
<b>Transmission</b> .....	<b>21</b>
[21.100] Mechanical transmission lubrication system .....	21.1
[21.114] Mechanical transmission .....	21.2
[21.130] Mechanical transmission external controls.....	21.3
[21.145] Gearbox internal components.....	21.4
[21.182] Differential.....	21.5
<b>Front axle system</b> .....	<b>25</b>
[25.100] Powered front axle .....	25.1
[25.108] Final drive hub, steering knuckles, and shafts .....	25.2
[25.310] Final drives .....	25.3

<b>Rear axle system</b> .....	<b>27</b>
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts .....	27.2
[27.550] Non-powered rear axle.....	27.3
<b>Hydrostatic drive</b> .....	<b>29</b>
[29.100] Transmission and steering hydrostatic control .....	29.1
[29.202] Hydrostatic transmission .....	29.2
[29.218] Pump and motor components.....	29.3
[29.300] Rear hydrostatic transmission.....	29.4
<b>Brakes and controls</b> .....	<b>33</b>
[33.110] Parking brake or parking lock .....	33.1
[33.202] Hydraulic service brakes .....	33.2
<b>Hydraulic systems</b> .....	<b>35</b>
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.220] Auxiliary hydraulic pump and lines .....	35.4
[35.300] Reservoir, cooler, and filters.....	35.5
[35.350] Safety and main relief valves .....	35.6
[35.359] Main control valve.....	35.7
[35.440] Grain tank unload system .....	35.8
[35.518] Reel control system .....	35.9
[35.536] Crop processor system .....	35.10
[35.752] Hydraulic fan drive cooling system.....	35.11
<b>Steering</b> .....	<b>41</b>
[41.101] Steering control .....	41.1
[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders .....	41.3

[41.432] Autoguidance steering .....	41.4
<b>Wheels .....</b>	<b>44</b>
[44.511] Front wheels .....	44.1
<b>Tracks and track suspension .....</b>	<b>48</b>
[48.100] Tracks .....	48.1
[48.130] Track frame and driving wheels .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.104] Ventilation .....	50.2
[50.200] Air conditioning .....	50.3
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system .....	55.2
[55.100] Harnesses and connectors .....	55.3
[55.201] Engine starting system .....	55.4
[55.421] Feeding control system .....	55.5
[55.426] Harvest material flow control system .....	55.6
[55.628] Threshing electrical control .....	55.7
[55.780] Shaker shoe leveling system control .....	55.8
[55.988] Selective Catalytic Reduction (SCR) electrical system .....	55.9
[55.DTC] FAULT CODES .....	55.10
<b>Product feeding .....</b>	<b>60</b>
[60.105] Floating roll, feed chain, and drive .....	60.1
[60.110] Feeder housing .....	60.2
[60.112] Stone trapping system .....	60.3
[60.150] Feeder drive system .....	60.4

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)