# 4050, 4250, 4450, 4650 and 4850 Tractors



## **TECHNICAL MANUAL**

4050, 4250, 4450, 4650 and 4850 Tractors

TM1259 (01Sep87) English

TM1259 (01Sep87)

LITHO IN U.S.A. ENGLISH

## 4050,4250,4450,4650 AND 4850 TRACTORS **TECHNICAL MANUAL** TM-1259 (SEP-87)

#### **CONTENTS—OPERATION AND TESTS**

This manual covers Tractor Operation and Tests (yellow tabs). Repair (green tabs) is covered in TM-1353 (formerly TM-1257) (4050,4250 and 4450 Tractors),TM-1354 (formerly TM-1258) (4650 and 4850 Tractors), CTM1 (6466 Engines), and CTM7 (Radial Piston Pumps).

SECTION 210-GENERAL Introduction and Safety Information

SECTION 220-ENGINE OPERATION AND TESTS

Group 05—System Operation

Group 10—System Tests and Diagnosis

SECTION 230—FUEL/AIR OPERATION AND TESTS

Group 05-Air Intake System Group 10-Diesel Fuel System

Group 15-Control Linkage

SECTION 240-ELECTRICAL SYSTEM

Group 05-Electrical System Information

Group 06-Phase I Electrical Wiring Diagrams

Group 07—Phase II Electrical Wiring Diagrams

Group 10-Electrical System Diagnosis

Group 15—Delcotron Charging Circuit

Group 16—John Deere Charging Circuit

Group 20-Starting Circuit

Group 25-Lighting Circuit

Group 30—INVESTIGATOR™ II and Digital Tachometer

Group 31—Gauge Cluster Instrumentation

Group 32—Analog Tachometer

Group 35—Accessories Circuit

Group 40—PERFORMANCE TRAK™ I Radar Sensor System (Tachometer Version)

Group 41-PERFORMANCE TRAK™ II Radar

Sensor System (Mini-Monitor)

Group 42-PERFORMANCE TRAK™ III Radar Sensor System (Multi-Function Monitor)

SECTION 250-POWER TRAIN (PERMA-CLUTCH TRANSMISSION)

Group 05—QUAD-RANGE™ System Operation

Group 10—PERMA-CLUTCH™ Operation

Group 15—QUAD-RANGE™ Planetary

Group 20—QUAD-RANGE™ Eight-Speed

Group 25-Transmission Oil Pump

Group 30-Transmission Lubrication Valve

Group 35-Transmission Control Valves

Group 40-Differential and Final Drive

Group 45—SYNCRO-RANGE™ Transmission

Group 55-PTO

Group 60—QUAD RANGE™ Transmissions Diagnosis

SECTION 255—POWER SHIFT TRANSMISSION

Group 05-Mechanical Operation

Group 10-Hydraulic Controls

Group 15-PTO, Differential and Final Drives

Group 16-Power Shift Transmission Diagnosis

Group 20—Mechanical Front Wheel Drive

Continued on next page

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

### **CONTENTS—OPERATION AND TESTS—CONTINUED**

SECTION 260—STEERING/BRAKES OPERATION AND TESTS

Group 05-4050, 4250, and 4450 Power Steering

Group 06-4650 and 4850 Power Steering

Group 10-Power Brakes

SECTION 270—HYDRAULIC OPERATION AND TESTS

Group 05—PERMA-CLUTCH™ Transmission Operation

Group 10—Power Shift Transmission Hydraulic System Operation and Tests

Group 15-Main Hydraulic Pump

Group 20—QUAD-RANGE™ Transmission Hydraulic Valves

Group 25—Power Shift Transmission Hydraulic Valves

Group 30-Pressure Control Valve

Group 35—HYDRACUSHIONED™ Seat

Group 40—Rockshaft Operation (4050, 4250, 4450)

Group 45-Rockshaft Operation (4650 and 4850)

Group 50-Selective Control Valve

Group 55-Remote Cylinder

Group 60-QUAD-RANGE Hydraulic Diagnosis

Group 65—Power Shift Transmission Hydraulic Diagnosis

SECTION 290—OPERATOR STATION
OPERATIONS AND TESTS

Group 05—Air Conditioning System

Group 10—Air Conditioning System Tests— Introduction

Group 11—System Tests Without Timer Relay-Warning Lamps

Group 12—System Tests With Timer Relay-Warning Lamps

Group 15—Heating System Operation Tests

Group 20—HYDRACUSHIONED™ Seat

SECTION 299—SPECIAL TOOLS

Group 05—Purchased Tools

Group 10-Fabricated Tools

Group 15—Test Equipment Calibration

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com