

**1150M**  
**Tier 2**  
**Crawler Dozer**  
*PIN NGC105100 and above*

**SERVICE MANUAL**

**Part number 48080035**  
1<sup>st</sup> edition English  
April 2017





## **SERVICE MANUAL**

**1150M Power Angle Tilt (PAT) Blade, Long Track (LT) - Tier 2 [NGC105100 - ]**  
**1150M Power Angle Tilt (PAT) Blade, Wide Track (WT) - Tier 2 [NGC105100 - ]**

## Link Product / Engine

Product	Market Product	Engine
1150M Power Angle Tilt (PAT) Blade, Long Track (LT) - Tier 2 [NGC105100 - ]	Middle East Africa	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Long Track (LT) - Tier 2 [NGC105100 - ]	Latin America	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Long Track (LT) - Tier 2 [NGC105100 - ]	Asia Pacific	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Long Track (LT) - Tier 2 [NGC105100 - ]	Australia New Zealand	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Wide Track (WT) - Tier 2 [NGC105100 - ]	Australia New Zealand	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Wide Track (WT) - Tier 2 [NGC105100 - ]	Latin America	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Wide Track (WT) - Tier 2 [NGC105100 - ]	Asia Pacific	F4HFA613L*E002
1150M Power Angle Tilt (PAT) Blade, Wide Track (WT) - Tier 2 [NGC105100 - ]	Middle East Africa	F4HFA613L*E002

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.202] Air cleaners and lines .....	10.2
[10.206] Fuel filters .....	10.3
[10.304] Engine lubrication system.....	10.4
[10.310] Aftercooler.....	10.5
[10.400] Engine cooling system .....	10.6
[10.414] Fan and drive .....	10.7
Hydrostatic drive.....	29
[29.218] Pump and motor components.....	29.1
Brakes and controls .....	33
[33.110] Parking brake or parking lock .....	33.1
[33.202] Hydraulic service brakes .....	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.105] Charge pump.....	35.4
[35.359] Main control valve.....	35.5
[35.741] Dozer blade cylinders .....	35.6
Tracks and track suspension.....	48
[48.130] Track frame and driving wheels.....	48.1
[48.100] Tracks .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4

[48.140] Dropbox and final drive .....	48.5
[48.AAA] Tracks and track suspension generic sub-group .....	48.6
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.104] Ventilation .....	50.2
[50.200] Air conditioning .....	50.3
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.011] Fuel tank system .....	55.2
[55.014] Engine intake and exhaust system .....	55.3
[55.015] Engine control system .....	55.4
[55.030] Service brake electrical system .....	55.5
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system .....	55.6
[55.100] Harnesses and connectors .....	55.7
[55.201] Engine starting system .....	55.8
[55.202] Cold start aid .....	55.9
[55.301] Alternator .....	55.10
[55.302] Battery .....	55.11
[55.408] Warning indicators, alarms, and instruments .....	55.12
[55.512] Cab controls .....	55.13
[55.518] Wiper and washer system .....	55.14
[55.DTC] FAULT CODES .....	55.15
<b>Dozer blade and arm .....</b>	<b>86</b>
[86.110] Dozer blade .....	86.1
[86.124] Dozer pushbeams and struts .....	86.2
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.160] Cab interior trim and panels .....	90.1
[90.120] Mechanically-adjusted operator seat .....	90.2

[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.100] Engine hood and panels .....	90.4

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)