

5440 and 5460 Self-Propelled Harvesters



TECHNICAL MANUAL 5440 and 5460 Self-Propelled Harvesters

TM1177 (01APR77) English

TM1177 (01APR77)

LITHO IN U.S.A. ENGLISH



5440 AND 5460 SELF-PROPELLED HARVESTERS

Technical Manual TM-1177 (Apr-77)

CONTENTS

SECTION 10 - GENERAL	SECTION 30 - FUEL SYSTEM
Group 5 - Specifications	Group 5 - General Information
Group 10 - Predelivery, Delivery, and After-Sale	Group 10 - Diagnosing Malfunctions
Services	Group 15 - Fuel Injection System
Group 15 - Tune-Up	Group 20 - Air Intake System
Group 20 - Lubrication	Group 25 - Specifications, Torques, and Special
Group 25 - Diagnosing and Testing Procedures	Tools
Group 30 - Separation	
Group 35 - Torque Values and Special Tools	SECTION 40 - ELECTRICAL SYSTEM
, , , , , , , , , , , , , , , , , , ,	Group 5 - General Information and Diagrams
SECTION 20 - ENGINE	Group 10 - Delcotron Charging Circuit
Group 5 - General Information (6404A OEM	Group 15 - Delco-Remy Starting Circuit
Engine)	Group 20 - John Deere Starting Circuit
Group 10 - Diagnosing Malfunctions (6404A)	Group 25 - Lighting and Miscellaneous
Group 15 - Cylinder Head, Valves, and	Components
Camshaft (6404A)	Group 30 - Specifications and Special Tools
Group 20 - Cylinder Block, Liners, Pistons, and	
Rods (6404A)	SECTION 50 - POWER TRAIN
Group 25 - Crankshaft, Main Bearings, and	Group 5 - Diagnosing Malfunctions
Flywheel (6404A)	Group 10 - Hydrostatic Drive
Group 30 - Lubrication System (6404A)	Group 15 - Transmission
Group 35 - Cooling System (6404A)	Group 20 - Differential
Group 40 - Specifications, Torques, and Special	Group 25 - Final Drive
Tools (6404A)	Group 30 - Power Rear Wheel Drive
Group 45 - General Information (6619A OEM	Group 35 - Specifications, Torques, and Special
Engine)	Tools
Group 50 - Diagnosing Malfunctions (6619A)	
Group 55 - Cylinder Head, Valves, and	SECTION 60 - STEERING AND BRAKES
Camshaft (6619A)	Group 5 - Diagnosing Malfunctions
Group 60 - Cylinder Block, Liners, Pistons, and	Group 10 - Steering
Rods (6619A)	Group 15 - Brakes
Group 65 - Crankshaft, Main Bearings and	Group 20 - Specifications, Torques, and Special
Flywheel (6619A)	Tools
Group 70 - Lubrication System (6619A)	
Group 75 - Cooling System (6619A)	
Group 80 - Specifications, Torques, and Special	
Tools (6619A)	

CONTENTS—Continued

SECTION 70 - HYDRAULIC SYSTEM

Group 5 - General Information and Tests

Group 10 - Diagnosing Malfunctions

Group 15 - Reservoir

Group 20 - Hydraulic Pump

Group 25 - Hydraulic Valves

Group 30 - Hydraulic Cylinders

Group 35 - Reverse Knife Grinder Motor

Group 40 - Breakaway Coupler

Group 45 - Spout Control Motor

Group 50 - Specifications and Torques

SECTION 80 - MACHINE FUNCTIONS

Group 5 - General Information

Group 10 - Diagnosing Malfunctions

Group 15 - Clutch

Group 20 - Main Gear Case

Group 25 - Fan and Spout

Group 30 - Cutterhead, Knife Grinder, and Feed

Rolls

Group 35 - Augers

Group 40 - Specifications, Torques, and Special

Tools

SECTION 90 - OPERATOR'S CAB

Group 5 - Pressurizer System

Group 10 - Air Conditioning System

Group 15 - Heater System

Group 20 - Specifications, Torques, and Special

Tools

SECTION 100 - HARVESTING UNITS

Group 5 - 7-Foot Hay Pickup Unit

Group 10 - Row Crop Units

Group 15 - Corn Head Attaching Parts

Group 20 - Mower Bar Unit

Group 25 - Specifications and Torques

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Copyright© 1974
DEERE & COMPANY
Moline, Illinois
All rights reserved

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com