

5720 and 5820 Self-Propelled Forage Harvesters



TECHNICAL MANUAL 5720 and 5820 Self-Propelled Forage Harvesters

TM1244 (01DEC84) English

TM1244 (01DEC84)

LITHO IN U.S.A (REVISED)
ENGLISH



5720 and 5820 Self-Propelled Forage Harvesters

Technical Manual TM-1244 (DEC-84)

CONTENTS

SECTION 10 - GENERAL

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Predelivery, Delivery and After-Sale Service
- Group 10 - Tune-Up
- Group 15 - Lubrication
- Group 20 - Diagnosing and Testing Procedures
- Group 25 - Engine Removal

SECTION 20 - ENGINE REPAIR (6466A)

- Group 00 - Specifications and Special Tools
- Group 05 - Cylinder Head, Valves and Camshaft
- Group 10 - Cylinder Block, Liner, Pistons and Rods
- Group 15 - Crankshaft, Main Bearings and Flywheel
- Group 20 - Lubrication System
- Group 25 - Cooling System

SECTION 25 - ENGINE REPAIR (6619A)

- Group 00 - Specifications and Special Tools
- Group 05 - Cylinder Head, Valves and Camshaft
- Group 10 - Cylinder Block, Liners, Pistons and Rods
- Group 15 - Crankshaft, Main Bearings and Flywheel
- Group 20 - Lubrication System
- Group 25 - Cooling System

SECTION 30 - FUEL AND AIR REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Air Intake System
- Group 10 - Diesel Fuel System

SECTION 40 - ELECTRICAL REPAIR

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Charging System (-594000)
- Group 10 - Charging System (594001-)
- Group 15 - John Deere Starter
- Group 20 - Delco-Remy Starting Motor
- Group 25 - Lights, Instruments and Accessory Repair

SECTION 50 - POWER TRAIN

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Hydraulic Oil Lines and Hoses
- Group 10 - Hydrostatic Drive
- Group 15 - Transmission
- Group 20 - Differential
- Group 25 - Final Drive
- Group 30 - Power Rear Wheel Drive
 - 5720 (-604141)
 - 5820 (-594000)
- Group 34 - Cam Lobe Motor
 - 5720 (604142-)
 - 5820 (594001-)
- Group 35 - Cam Lobe Motor Repair
- Group 40 - Power Rear Wheel Control Valve

SECTION 60 - STEERING AND BRAKES

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Shaft Seal
- Group 10 - Steering Hand Pump
- Group 15 - Steering Control Valve
- Group 20 - Steering Cylinder
- Group 25 - Steering System
- Group 30 - Brakes
- Group 35 - Master Cylinder
- Group 40 - Slave Cylinder

CONTENTS

SECTION 70 - HYDRAULIC REPAIR

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Hydraulic Outlet
- Group 10 - Reservoir
- Group 15 - Main Hydraulic Pump (-680000)
- Group 20 - Main Hydraulic Pump (680001-)
- Group 25 - Gear Case Cooler Pump
- Group 30 - Main System Control Valve
- Group 31 - Relief Valves
- Group 35 - Height Control Valve
- Group 40 - Lift Cylinder
- Group 45 - Belt Tightener Cylinder
- Group 50 - Knife Sharpener Motor
- Group 55 - Spout Control Motor
- Group 60 - Electrohydraulic Modules
- Group 65 - Rotary Screen Motor (594001-)

SECTION 80 - MACHINE FUNCTIONS

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Diagnosing Malfunctions
- Group 10 - Feed Rolls
- Group 15 - Stationary Knife
- Group 20 - Feed Roll Arm
- Group 25 - Knife Bracket
- Group 30 - Cutterhead
- Group 35 - Knife Sharpener
- Group 40 - Feed Roll Gear Case
- Group 45 - Augers
- Group 50 - Fan and Spout
- Group 55 - Clutch
- Group 60 - Main Gear Case

SECTION 90 - OPERATOR'S STATION REPAIR

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Pressurizer System
- Group 10 - Air-Conditioning System
- Group 15 - Cab Removal
- Group 20 - Heating System
- Group 25 - Lights, Instruments and Accessories
- Group 30 - Personal Posture Seat
- Group 35 - Miscellaneous Components

SECTION 100 - HARVESTING UNITS

- Group 00 - Specifications and Torques
- Group 25 - Kernel Processor

SECTION 220 - ENGINE OPERATION AND TESTS (6466A)

- Group 00 - Specifications and Special Tools
- Group 05 - System Operation
- Group 10 - System Tests and Diagnosis

SECTION 225 - ENGINE OPERATION AND TESTS (6619A)

- Group 00 - Specifications and Special Tools
- Group 05 - System Operation
- Group 10 - System Tests and Diagnosis

SECTION 230 - FUEL/AIR OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - Air Intake System
- Group 10 - Diesel Fuel System

SECTION 240 - ELECTRICAL OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - General Information and Diagrams (-594000)
- Group 15 - Charging Circuit Diagnosis (594001-)
- Group 20 - Test John Deere Starter
- Group 25 - Test Delco-Remy Starter
- Group 30 - Test Metal Detector (-650000)
- Group 35 - IRON-GARD™ Metal Detector
- Group 40 - Test Electric Clutch

SECTION 250 - POWER TRAIN OPERATION AND TESTS

- Group 00 - Specifications, Torques and Special Tools
- Group 05 - Diagnosing Power Train Malfunctions
- Group 10 - Power Train Operation and Tests
- Group 15 - Power Rear Wheel Drive Operation and Tests 5720 (-604141)
- Group 20 - Power Rear Wheel Drive 5720 (604142-)
5820 (594001-)

CONTENTS

SECTION 260 - STEERING/BRAKES OPERATION

- Group 05 - Steering
- Group 10 - Brakes

SECTION 270 - HYDRAULIC TESTING

- Group 00 - Specifications, Torques and
Special Tools
- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Test Hydraulic System
- Group 20 - Rotary Air Screen

SECTION 290 - OPERATOR STATION OPERATION AND TESTS

- Group 00 - Specifications, Torques and
Special Tools
- Group 05 - Pressurizer System
- Group 10 - Air Conditioning System Operation
- Group 15 - Air Conditioning System Tests
and Diagnosis
- Group 20 - Heating System Operation and Tests
- Group 25 - Lights, Instruments and Accessories

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT® 1985
DEERE & COMPANY
Moline, Illinois
All rights reserved
A JOHN DEERE ILLUSTRATION

E03;0000 C 020385

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com